



NESPRESSO | DESCALING





IMPORTANT INFORMATION BEFORE YOU BEGIN

Nespresso recommends descaling every 3 months or 300 capsules (whichever comes first).

Nespresso machines should be descaled with a Nespresso Descaling Kit which contains a natural solution that thoroughly dissolves the scale build up. Other solutions (such as vinegar or store-bought descalers) may cause damage to your Nespresso machine.

Descaling solution can damage or discolor surfaces so we suggest placing something underneath your machine in case a spill should occur. If a spill does occur, please make sure to clean up the solution immediately to avoid any damage.

Keep descaling solution out of reach of children.

In case of contact with eyes, rinse immediately with plenty of water for 15 minutes and seek medical advice.

Do not swallow or ingest the descaling solution.

The descaling solution may be irritating to the eyes and skin.

Avoid filling up the water tank during the descaling process.

After descaling, wipe down the machine with a damp cloth.



VERTUO POP

**Duration: 20 Minutes (cannot be interrupted)****STEP 1**

Descaling is needed when the cup button blinks orange 3 times before steady white. Eject any capsules. With machine plugged in, empty the capsule container and drip tray and place back onto the machine.

STEP 2

Fill water tank with 17 ounces of water and **1 packet** of Nespresso descaling solution*.
**Avoid solution contact with eyes, skin, and kitchen surfaces.*

STEP 3

Remove the cup support and place an empty container (at least 34 oz) under the coffee outlet. With machine on, close the machine head and leave the lever in the unlocked position.

STEP 4

Press and hold button until you see steady light turn off first, and then start blinking orange quickly. It may take approximately 7 seconds before light starts to blink.

STEP 5

Turn lever to the left to lock the lever, then turn lever back to the front to unlock the lever.

STEP 6

Press and hold the button until the light turns off and then starts blinking orange and quickly again (approx. 7 seconds). **Steps 5 and 6 must be completed within 45 seconds.**

STEP 7

Lock the lever. The light should still be blinking orange quickly. This is an indication that you have entered descaling mode. If not, start over from Step 3.

STEP 8

Press and release button once to begin descaling. Light will continuously blink throughout the process.

STEP 9

Once the solution has finished running through, machine should be silent. Discard the solution and return the empty container underneath the coffee spout.



STEP 10



Empty drip tray and capsule container. Rinse water tank and clean thoroughly. Refill the tank to the top with fresh water and place back on the machine.

STEP 11



Press and release the button to begin the rinsing phase. Water will dispense into container. When machine stops making noise, discard the water from the container.

STEP 12



The machine will stop automatically, and the cup button should become steady on its own.

STEP 13



Refill the water tank and place it back onto the machine.

STEP 14



Empty and rinse the capsule container and drip tray and reinsert.

STEP 15



Replace cup support. Wipe down the machine with a damp cloth. Let the machine rest for 10 minutes. The machine is now ready for use.