

INSIGNIA™

USER GUIDE

10" Steam Iron with Retractable Cord

NS-IR10BL7/NS-IR10PK7



Before using your new product, please read these instructions to prevent any damage.

Contents

- Introduction2
- IMPORTANT SAFETY INSTRUCTIONS2
- Features4
 - Package contents4
 - Main features4
- Using your iron5
 - Using your iron for the first time5
 - Setting the temperature control5
 - Dry ironing6
 - Steam ironing6
 - Spraying the fabric7
 - Using the Burst of Steam7
- Cleaning and maintaining your iron7
 - Using the self-clean function7
 - Cleaning the exterior of your iron8
 - Storing your iron8
- Troubleshooting9
- Specifications10
- ONE-YEAR LIMITED WARRANTY11

Introduction

Congratulations on your purchase of a high-quality Insignia product. Your NS-IR10BL7 or NS-IR10PK7 represents the state of the art in steam iron design and is designed for reliable and trouble-free performance.

IMPORTANT SAFETY INSTRUCTIONS

When using an iron, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING

- 1 Only use an iron for its intended use.
- 2 To avoid the risk of electric shock, do not immerse the iron in water or other liquids.
- 3 Always turn the iron OFF before plugging or unplugging it from the electrical outlet. Never pull on the cord to disconnect the iron from the electrical outlet. Instead, grasp the plug and pull on the plug to disconnect the iron.

- 4 Do not let the cord touch hot surfaces. Let the iron cool completely before putting the iron away. Coil the cord loosely around the iron when storing.
- 5 Always disconnect the iron from the electrical outlet before filling the iron with water, emptying the water from the iron, and when the iron is not in use.
- 6 Do not operate the iron with a damaged cord or if the iron has been dropped or damaged. To avoid the risk of electric shock, do not disassemble the iron. Take it to a qualified serviceman for examination and repair. Incorrect assembly might result in a risk of electric shock when the iron is used after reassembly.
- 7 Close supervision is required if the iron is used by or near children.
- 8 Burns can occur from touching hot metal parts, hot water, or steam. Use caution when you turn a STEAM IRON upside down – there might be hot water in the reservoir.
- 9 To avoid a circuit overload, do not operate an iron on the same circuit with another high wattage appliance.
- 10 The iron must not be left unattended while it is plugged in.
- 11 The water inlet cover must not be opened during use.
- 12 The iron must be used and rested on a stable surface.
- 13 The iron is not to be used if it has been dropped, if there are visible signs of damage, or if it is leaking.
- 14 Never use an extension cord that is not approved by a competent authority. If an extension cord is absolutely necessary, a cord with an ampere rating equal to or greater than 15A shall be used. A cord rated for less amperage may overheat. Care shall be taken to arrange the cord so that it cannot be pulled or the iron tripped over.
- 15 This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 16 If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid a hazard.
- 17 The plug must be removed from the socket-outlet before the water reservoir is filled with water.
- 18 When placing the iron on its stand, ensure that the surface on which the stand is placed is stable.


SAVE THESE INSTRUCTIONS

Features

Package contents

- 10" steam iron with retractable cord
- *User Guide*

Main features



Using your iron

Using your iron for the first time

Some parts of the iron have been slightly greased and, as a result, the iron may smoke slightly when turned on for the first time. This stops after a few uses.

- 1 Remove any protective films or stickers from the sole plate and the body of the iron. Clean the sole plate with a soft cloth.
- 2 Test the iron on an old piece of fabric to make sure that the sole plate and water reservoir are completely clean.

Setting the temperature control

- Always check the garment label for ironing instructions before ironing the garment.
- If the ironing instructions are missing, use the table below to set the temperature.
- Sort your laundry into fabric types (wool with wool, cotton with cotton, and so on), then iron the fabrics requiring the lowest temperature setting first, then progress to fabrics that require higher temperatures (the iron heats up quicker than it cools down).
- If the fabric consists of various kinds of fibers (such as cotton with polyester), always select the ironing temperature for the material with the lowest advised temperature.

Fabric Label	Fabric	Temperature dial	Steam	Burst of Steam	Spray
	Acrylic or Nylon		No	No	Yes
	Silk or wool		No	No	Yes
	Polyester		No	No	Yes
	Cotton or linen		No	No	Yes
	If you see this label on your garment, it means that it cannot be ironed. DO NOT IRON.				

Dry ironing

- 1 Stand the iron upright and plug it in.
- 2 Turn the temperature control dial to the setting you want.
- 3 Set the steam control knob to 0.
- 4 The temperature indicator turns off when the temperature you want is reached. The iron is ready for use.

Steam ironing

The steam feature can only be used at higher ironing temperatures. Use the following settings:



Use for moderate steam

Use for maximum steam

- 1 Open the water inlet cover and fill the iron with water.
- 2 Stand the iron upright and plug it in.
- 3 Turn the temperature control dial to the setting you want.
- 4 The temperature indicator turns off when the temperature you want is reached. The iron is ready for use.
- 5 Turn the steam control to the required position. Steam starts coming from the holes in the sole plate.

Note

With conventional steam ironing, water may leak from the sole plate if you have selected too low a temperature. If this happens, turn the temperature control dial to a higher setting. Steam will be produced as soon as the appropriate temperature has been reached.

Choosing the water

- This iron can be used with normal tap water.
- If the water in your area is particularly hard, use distilled or demineralized water.
- Do not use chemically descaled water or any other liquids.

Filling the iron

- 1 Set the steam control knob to 0 and the temperature control dial to OFF.
- 2 Unplug the iron from the wall outlet and wait for the iron to cool down.
- 3 Pour water into the water inlet up to the MAX level of the water reservoir.

Spraying the fabric

You can use the spray feature at any time to help eliminate wrinkles. It does not affect the temperature of the iron.

- 1 Open the water inlet cover and fill the iron with water.
- 2 Aim the spray nozzle at the garment.
- 3 Press the spray pump.

Using the Burst of Steam

This feature provides an extra amount of steam to help remove stubborn wrinkles.

- 1 Open the water inlet cover and fill the iron with water.
- 2 Stand the iron upright and plug it in.
- 3 Turn the temperature control dial to the maximum setting.
- 4 The temperature indicator turns off when the temperature you want is reached. The iron is ready for use.
- 5 Press the Burst of Steam pump. Steam penetrates the garment and remove stubborn wrinkles.
- 6 Press the Burst of Steam pump a second or third time. Usually, all wrinkles can be removed within three steam bursts. For best results, wait three seconds between each burst.

Cleaning and maintaining your iron

Using the self-clean function

You can use the self-clean function to remove scale and impurities from your iron. The self-clean function should be used approximately once every two weeks. If the water in your area is very hard, the self-clean function should be used more frequently.

- 1 Unplug the iron.
- 2 Set the steam control knob to the "0" position.
- 3 Open the water inlet cover and fill the iron with water.
- 4 Select the maximum ironing temperature.
- 5 Plug in the iron.
- 6 When the temperature indicator turns off, unplug the iron.
- 7 Hold the iron over the sink, then press and hold the self-clean button and gently shake the iron. Steam and boiling water come out of the sole plate and any impurities and flakes are flushed out.
- 8 Release the self-clean button as soon as all water in the reservoir has been drained.

- 9 Repeat the self-clean process if the iron still contains a lot of impurities.

Note

In addition to a self-clean function, your iron features an anti-scale cartridge, which reduces scale deposits in the iron and prolongs its operational life. The anti-scale system is an integral part of your iron and does not require any maintenance.

Cleaning the exterior of your iron

Turn the temperature control dial to OFF, then unplug the iron and let it cool down completely. Deposits and other residues on the sole plate can be removed with a cloth soaked in a vinegar/water solution.

The casing may be wiped with a damp cloth and then polished with a dry one.

Notes

- Never use any abrasives to clean the sole plate.
- Keep the sole plate smooth. Avoid contact with metal objects.

Storing your iron

- 1 Turn the temperature control dial to OFF and set the steam control knob to 0 (no steam).
- 2 Unplug the iron.
- 3 Pour any remaining water out of the water reservoir.
- 4 Stand the iron upright and let it cool down completely.
- 5 Wind the power cord around the iron.
- 6 Always store the iron in an upright position.

Auto shut-off

In the unlikely event that the thermostat fails, the protective cut-out turns of the iron off after 30 seconds (horizontal position) or eight minutes (vertical position) to protect it from overheating. If that occurs, the iron should be taken to the nearest authorized service facility.

Secure cord retraction

Lets you safety retract you power cord without a whipping effect.

- 1 Pull out the length of cord you want before plugging your iron into an electrical outlet. Do not pull cord past the red indicator.
- 2 To retract the cord, hold the iron with one hand and grab the end of the cord with the other hand. Use the cord prongs to press the Retract button. Failure to hold the end of the cord may cause it to whip around.
- 3 If the cord does not fully rewind, pull it out and guide it evenly onto the reel.

Troubleshooting

Caution

Do not try to repair your iron yourself. Doing so invalidates the warranty.

Problem	Possible cause	Possible solution
The iron won't heat	The iron may not be plugged in or the temperature control dial is not set correctly.	Plug in the iron and turn up the temperature control dial. If the temperature indicator does not come on, does a lamp plugged into the same outlet turn on? If it does, there is a problem with the iron. Contact customer service.
Water drips from the holes in the sole plate	The chosen temperature is too low and does not allow the formation of steam.	Increase the temperature setting.
	You are using steam while the iron is not hot enough.	Wait until the temperature indicator turns off.
	You are using the Burst of Steam button too often.	Wait a few seconds between each use of the button.
	There is too much steam selected.	Reduce the steam rate.
Brown streaks come through the sole plate and stain the fabric	You are using chemical descaling agents.	Do not add any descaling agents to the water in the water tank.
	You are not using the right type of water.	Use the self-clean function and refer to "Choosing the water" on page 6.
	Fabric fibers have accumulated in the holes of the sole plate and are burning.	Use the self-clean function and clean the sole plate with a damp sponge. Vacuum the holes of the sole plate from time to time.
	Your fabric has not been rinsed sufficiently or you have ironed a new garment before washing it.	Make sure that your laundry is rinsed sufficiently so as to remove any deposits of soap or chemical products on new clothes.
The sole plate is dirty or brown and can stain the fabric	You are ironing with an inappropriate setting (temperature too high).	Select the appropriate setting.
	You are using starch. Always spray starch onto the reverse side of the fabric.	Clean the sole plate with a non-metallic sponge.
There is little or no steam	The water tank is empty.	Fill it.
	Your iron has a build-up of scale.	Use the self-clean function.
	Your iron has been used dry for too long.	Use the self-clean function.
The sole plate is scratched or damaged	You have placed your iron flat on a metallic rest-plate or ironed over a zipper.	Always set your iron on its heel.

Problem	Possible cause	Possible solution
Steam or water comes out from the iron as you finish filling the tank	The steam control is not set to produce steam.	Make sure that the steam control is set to produce steam.
	The water tank is overfilled.	Never overfill the water tank. Empty out the excess water.
The spray nozzle does not spray	There is not enough water in the water tank.	Fill up the water tank.

Specifications

Dimensions (WxDxH)	6.1 x 12.2 x 4.6 inches (15.5 x 31 x 11.6 cm)
Weight	2.8 lbs. (1.25 kg)
Power	1200 W

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.



ONE-YEAR LIMITED WARRANTY

Definitions:

The Distributor* of Insignia branded products warrants to you, the original purchaser of this new Insignia-branded product ("Product"), that the Product shall be free of defects in the original manufacturer of the material or workmanship for a period of one (1) year from the date of your purchase of the Product ("Warranty Period").

For this warranty to apply, your Product must be purchased in the United States or Canada from a Best Buy branded retail store or online at www.bestbuy.com or www.bestbuy.ca, and is packaged with this warranty statement.

How long does the coverage last?

The Warranty Period lasts for 1 year (365 days) from the date you purchased the Product. Your purchase date is printed on the receipt you received with the Product.

What does this warranty cover?

During the Warranty Period, if the original manufacture of the material or workmanship of the Product is determined to be defective by an authorized Insignia repair center or store personnel, Insignia will (at its sole option): (1) repair the Product with new or rebuilt parts; or (2) replace the Product at no charge with new or rebuilt comparable products or parts. Products and parts replaced under this warranty become the property of Insignia and are not returned to you. If service of Products or parts are required after the Warranty Period expires, you must pay all labor and parts charges. This warranty lasts as long as you own your Insignia Product during the Warranty Period. Warranty coverage terminates if you sell or otherwise transfer the Product.

How to obtain warranty service?

If you purchased the Product at a Best Buy retail store location, please take your original receipt and the Product to any Best Buy store. Make sure that you place the Product in its original packaging or packaging that provides the same amount of protection as the original packaging. If you purchased the Product from a Best Buy online web site (www.bestbuy.com or www.bestbuy.ca), mail your original receipt and the Product to the address listed on the web site. Make sure that you put the Product in its original packaging or packaging that provides the same amount of protection as the original packaging.

To obtain warranty service, in the United States call 1-888-BESTBUY, Canada call 1-866-BESTBUY. Call agents may diagnose and correct the issue over the phone.

Where is the warranty valid?

This warranty is valid only in the United States and Canada at Best Buy branded retail stores or websites to the original purchaser of the product in the county where the original purchase was made.

What does the warranty not cover?

This warranty does not cover:

- Food loss/spoilage due to failure of refrigerator or freezer
- Customer instruction/education
- Installation
- Set up adjustments
- Cosmetic damage
- Damage due to weather, lightning, and other acts of God, such as power surges
- Accidental damage
- Misuse
- Abuse
- Negligence

- Commercial purposes/use, including but not limited to use in a place of business or in communal areas of a multiple dwelling condominium or apartment complex, or otherwise used in a place of other than a private home.
- Modification of any part of the Product, including the antenna
- Display panel damaged by static (non-moving) images applied for lengthy periods (burn-in).
- Damage due to incorrect operation or maintenance
- Connection to an incorrect voltage or power supply
- Attempted repair by any person not authorized by Insignia to service the Product
- Products sold "as is" or "with all faults"
- Consumables, including but not limited to batteries (i.e. AA, AAA, C etc.)
- Products where the factory applied serial number has been altered or removed
- Loss or Theft of this product or any part of the product
- Display panels containing up to three (3) pixel failures (dots that are dark or incorrectly illuminated) grouped in an area smaller than one tenth (1/10) of the display size or up to five (5) pixel failures throughout the display. (Pixel based displays may contain a limited number of pixels that may not function normally.)
- Failures or Damage caused by any contact including but not limited to liquids, gels or pastes.

REPAIR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS YOUR EXCLUSIVE REMEDY FOR BREACH OF WARRANTY. INSIGNIA SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR THE BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, INCLUDING, BUT NOT LIMITED TO, LOST DATA, LOSS OF USE OF YOUR PRODUCT, LOST BUSINESS OR LOST PROFITS. INSIGNIA PRODUCTS MAKES NO OTHER EXPRESS WARRANTIES WITH RESPECT TO THE PRODUCT, ALL EXPRESS AND IMPLIED WARRANTIES FOR THE PRODUCT, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF AND CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE WARRANTY PERIOD SET FORTH ABOVE AND NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THE WARRANTY PERIOD. SOME STATES, PROVINCES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE.

Contact Insignia:

For customer service please call 1-877-467-4289

www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies.

Distributed by Best Buy Purchasing, LLC

©2016 Best Buy. All rights reserved.

Made in China

INSIGNIA™

www.insigniaproducts.com

1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)

INSIGNIA is a trademark of Best Buy and its affiliated companies.

Distributed by Best Buy Purchasing, LLC

©2016 Best Buy. All rights reserved.

Made in China.

V2 ENGLISH
16-0214