

INSIGNIA™

USER GUIDE

Ice Maker

NS-ICEF2W2



Before using your new product, please read these instructions to prevent any damage.

Contents

Introduction	2
IMPORTANT SAFETY INSTRUCTIONS	3
Features	4
Package contents	4
Tools and materials needed	5
Installing the ice maker	5
Installing the ice maker in a top mount freezer	5
Installing the ice maker in a bottom mount freezer	13
Connecting the ice maker to the water supply	19
Tips for using your ice maker	21
Maintaining your ice maker	21
Troubleshooting	22
Specifications	23
ONE-YEAR LIMITED WARRANTY	24

Introduction

Congratulations on your purchase of a high-quality Insignia product. Your NS-ICEF2W2 represents the state of the art in ice maker design and is designed for reliable and trouble-free performance.

IMPORTANT SAFETY INSTRUCTIONS



This symbol indicates that dangerous voltage constituting a risk of electric shock is present within your refrigerator.



This symbol indicates that there are important operating and maintenance instructions in the literature accompanying your refrigerator.

WARNING

- 1 Read these instructions.
- 2 Keep these instructions.
- 3 Heed all warnings.
- 4 Follow all instructions.
- 5 Do not place fingers or hands into the automatic ice making mechanism while the refrigerator is plugged in. Doing so may expose you to possible injury.
- 6 Keep your hands away from the ejector mechanism and the heating element that releases the ice cubes, located on the bottom of the ice maker.
- 7 Refer all servicing to qualified service personnel. Servicing is required when the appliance has been damaged in any way, such as the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the appliance, the appliance has been exposed to rain or moisture, does not operate normally, or has been dropped.



WARNING

Electric Shock Hazard

Failure to follow these instructions can result in electric shock, fire, or death.


- 1 **WARNING**—Do not touch the interior of the freezer compartment with wet hands. This could result in frost bite.
- 2 **WARNING**—Do not use electrical appliances inside the food storage compartment of the refrigerator, unless they are of the type recommended by the manufacturer.

- 3 Unplug the refrigerator before performing user maintenance on it.
- 4 This appliance can be used by children age eight years and older and persons with reduced physical or mental capabilities or lack of experience and knowledge if they are given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children should not play with the appliance. Cleaning and maintenance should not be performed by children without supervision.
- 5 If a component part is damaged, it must be replaced by the manufacturer, its service agent, or similar qualified persons in order to avoid a hazard.
- 6 **WARNING:** Connect this refrigerator to a potable water supply only.
- 7 To eliminate the danger of electric shock during installation, you must unplug the refrigerator.
- 8 The minimum inlet water pressure should be no lower than 138 kPa (20 PSIG). The maximum should be no higher than 827 kPa (120 PSIG).

Features

- Stores up to 5.5 pounds of ice
- Makes up to 2.5 pounds of ice daily so you always have ice on hand
- Prevents overfilling with auto shut-off
- Works with these Insignia refrigerators: NS-RTM14SS5, NS-RTM14SS5-C, NS-RTM14WH5, NS-RTM14WH5-C, NS-RBM18SS0, NS-RBM18SS0-C, NS-RTM18SS2, NS-RTM18WH2, NS-RTM18BK2L, NS-RTM18SS2L, NS-RTM18BK2, NS-RTM18WHD2, NS-RBM18WH0-C, and NS-RTM20SS3


Package contents




Ice maker unit



Ice storage bin



Water valve



Plastic water supply tubing



Mounting box



Box cover



Tube clamp



Leveling bracket screw



Ice maker mounting screws (3)



Self-tapping screws (3)

Top Mount Freezer only



Plastic clamp (3)



Water inlet tube

Bottom Mount Freezer only



Water pipe joint



Sealed silica gel block



Connecting plate


Tools and materials needed



Electric drill with a
1/4" drill bit



Putty knife




Needle nose pliers or
nut driver



Adjustable wrench



Knife



Flat blade
screwdriver



1/4" OD copper supply
line with compression
nuts and ferrules



Shut off valve (non
self piercing)



Phillips
screwdriver



Water line kit
#5303917950

You'll also need:

- A freezer shelf to hold the ice storage bin. If your model does not have one, contact your dealer to order one.
- Access to a household cold water line with water pressure between 20 and 120 psi.

The water line kit (including copper tubing and shut off valve) are available in a kit (#5303917950) from your local hardware or plumbing supply store.

Installing the ice maker


Your Insignia refrigerator comes set up for ice maker installation.

CAUTION: To eliminate the danger of electric shock during installation, you must first unplug the refrigerator.


Installing the ice maker in a top mount freezer

- 1 Unplug the refrigerator from the wall outlet.
- 2 Remove the freezer shelf and ice tray rack from the freezer.


- 3** Remove the plug from the inside of the freezer compartment with a putty knife.



- 4** Peel off the label covering the ice maker hole on the back of the refrigerator, then remove the foam from the hole with the needle nose pliers. Retain the foam for future use.




- 5 Push the water inlet tube into the small hole on back of refrigerator. Rotate while inserting the tube until the flat surface of inlet tube is tight against the back of the refrigerator.




- 6 Secure the water inlet tube to the back of the refrigerator with two self-drilling screws (provided).
- 7 Squeeze together and slide the tube clamp over the fill tube. While still squeezing the clamp, insert one end of the plastic tube into the fill tube as far as it will go, then slide the clamp downward to capture the fill tube in place.


CAUTION: Leaks may result if the plastic tube is not pushed in as far as it can go and the tube clamp is not in place over the fill tube.




- 8 Insert the two ice maker mounting screws into the holes in the freezer wall. Turn each screw clockwise five times.




- 9 Use needle nose pliers to remove the terminal cover located at the top of the freezer by first pulling down one side of the cover, then pulling down the other side. Save the terminal cover for future use in case the ice maker is removed.




- 10** With the ice maker in one hand, plug the wiring harness connector into the terminal located at the top of the freezer panel. Make sure that the connection is tight. Make sure that the wiring harness is still in the hook on the back of ice maker.




- 11** Mount the ice maker onto the two ice maker mounting screws you installed in step 8. Make sure that the water inlet tube is sitting inside the fill cup, then tighten the screws.




- 12** Adjust the leveling bracket to level the ice maker. The ice maker is level when the gap between the freezer wall and the ice maker is the same at the top and bottom.




- 13** With the ice maker level, insert the third ice maker mounting screw at the bottom of the ice maker and tighten.
- 14** Reinstall the freezer shelf and set the ice storage bin on the shelf.




- 15** Locate the pre-punched holes at the bottom right corner of the back panel of the refrigerator. Align the water valve bracket with the factory drilled holes, then use a Phillips head screwdriver to drive the two self-drilling screws through the bracket and into the cabinet.




- 16** Connect the wiring harness to the water valve, making sure that the connection is tight, then install the mounting box and box cover on the plug.



- 17 Grasp the other end of the plastic tube and push it firmly into the quick-connection on the valve until it bottoms out.




- 18 Clean the back of the cabinet with a commercial household cleaner, ammonia, or alcohol before applying the clamps.
- 19 Secure the plastic water supply tubing to the back of the cabinet with three plastic clamps.




Installing the ice maker in a bottom mount freezer


- 1 Unplug the refrigerator from the wall outlet.
- 2 Remove the drawers from the freezer compartment.
- 3 Remove the small screws on both sides of the guide rail of the freezer compartment door, then remove the freezer compartment door, with the guide rail support, from the guide rail.




- 4 Remove the ice maker unit and the connection plate from the accessories bag, then insert the connection plate into the ice maker unit (as shown below) by aligning the connection plate with the notch in the ice maker unit.




- Remove the terminal cover from the upper left corner of the freezer compartment, then remove the ice maker mounting screws from the accessory bag and attach them loosely to the two mounting holes in the back of the freezer compartment.




- Insert the power connector of the ice maker into the socket in the freezer compartment, then loosely mount the ice maker onto the ice maker mounting screws.
- Move the ice maker to the left as far as it will go, then align it vertically and tighten the ice maker mounting screws.




- 8 Reinstall the freezer door guide rail and replace the freezer drawers, then place the ice storage bin in the top freezer drawer.




- 9 Peel the label off the water hole on the back of your refrigerator.



- 10** Use needle nose pliers to remove the thermal insulation foam strip from the hole you just exposed.




- 11** Remove the water tube connector, silicone seal, long water supply tube, and white head screw from the accessory bag, then assemble the parts by aligning the notch on the silicone seal with the notch on the water tube connector, inserting one end of the water supply tube into the quick change sealing ring at the bottom of the connector. Make sure that all parts are securely assembled.




- 12** Insert the water supply assembly into the water inlet hole on the back of your refrigerator, and secure it with the long screw from the accessory bag.


- 13** Locate the pre-punched holes at the bottom right corner of the back panel of the refrigerator. Align the water valve bracket with the factory drilled holes, then use a Phillips head screwdriver to drive the two self-drilling screws through the bracket and into the cabinet.




- 14** Connect the wiring harness to the water valve, making sure that the connection is tight, then install the mounting box and box cover on the plug.



- 15 Grasp the other end of the plastic tube and push it firmly into the quick-connection on the valve until it bottoms out.



- 16 Secure the plastic water supply tubing to the back of the cabinet with three plastic clamps.



Connecting the ice maker to the water supply

Before you begin, please note:

- This water line installation is not warranted by the refrigerator or ice maker manufacturer.
- Follow these instructions carefully to minimize the risk of water damage.
- Water hammer (water banging in the pipe) in house plumbing can cause damage to refrigerator parts and lead to water leakage or flooding. Call a qualified plumber to correct water hammer before installing the water supply line to the refrigerator.
- To prevent burns and product damage, do not hook up the water line to the hot water line.
- If you use your refrigerator before connecting the water line, make sure that the ice maker wire signal arm is in the OFF position.
- Do not install the ice maker tubing in areas where temperature falls below freezing.
- When using any electrical devices (such as a power drill) during installation, be sure the device is double insulated or grounded in a manner to prevent the hazard of electric shock, or the device is battery powered.
- All installations must be in accordance with local plumbing code requirements.

WARNINGS:

- The ice maker should be installed by an authorized service technician.
- Make sure that the refrigerator is unplugged to eliminate the danger of electric shock during installation.

- 1 Disconnect the refrigerator from the electric wall outlet.
- 2 Remove the parts in the water line kit that you purchased for this purpose.
- 3 Connect the end of the water supply line to the household cold water line behind the refrigerator. Choose a location for the valve that is easy to access. We recommend that you connect it to the side of a vertical water pipe. If it is necessary to connect it to a horizontal water pipe, make the connection to the top or side, rather than at the bottom, to avoid drawing off any sediment from the water pipe.
- 4 Make sure that the household water supply is turned off, then drill a ¼" hole in the water pipe (even if using a self-piercing valve), using a sharp bit. Remove any burrs resulting from drilling the hole. Take care not to allow water to drain into the drill. Failure to drill a ¼" hole may result in reduced ice production or smaller cubes.
- 5 Fasten the shutoff valve to the cold water pipe with the pipe clamp, then tighten the pipe clamp screws until the sealing washer begins to swell. Do not over-tighten or you may crush the tubing.
- 6 Route the tubing through a hole drilled in the wall or floor (behind the refrigerator or adjacent base cabinet) as close to the wall as possible.

Note: Make sure that there is sufficient extra tubing to allow the refrigerator to move out from the wall after installation.


- 7 Connect the tubing to the valve by placing the compression nut and ferrules (sleeves) for copper tubing onto the end of the tubing and connect it to the shutoff valve. Make sure that the tubing is fully inserted into the valve.

- 8 Tighten the compression nut securely. For plastic tubing, insert the molded end of the tubing into the valve and tighten the compression nut until it is hand-tight, then tighten one additional turn with a wrench. Over-tightening may cause leaks.
- 9 Place the end of the water supply line into a sink or bucket and flush the water supply line with water until the water runs clear.


Notes:

- Before making the connection to the refrigerator, be sure the refrigerator power cord is not plugged into the wall outlet.
- If your refrigerator does not have a water filter, we recommend installing one if your water supply has sand or particles that could clog the screen of the refrigerator's water valve.

- 10 Unscrew the plastic cap from the water inlet valve and discard it.



- 11 Slide a brass compression nut, then a ferrule (sleeve), onto the water supply line.



- 12 Push the end of the tubing into the water inlet valve as far as it will go or 1/4-inch, then slide the ferrule (sleeve) into the valve inlet and finger tighten the compression nut onto the valve. Tighten another half turn with a wrench. DO NOT overtighten.
- 13 Secure the water supply line to the back panel of your refrigerator with a steel clamp and screw at the location shown on the illustration.
- 14 Coil the excess water supply line (about 2-1/2 turns) behind the refrigerator and arrange the coils so they do not vibrate or wear against any other surface.
- 15 Turn on the water supply at the shutoff valve and tighten any connections that leak.

16 Reconnect the refrigerator to the electric wall outlet.


17 To turn on the ice maker, lower the wire signal arm.

Important: It takes approximately 24 hours for the ice maker to begin producing usable ice. Air in new plumbing lines may cause the ice maker to cycle two or three times before making a full tray of ice. New plumbing may cause ice to be discolored or have poor flavor. Discard ice made during the first 24 hours.

Tips for using your ice maker

Remember that water quality determines the quality of ice. The ice maker should not be connected to softened water. If the water softener has problems, chemical substances can damage the ice maker.

To turn off the ice maker, raise the wire signal arm until it locks in the “up” off position. When the ice storage bin is full, the wire signal arm will hit the ice cubes and the ice maker will automatically shut down.



If you store ice cubes too long they may produce a peculiar smell. To eliminate the smell, empty the ice storage bin, wash it out, then replace it. The ice maker will produce more ice cubes.

Shake the ice storage bin from time to time to ensure that the ice cubes separate from each other.

Before the refrigerator is connected to the water supply system, or any time the water supply is turned off, the wire signal arm should be in the “up” or closed position.

Maintaining your ice maker

Use mild detergent in warm water to clean the ice storage box, then rinse and dry it.

Turn off the ice maker when you clean your refrigerator or plan to be away for a short period.

If you are going away for an extended period, turn off the water supply valve.

Troubleshooting

CAUTION: Do not try to repair your ice maker yourself. Doing so invalidates the warranty.

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
The ice maker makes no ice	The freezer temperature is too high.	Make sure that the freezer temperature is low enough to make ice.
	There may be something mechanically wrong with the ice maker.	Test or have tested the following: <ul style="list-style-type: none"> • The ejector gear • The ejector motor • The ice mold heater • The holding switch • The water inlet switch • The thermostat • The water inlet valve
The ice maker is not working	The ice maker is not plugged in correctly.	Make sure that the ice maker connector plug is fully inserted into the socket.
The ice tray is not filling	The fill tube is not correctly seated in the fill cup.	Make sure that the fill tube is correctly inserted into the fill cup opening.
	The water supply valve is turned off.	Make sure that the water supply valve is turned on. Inspect the water supply line for problems.
The ice smells funny	The ice storage bin needs cleaning.	Empty and wash the ice storage bin and discard the old ice cubes.
The ice maker buzzes	Normal	The ice maker water valve buzzes when the ice maker fills with water.
The ice maker makes too much ice or will not shut off	The wire signal arm is jammed in the wrong position.	Make sure that the ice maker wire signal arm is not jammed and free it if it is.
	The shutoff switch is broken.	Call an appliance technician and have the switch tested.
The ice cubes will not eject	There may be something mechanically wrong with the ice maker.	Test or have tested the following: <ul style="list-style-type: none"> • The ejector gear • The ejector motor • The ice mold heater • The holding switch • The thermostat

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
The ice smells funny or tastes bad	The ice storage bin or freezer needs cleaning.	Empty and wash the ice storage bin and discard the old ice cubes. Wash the interior of the freezer. Remove any old food.
	The water inlet filter (if you are using one) needs to be replaced.	Replace the water inlet filter.
	There may be impurities in the water supply line.	Flush out the water supply line.
The ice is discolored	There may be impurities in the water supply line or the ice mold tray.	Flush out the water supply line and clean the ice mold tray. Install a water supply line filter if your refrigerator doesn't have one.

Specifications

Ice Maker Dimensions (H×W×D)	4.4 × 5.4 × 12.2 in. (11.3 × 13.8 × 31.1 cm)
Ice Storage Bin Dimensions (H×W×D)	6.2 × 10 × 14.3 in. (15.7 × 25.3 × 36.3 cm)
Weight	4.6 lbs. (2.1 kg)
Power requirements	115V AC at 60Hz
Power	6W

ONE-YEAR LIMITED WARRANTY

Definitions:

The Distributor* of Insignia branded products warrants to you, the original purchaser of this new Insignia-branded product ("Product"), that the Product shall be free of defects in the original manufacturer of the material or workmanship for a period of one (1) year from the date of your purchase of the Product ("Warranty Period").

For this warranty to apply, your Product must be purchased in the United States or Canada from a Best Buy branded retail store or online at www.bestbuy.com or www.bestbuy.ca and is packaged with this warranty statement.

How long does the coverage last?

The Warranty Period lasts for 1 year (365 days) from the date you purchased the Product. Your purchase date is printed on the receipt you received with the Product.

What does this warranty cover?

During the Warranty Period, if the original manufacture of the material or workmanship of the Product is determined to be defective by an authorized Insignia repair center or store personnel, Insignia will (at its sole option): (1) repair the Product with new or rebuilt parts; or (2) replace the Product at no charge with new or rebuilt comparable products or parts. Products and parts replaced under this warranty become the property of Insignia and are not returned to you. If service of Products or parts are required after the Warranty Period expires, you must pay all labor and parts charges. This warranty lasts as long as you own your Insignia Product during the Warranty Period. Warranty coverage terminates if you sell or otherwise transfer the Product.

How to obtain warranty service?

If you purchased the Product at a Best Buy retail store location or from a Best Buy online website (www.bestbuy.com or www.bestbuy.ca), please take your original receipt and the Product to any Best Buy store. Make sure that you place the Product in its original packaging or packaging that provides the same amount of protection as the original packaging.

To obtain warranty service, in the United States and Canada call 1-877-467-4289. Call agents may diagnose and correct the issue over the phone.

Where is the warranty valid?

This warranty is valid only in the United States and Canada at Best Buy branded retail stores or websites to the original purchaser of the product in the country where the original purchase was made.

What does the warranty not cover?

This warranty does not cover:

- Food, beverage, and/or medicine loss/spoilage
- Customer instruction/education
- Installation
- Set up adjustments
- Cosmetic damage
- Damage due to weather, lightning, and other acts of God, such as power surges
- Accidental damage
- Misuse
- Abuse
- Negligence
- Commercial purposes/use, including but not limited to use in a place of business or in communal areas of a multiple dwelling condominium or apartment complex, or otherwise used in a place of other than a private home.
- Modification of any part of the Product, including the antenna
- Display panel damaged by static (non-moving) images applied for lengthy periods (burn-in).

- Damage due to incorrect operation or maintenance
- Connection to an incorrect voltage or power supply
- Attempted repair by any person not authorized by Insignia to service the Product
- Products sold “as is” or “with all faults”
- Consumables, including but not limited to batteries (i.e. AA, AAA, C etc.)
- Products where the factory applied serial number has been altered or removed
- Loss or Theft of this product or any part of the product
- Display panels containing up to three (3) pixel failures (dots that are dark or incorrectly illuminated) grouped in an area smaller than one tenth (1/10) of the display size or up to five (5) pixel failures throughout the display. (Pixel based displays may contain a limited number of pixels that may not function normally.)
- Failures or Damage caused by any contact including but not limited to liquids, gels or pastes.

REPAIR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS YOUR EXCLUSIVE REMEDY FOR BREACH OF WARRANTY. INSIGNIA SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR THE BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, INCLUDING, BUT NOT LIMITED TO, LOST DATA, LOSS OF USE OF YOUR PRODUCT, LOST BUSINESS OR LOST PROFITS. INSIGNIA PRODUCTS MAKES NO OTHER EXPRESS WARRANTIES WITH RESPECT TO THE PRODUCT, ALL EXPRESS AND IMPLIED WARRANTIES FOR THE PRODUCT, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF AND CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE WARRANTY PERIOD SET FORTH ABOVE AND NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THE WARRANTY PERIOD. SOME STATES, PROVINCES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE.

Contact Insignia:

1-877-467-4289

www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies.

*Distributed by Best Buy Purchasing, LLC

7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2024 Best Buy. All rights reserved.

INSIGNIA™

www.insigniaproducts.com

1-877-467-4289 (U.S. and Canada)

INSIGNIA is a trademark of Best Buy and its affiliated companies.

Distributed by Best Buy Purchasing, LLC

7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2024 Best Buy. All rights reserved.

V5 ENGLISH
24-0528