












Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first. Replacements for missing or damaged parts will be shipped ASAP!

US office: Fontana **UK** office: Ipswich **AU** office: Truganina

DE office: Hamburg **FR** office: Saint Vigor d'Ymonville **PL** office: Gdańsk





Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.



US:cs.us@costway.com UK:cs.uk@costway.com AU:cs.au@costway.com

USER'S MANUAL

Squat Machine FH10024







Before You Start

- ⚠ Please read all instructions carefully.
- Retain instructions for future reference.
- \triangle Separate and count all parts and hardware.
- riangle Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- Always place the product on a flat, steady and stable surface.
- Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

Product Display





• Parts List



02

• Installation Steps





Step 1: Assemble the Bracket Plate

- 1. Load the foot pads ⑥ into the main frame ①.
- 2. Install the bracket plate ② into the main frame ①, fix it to the appropriate hole position with the elastic pull pin ⑤, and tighten and lock it.

Step 2: Assemble Foam Foot Pads and Pipe Plugs

- 1. Tighten the elastic pull pin ⑤ to fix it to the correct hole position and lock.
- 2. Insert foam foot pads 3 into the hook tube on the main frame 1, and then install pipe plugs 4 to the hook tube on the main frame 1.

04