

A large, light gray curved line that starts from the left side of the page, curves upwards and then downwards, ending on the right side, framing the text.

Hisense

USE AND INSTALLATION MANUAL

Model: AHLW1225TW1W

**For questions about features, operation / performance,
parts or service, call: 1-877-465-3566**

**Operating hours (EST):
Monday - Friday from 9 a.m. to 9 p.m.
Saturday - Sunday from 9 a.m. to 6 p.m.**

Language: English and Spanish

Table of Contents

Safety Information	3
Pre-Installation	8
Installation	14
Operation	17
Care and Cleaning	24
Troubleshooting	25

Safety Information

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



DANGER: This symbol alerts you to a potential hazard, that if not avoided, will result in death or serious injury.



CAUTION: This symbol alerts you to a potential hazard, that if not avoided, may result in minor or moderate injury.



WARNING: This symbol alerts you to a potential hazard, that if not avoided, could result in death or serious injury.







WARNING: Risk of Fire or Explosion. This unit contains flammable refrigerant.

Additional safety precautions must be followed.

- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn refrigerant tubing. Be aware that refrigerants may not contain an odor.
- Compliance with national gas regulations shall be observed.
- Keep ventilation openings clear of obstruction. The maximum refrigerant charge amount is shown on nameplate on the air conditioner.
- When handling, installing, and operating the appliance, care should be taken to avoid damage to the refrigerant tubing.
- The maximum refrigerant charge amount is shown on nameplate on the air conditioner.
- Do not drill holes in the unit.
- Maintenance, cleaning, and service should only be performed by technicians properly trained and qualified in the use of flammable refrigerants.
- Dispose of air conditioner in accordance with Federal and Local Regulations. Flammable refrigerants require special disposal procedures. Contact your local authorities for the environmentally safe disposal of your air conditioner.
- The appliance shall be stored so as to prevent mechanical damage from occurring.
- The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.
- This product contains small parts such as (batteries, battery cover and screws) that may cause suffocation if swallowed by children.
- Do not place items on the air conditioner or bracket.
- Do not play with the air conditioner or bracket, especially for children.
- Do not drink water discharged from the air conditioner, it may contain mold and bacteria that can lead to death if ingested.
- When the air filter is to be removed, do not touch the metal parts of the unit, it may cause injury.

Explanation of symbols displayed on the unit.

	WARNING	This symbol shows that this appliance uses a flammable refrigerant. If the refrigerant is leaked and exposed to an external ignition source, there is a risk of fire.
	CAUTION	This symbol shows that the operation manual should be read carefully.
	CAUTION	This symbol shows that a service personnel should be handling this equipment with reference to the installation manual.
	CAUTION	This symbol shows that information is available such as the operating manual or installation manual.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electrical shock or injury when using your air conditioner, follow these basic precautions:

1. Plug into a grounded 3-prong outlet.
2. Do not remove ground prong.
3. Do not use an adapter.
4. Do not use an extension cord.
5. Unplug air conditioner before servicing.
6. Use two or more people to move and install air conditioner.
7. If the SUPPLY CORD is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Safety Information (continued)

DISPOSING OF THE UNIT

1. Before throwing out the device, it is necessary to remove the battery cells and dispose or recycle them properly.
2. When you need disposal of the unit consult our dealer. If pipes are removed incorrectly, refrigerant may blow out and come into contact with your skin, causing injury. Releasing refrigerant into the atmosphere also damages the environments.
3. Please recycle or dispose of the product packaging material in an environmentally responsible manner.
4. Never store or ship the air conditioner upside down or sideways to avoid damage to the compressor.
5. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
6. The wiring diagram is shown on nameplate on the air conditioner.

Precautions for using R32 refrigerant

The basic installation work procedures are the same as the conventional refrigerant (R22 or R410A). However, pay attention to the following :

1. Transport of equipment containing flammable refrigerants

- Compliance with the transport regulations.

2. Marking of equipment using signs

- Compliance with local regulations.

3. Disposal of equipment using flammable refrigerants

- Compliance with national regulations.

4. Storage of equipment/appliances

- The storage of equipment should be in accordance with the manufacturer.

5. Storage of packed (unsold) equipment

- Storage package protection should be constructed such that mechanical damage to the equipment inside the package will not cause a leak of the refrigerant charge.
- The maximum number of pieces of equipment permitted to be stored together will be determined by local regulations.

6. Information on servicing

- **Checks to the area:** Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimized. For repair to the refrigerating system, the following precautions shall be complied with prior to conducting work on the system.
- **Work procedure:** Work shall be undertaken under a controlled procedure so as to minimize the risk of flammable gas or vapor being present while the work is being performed.
- **General work area:** All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided. The area around the workspace shall be sectioned off. Ensure that the conditions within the area have been made safe by control of flammable material.
- **Checking for presence of refrigerant:** The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially flammable atmospheres. Ensure that the leak detection equipment being used is for use with flammable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe.
- **Presence of fire extinguisher:** If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO₂ fire extinguisher adjacent to the charging area.
- **No ignition sources:** No person carrying out work in relation to a refrigeration system which involves exposing any pipe work that contains or has contained flammable refrigerant shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which flammable refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.
- **Ventilated area:** Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

Safety Information (continued)

- **Checks to the refrigeration equipment:** Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt consult the manufacturer's technical department for assistance. The following checks shall be applied to installations using flammable refrigerants: The charge size is in accordance with the room size within which the refrigerant containing parts are installed; The ventilation machinery and outlets are operating adequately and are not obstructed; If an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant; Marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected; Refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.
- **Checks to electrical devices:** Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised. Initial safety checks shall include: That capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking; That there no live electrical components and wiring are exposed while charging, recovering or purging the system; That there is continuity of earth bonding.

7. Repairs to sealed components

- During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc.
- If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.
- Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected.
- This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, in correct fitting of glands, etc.
- Ensure that apparatus is mounted securely.
- Ensure that seals or sealing materials have not degraded such that they no longer serve the purpose of preventing the ingress of flammable atmospheres.
- Replacement parts shall be in accordance with the manufacturer's specifications.



NOTE: The use of silicon sealant may inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.

8. Repairs to intrinsically safe components

- Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.
- Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating.
- Replace components only with parts specified by the manufacturer. Other parts may result in the ignition of refrigerant in the atmosphere from a leak.

9. Cabling

- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects.
- The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

10. Detection of flammable refrigerants

- Under no circumstances shall potential sources of ignition be used in these arching for or detection of refrigerant leaks.
- A halide torch (or any other detector using a naked flame) shall not be used.

11. Leak detection methods

- The following leak detection methods are deemed acceptable for systems containing flammable refrigerants:
 - Electronic leak detectors shall be used to detect flammable refrigerants, but the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.)

Safety Information (continued)

- Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used.
- Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed and the appropriate percentage of gas (25 % maximum) is confirmed.
- Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.
- If a leak is suspected, all naked flames shall be removed/extinguished.
- If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shutoff valves) in a part of the system remote from the leak.
- Oxygen free nitrogen (OFN) shall then be purged through the system both before and during the brazing process.

12. Removal and evacuation

- When breaking into the refrigerant circuit to make repairs - or for any other purpose - conventional procedures shall be used. However for flammable refrigerants it is important that best practice be followed, since flammability is a consideration. The following procedure shall be adhered to:
 - a) safely remove refrigerant following local and national regulations;
 - b) purge the circuit with inert gas;
 - c) evacuate (optional for A2L);
 - d) purge with inert gas (optional for A2L);
 - e) open the circuit by cutting or brazing;
- The refrigerant charge shall be recovered into the correct recovery cylinders if venting is not allowed by local and national codes. For appliances containing flammable refrigerants, the system shall be purged with oxygen - free nitrogen to render the appliance safe for flammable refrigerants. This process might need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems.
- For appliances containing flammable refrigerants, refrigerants purging shall be achieved by breaking the vacuum in the system with oxygen - free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum (optional for A2L). This process shall be repeated until no refrigerant is within the system (optional for A2L). When the final oxygen - free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.
- Ensure that the outlet for the vacuum pump is not close to any potential ignition sources and that ventilation is available.

13. Charging procedures

- In addition to conventional charging procedures, the following requirements shall be followed:
 - Ensure that contamination of different refrigerants does not occur when using charging equipment.
 - Hoses or lines shall be as short as possible to minimise the amount of refrigerant contained in them.
 - Cylinders shall be kept up right.
 - Ensure that the refrigeration system is earthed prior to charging the system with refrigerant.
 - Label the system when charging is complete (if not already).
 - Extreme care shall be taken not to overfill the refrigeration system.
- Prior to recharging the system it shall be pressure tested with OFN.
- The system shall be leak tested on completion of charging but prior to commissioning.

14. Decommissioning

- Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail.
- It is recommended good practice that all refrigerants are recovered safely.
- Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of reclaimed refrigerant. It is essential that electrical power is available before the task is commenced.
 - a) Become familiar with the equipment and its operation.
 - b) Isolate system electrically.
 - c) Before attempting the procedure ensure that:
 - Mechanical handling equipment is available, if required, for handling refrigerant cylinders;
 - All personal protective equipment is available and being used correctly;
 - The recovery process is supervised at all times by a competent person;
 - Recovery equipment and cylinders conform to the appropriate standards.

Safety Information (continued)

- d) Pump down refrigerant system, if possible.
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f) Make sure that cylinder is situated on the scales before recovery takes place.
- g) Start the recovery machine and operate in accordance with manufacturer.
- h) Do not overfill cylinders. (No more than 80 % volume liquid charge).
- i) Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

15. Labelling

- Equipment shall be labelled stating that it has been decommissioned and emptied of refrigerant.
- The label shall be dated and signed. Ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

16. Recovery

- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed.
- Ensure that the correct number of cylinders for holding the total system charge is available.
- All cylinders to be used are designated for the recovered refrigerant and labeled for that refrigerant (i.e. special cylinders for the recovery of refrigerant).
- Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order.
- Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of flammable refrigerants.
- In addition, a set of calibrated weighing scales shall be available and in good working order.
- Hoses shall be complete with leak-free disconnect couplings and in good condition.
- Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release.
- Consult manufacturer if in doubt. Opening of the refrigeration systems shall not be done by brazing.
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste Transfer Note arranged.
- Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant.
- The evacuation process shall be carried out prior to returning the compressor to the suppliers.
- Only electric heating to the compressor body shall be employed to accelerate this process.
- When oil is drained from a system, it shall be carried out safely.

Pre-Installation

ELECTRICAL REQUIREMENTS

**DANGER: ELECTRICAL SHOCK HAZARD**

1. Plug into a grounded 3-prong outlet.
2. Do not remove ground prong.
3. Do not use an adapter.
4. Do not use an extension cord.
5. Failure to follow these instructions can result in death, fire, or electrical shock.



RECOMMENDED GROUNDING METHOD

This air conditioner must be grounded. This air conditioner is equipped with a power supply cord with a three-prong grounding plug. The cord must be plugged into a three-prong outlet, grounded in accordance with all local codes and ordinances. If a grounded outlet is not available, it is the customer's responsibility to have a properly grounded three-prong outlet installed by a qualified electrical installer.

It is the customer's responsibility:

1. To contact a qualified electrical installer.
2. To assure that the electrical installation is adequate and conforms to the Nation Electrical Code, ANSI/NFPA 70-last edition, and all local codes and ordinances.

Copies of the standards listed may be obtained from:

National Fire Protection Association

1 Batterymarch Park

Quincy, Massachusetts U.S.

02169-7471


www.nfpa.org

WIRING REQUIREMENT

Power supply	Model	Time-delay fuse (or circuit breaker)
115V 103.5V min. 126.5 V max.	8K BTU cooling only	13A
	12K BTU cooling only	15A

Pre-Installation (continued)

POWER SUPPLY CORD



NOTE: Your air conditioner's device may differ from the one shown. This room air conditioner is equipped with a power supply cord required by UL. This power supply cord contains state-of-the-art electronics that sense leakage current. If the cord is crushed, the electronics detect leakage current and power will be disconnected in a fraction of a second.

To test your power supply cord:

1. Plug power supply cord into a grounded 3-prong outlet.
2. Press RESET (2) (on some devices, a green light will turn on).
3. Press TEST (1) and listen for click. The RESET button will trip and on some devices, a green light will turn off.
4. Press and release RESET (2) and listen for click. The RESET button will latch, and on some devices, a green light will turn on. The power supply cord is ready for operation.

NOTE: The RESET button must be pushed in for proper operation.



1. The power supply cord must be replaced if it fails to trip when the test button is pressed or fails to reset.
2. Do not use the power supply cord as an off/on switch. The power supply cord is designed as a protective device.
3. A damaged power supply cord must be replaced with a new power supply cord obtained from the product manufacturer and must not be repaired.
4. The power supply cord contains no user serviceable parts. Opening the tamper-resistant case voids all warranty and performance claims.


PLANNING INSTALLATION

Gather the required tools and parts before starting installation. Read and follow the instructions provided with any tools listed here.


TOOLS REQUIRED




Phillips
screwdriver




Tape
measure



Scissors



Pencil



Cordless drill



1/8 in. bit



Level



Knife



Proper PPE

Pre-Installation (continued)

HARDWARE INCLUDED





NOTE: Check that all parts are included in parts package.

Part	Description	Quantity	Sketch Map
A1	Adhesive seal (gray)	1	
A2	Adhesive seal (black-long)	1	
A3	Adhesive seal (black-short)	1	
BB	Foam seal (gray)	1	
CC	Screw bolt	2	
DD	1/2" screw	6	
EE	3/8" screw	6	
FF	3/4" screw	6	
GG	Short side curtain (left/right)	1+1	
G1	Wide side curtain (left/right)	1+1	
G2	Spare curtain (left/right)	1	

Part	Description	Quantity	Sketch Map
H1	Main bracket	1	
H2	Extension arm (short)	1	
H3	Extension arm (long)	2*	
H4	Back plate	2	
H5	Sash lock (for air conditioner)	2	
II	Sash lock (for window)	1	
JJ	EVA foam (white)	2	
KK	Air conditioner	1	
LL	Remote control	1	
MM	Batteries (standard AAA 1.5Volt)	2	

* One of the Extension arm (long) has been installed on the Main bracket to demonstrate how to insert or remove.



NOTE: All the illustrations in the manual are for explanation purpose only. The actual installation may vary.

Pre-Installation (continued)



UNPACK THE AIR CONDITIONER



WARNING

Excessive Weight Hazard

1. Use two or more people to move and install air conditioner. Failure to do so can result in back or other injury.
2. You must use the supplied parts and use proper installation procedures as described in these instructions when installing the air conditioner.
3. Be careful to avoid cuts from sharp metal edge. Please wear cut-resistant gloves. Support bracket should only used for its intended purpose. If not, the warranty will be voided.



Remove packaging materials

1. Remove and dispose of/recycle packaging materials. Remove tape and glue residue from surfaces before turning on the air conditioner. Rub a small amount of liquid dish soap over the adhesive with your fingers. Wipe with warm water and dry.
2. Do not use sharp instruments, rubbing alcohol, flammable fluids, or abrasive cleaners to remove tape or glue. These products can damage the surface of your air conditioner.
3. Remove main bracket and other hardware from the packaging material.
4. Take out the power supply cord, then move the packaging on the top of the air conditioner.
5. Place both hands in the positions indicated by the arrows and remove the air conditioner from the front of the product.

Pre-Installation (continued)

LOCATION REQUIREMENTS

Before You Begin

Read these instructions completely and carefully.



IMPORTANT: Save these instructions for local inspector's use. Observe all governing codes and ordinances.



NOTE: Installer, be sure to leave these instructions with the Consumer. Consumer, keep these instructions for future reference.

1. Completion time: Around 20 min.
2. We recommend that two people install this product.
3. Proper installation is the responsibility of the installer.
4. Product failure due to improper installation is not covered under the warranty.
5. You **MUST** use all supplied parts and use proper installation procedures as described in these instructions when installing this air conditioner.



IMPORTANT: Observe all governing codes and ordinances.


Check the location where air conditioner will be installed. Proper installation is your responsibility. Make sure you have everything necessary for correct installation.

The location should provide:

1. Do not use an extension cord. The appliance shall be installed in accordance with national wiring regulations.
2. Free movement of air in room to be cooled.
3. A large enough opening for the air conditioner.



NOTE: Cabinet louvers (A-B-C-D) must not be obstructed. Air must be able to pass freely through the cabinet louvers.




Pre-Installation (continued)

WINDOW OPENING MEASUREMENTS

1. These instructions are for a standard double-hung window. You will need to modify them for other types of windows.
2. The air conditioner can be installed without the side curtain panels if needed to fit in a narrow window. See the window opening dimensions.
3. All supporting parts must be secured to firm wood, masonry or vinyl-clad.
4. Aluminum house wiring may present special problems-consult a qualified electrician.
5. The electrical outlet must be within reach of the power cord.
6. Follow the dimensions in the table and illustration for your model.


Models	A	B
8K BTU cooling only	15" (385 mm) min	25" (635 mm) - 38" (980 mm)
12K BTU cooling only		



IF AC IS BLOCKED BY STORM WINDOW


Add wood as shown, or remove storm window before air conditioner is installed.

If storm window frame must remain, be sure the drain holes or slots are not caulked or painted shut. Accumulated rain water or condensation must be allowed to drain out.



Installation

1 Prepare Support Bracket



Remove main bracket and hardware from the carton, set on the flat surface.


Measure the width of the window to choose between two long extension arms (H3) or one long extension arm (H3) and one short extension arm (H2).

Insert the extension arm (H2 or H3) into left and right ends respectively. The extension arm (H2 or H3) can slide freely under external force.

The support legs slide forward and backward along the guide slot on the main bracket, and can also rotate.

2 Install Support Bracket

IMPORTANT: Maintain control of the support until installation is complete.



Ensure extension arms are located on the indoor side of the window

Install support bracket into the opening window. And ensure extension arms are located on the indoor side of the window.

Move the two support legs toward the exterior wall until the feet of the support legs touch the wall. It is recommended to align the two support legs according to the marking on the support bracket.


Lock the screw bolt (CC), and visually ensure that the support bracket is slightly tilted toward the outside.

Attach the seal (A3) to the top of the secure support.

Back plate (H4) is installed on the support bracket, one on each side. The distance from the indoor side of support bracket is greater than 13".

Secure support bracket to the windowsill by drilling 3/8" and 1/2" type screws (DD and EE).

3 Attaching the Adhesive Seal




Cut the adhesive seal (gray) (A1) to the width of the lower window sash (B).

Remove the backing from the seal and attach the seal to the bottom of the lower window sash.

Installation (continued)

4 Placing Air Conditioner in Window



Keeping a firm grip on the air conditioner, carefully place the unit into the window opening so the bottom of the air conditioner frame is against the support bracket and make sure the unit is staying center of the support bracket. Then slowly push the air conditioner towards the outside of the room.

Carefully close the window down into the top of the air conditioner help align the air conditioner in the correct location, and help support the air conditioner during installation.




WARNING: Excessive Weight Hazard

Use two or more people to move and install air conditioner. Failure to do so can result in back or other injury.



NOTES:


1. Handle air conditioner gently.
2. Be sure your air conditioner does not fall out of the opening during installation or removal.
3. Do not block the louvers in the front panel.
4. Do not block the louvers on the outside of the air conditioner.
5. Your model may differ from the one shown.



The air conditioner is tilted about 3° toward outside of the room.

Insert the Sash lock (for air conditioner) into both sides of the air conditioner, and secure it with 3/8" or 3/4" type screws (EE or FF).

5 Attaching Side Curtains to Window




Carefully open the window up. Install Short side curtain (left and right) into the air conditioner, from top to bottom. Repeat for the right-hand curtain.


- a) When the gap between the air conditioner and the side of the window (left or right) is greater than 6.5" (165mm), use the Wide side curtain L+ or R+ (G1) (first remove the corresponding L or R).
- b) When the gap between the air conditioner and the side of the window (left or right) is less than 3.5" (90mm), use the Spare curtain (G2).

Open side curtains (left and right) until touch the side of window. Carefully close the window down.


Installation (continued)



Put one EVA foam (JJ) on the curtain housing. In order to minimize air leaks and ensure optimal insulation, it is necessary to install the EVA Foam (JJ) on the curtain housing. After the unit is installed on the window frame, measure the inner width of the side curtain as shown.




Remark a line on the EVA foam (JJ) according to the measured width, then cut the EVA foam (JJ) along the line, use scissors or knife.




Install the EVA foam (JJ) into the Side curtains (left/right).


6 Completing Installation



Insert foam seal (BB) behind the top of the lower window sash (A) and against the glass of the upper window.




Check the gap around the unit and seal it with the adhesive seal (black) (A2) attached.



To secure lower sash in place, attach sash lock (II) with 3/4 inch (20 mm) screw (FF) as shown.

Glass is fragile and should be protected during installation.



1. Plug into a grounded 3-prong outlet.
2. Press RESET on the power supply cord. (See "ELECTRICAL REQUIREMENTS".)



DANGER: ELECTRICAL SHOCK HAZARD

1. Plug into a grounded 3-prong outlet.
2. Do not remove ground prong.
3. Do not use an adapter.
4. Do not use an extension cord.
5. Failure to follow these instructions can result in death, fire, or electrical shock.

Operation

AIR CONDITIONER USE


IMPORTANT:



1. If you turn off the air conditioner, wait at least 3 minutes before turning it back on. This prevents the air conditioner from blowing a fuse or tripping a circuit breaker.
2. Air conditioner in the Cool mode operation the better limits: Outdoor 64.4-109.4 °F (18-43 °C), ≤ 80% RH; indoor 62.6-89.6 °F (17-32 °C), ≤ 80% RH.
3. In the event of a power failure, your air conditioner will operate at the previous settings when the power is restored.

1. Operating your air conditioner properly helps you to obtain the best possible results.
2. This section explains proper air conditioner operation.

1 Using the Control Panel



CONNECT 3 Sec 

ON/ OFF SETTINGS

1. Press the POWER button to turn on the air conditioner.
2. Press and hold for three seconds to activate WiFi pairing mode.
3. Set temperature. See “TEMPERATURE SETTINGS”.







NOTE:

When the air conditioner is turned on for the first time after it is plugged in, the display will show the current set temperature and will run in the ECO control.




TEMPERATURE SETTINGS


1. Press the UP  button to raise the temperature. Each time you press or hold the UP  button, the temperature will go up 1 °F (1 °C) until it reaches 86 °F (30 °C).
2. Press the DOWN  button to lower the temperature. Each time you press or hold the DOWN  button, the temperature will go down 1 °F (1 °C) until it reaches 61 °F (16 °C).

2 Using the Remote Control


INSERT THE BATTERIES



1. Remove the battery cover along the arrow direction.



2. Insert new batteries making sure that the (+) and (-) of battery are matched correctly.



3. Re-attach the cover by sliding it back into position.




- NOTE:** 1. Use 2 standard AAA (1.5 volt) batteries. Do not use rechargeable batteries.
2. Replace batteries with new ones of the same type when the display becomes dim, or after 6 months.
3. When replacing batteries, always replace both batteries with new batteries. Do not mix old and new batteries.
4. Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cd, ni-mh, etc) batteries.
5. If the air conditioner will not be used for an extended period of time, remove the batteries from the remote.



1. Do not use the remote if the batteries have leaked.
2. The chemicals in batteries could cause burns or other health hazards.
3. Do not dispose of batteries in a fire. Batteries may explode or leak.

HOW TO USE

1. To operate the room air conditioner, aim the remote control at the signal receptor. The remote control will operate the air conditioner at a distance of up to 23' (7m) when pointed at the signal receptor.



Signal receptor/display



Operation (continued)


BUTTON AND FUNCTION




NOTE: Remote control may differ in appearance.
Heating indicator is not available on this models.



NOTE: Press and hold the MODE button on the remote for 5 seconds to switch the temperature display from degrees Fahrenheit (°F) to degrees Celsius (°C).



INDICATION SYMBOLS



Operation (continued)



QUIET

1. Press the Quiet button to set or cancel the Quiet Mode operation.



- NOTE:**
1. It takes about 2 to 3 minutes to fully enter the quiet mode.
 2. Sometimes it cannot enter the quiet mode because of some protection.
 3. The QUIET button is disabled in dry mode.



SUPER

The SUPER button is used to start or stop fast cooling.

1. Press the SUPER button. The air conditioner automatically sets the fan speed to High and the temperature to 61 °F (16 °C).
2. To turn off Super control, press MODE, FAN, QUIET or SUPER button on the remote control.



- NOTE:**
1. In the SUPER mode, you can set the timer.
 2. SUPER button is ineffective in ECO mode.



FILTER (valid for some models)

1. The Filter indicator light is lit, remove, clean and replace the air filter. See “CLEANING THE AIR FILTER”.
2. Press Power button on the machine or FILTER button on remote to reset the filter after cleaning and replacing the air filter.



- NOTE:** When the light is on, it will remain on for 180 hours or until you press Clean Filter button.



DIMMER
sleep [5 sec]

DIMMER

1. Press the DIMMER button to turn off the control panel display.



- NOTE:** When in DIMMER mode, new control inputs will return display to normal.



DIMMER
sleep [5 sec]

DIMMER sleep [5 sec]

1. Press and hold the DIMMER button on the remote for 5 seconds to switch the DIMMER mode to SLEEP mode.
2. After 10 seconds, the light on the control panel display will dim.
3. To turn off Sleep control, press MODE, FAN, SLEEP or wait 8 hours for Sleep control to turn off automatically



NOTE: When you press sleep button

1. The appliance will stop operation automatically after operating for 8 hours.
2. Fan speed is automatically set at low speed.
3. In the Cooling mode, Dry mode, and ECO mode, the set temperature will increase by 4°F (2°C) at most, during 2 hours, and continues running at that temperature until auto shut off.
4. Sleep control cannot be selected in Fan mode.

Operation (continued)



TIMER

Use the TIMER function to turn the air conditioner ON/OFF automatically.

Setting the Air Conditioner to Turn On:

1. Plug in the air conditioner and use the remote to power it ON.
2. Use the remote to set the desired mode, temperature, fan speed, etc.
3. Use the remote to power OFF the air conditioner.
4. Press TIMER on the remote and use the UP/ DOWN buttons to set the desired delay time.
The delay time can be set from 0 to 24 hours in one-hour increments.
5. Press TIMER again to confirm the delay time. The Timer light on the unit will be on.

Setting the Air Conditioner to Turn Off:

1. Plug in the air conditioner and use the remote to power it ON.
2. Use the remote to set the desired mode, temperature, fan speed, etc.
3. Press TIMER on the remote and use the UP/ DOWN buttons to set the desired delay time.
The delay time can be set from 0 to 24 hours in one-hour increments.
4. Press TIMER again to confirm the delay time. The Timer light on the unit will be on.

To Cancel Timer:


1. Press the TIMER button again. Once a “beep” is heard and the indicator disappears, the Timer mode has been canceled.



NOTE: The TIMER function can only be set using the remote.

3 Changing Air Direction


1. Use the Vertical Vane to direct the air right or left.
2. Use the Level Vane to direct air up, down or straight ahead.



4 Normal Sounds

When your air conditioner is operating normally, you may hear sounds such as:

1. Droplets of water hitting the condenser, causing a pinging or clicking sound. The water droplets help cool the condenser.
2. Air movement from the fan.
3. Clicks from the thermostat cycle.
4. Vibrations or noise due to poor wall or window construction.
5. A high-pitched hum or pulsating noise caused by the modern high-efficiency compressor cycling on and off.



Operation (continued)

✧ Set Up Your Device via Matter

Matter is a smart home connectivity standard that allows your device to work seamlessly with various ecosystems, such as Amazon Alexa, Google Home, and Apple Home.

Before you begin, ensure you have:

A Matter-compatible hub (e.g., Amazon Echo, Google Nest Hub, Apple HomePod, or Apple TV).

A smartphone with the latest version of your preferred ecosystem's app (Amazon Alexa, Google Home, or Apple Home).

Your smartphone and Matter hub connected to the same Wi-Fi network.

Step 1

Ensure Bluetooth is enabled on your smartphone.

Step 2

Turn on the unit and put the device into pairing mode according to the specific instructions for each device category.


Device Category	Pairing Activation Method
Window or Portable Air Conditioner	Press and hold the "Connect" button or the Wi-Fi symbol for approx 3-6 secs. Or, aim the remote at the receiver and press the "swing" button 6 times. The display will show "77" or the WiFi light will flash.
Dehumidifier	Press and hold the "Mode" and "Fan" buttons together until the device beeps three times. Ensure the display reads "P2".

Step 3

3.1 Open your preferred ecosystem app (Amazon Alexa, Google Home, or Apple Home).

3.2 Follow the app's instructions to add a new Matter device.

3.3 When prompted, scan the Matter QR code located on your air conditioner.



Operation (continued)

Step 4

Follow any additional on-screen instructions in your ecosystem app to complete the setup process.



Note: Matter may provide limited features for this device. For full access to all product features and capabilities, it is recommended to use the ConnectLife app.

Device Requirements

Smartphone OS	iOS 16.1 or later Android 8.1 or later
Wi-Fi Router	2.4GHz, 802.11n newer and IPv6

Hub Compatibility by Ecosystem

Amazon	Echo (4th gen) or newer
Google	Nest Hub (2nd gen) Nest Hub Max Nest Wifi Pro
Apple	HomePod (1st or 2nd gen) HomePod mini Apple TV 4K (2nd gen+)
Samsung	SmartThings Hub v3+



Note: Your hub must be updated to the latest firmware version to ensure Matter compatibility and optimal performance.

Troubleshooting

App can't find the device (e.g., app is stuck in "Connecting" or shows "Unable to add accessory")

- Verify that Bluetooth is enabled on your smartphone.
- Make sure your air conditioner is in pairing mode.
- Ensure your smartphone and Matter hub are on the same network.
- Unplug the device for 10 seconds, then plug it back in and retry.

Matter setup code is not visible or damaged

- Put the device into pairing mode.
- In your smartphone's Wi-Fi settings, look for a network named "HIS-xxxxxxxxxx-xxxxxxxx".
- In your ecosystem app, select the option to enter the setup code manually or setup without QR code. When prompted, utilize the middle 11 digits of the network name as the setup code.

Can't add device to a second ecosystem

- Open the app of the first ecosystem where the device was originally set up.
- Generate a new setup code for the device within this app.
- Use the new code to add the device to the second ecosystem.
- If the app fails to generate a new setup code, unplug the device for 10 seconds, then plug it back in and retry.

Care and Cleaning


Your new air conditioner is designed to give you many years of dependable service. This section tells you how to clean and care for your air conditioner properly. Call your local authorized dealer for an annual checkup. Remember the cost of this service call is your responsibility.

CLEANING THE AIR FILTER


The air filter is removable for easy cleaning. A clean filter helps remove dust, lint, and other particles from the air and is important for best cooling and operating efficiency. Check the filter every 2 weeks to see whether it needs cleaning.



- NOTE:** 1. Do not operate the air conditioner without the filter in place.
2. Do not touch the metal parts of the unit, when the air filter is to be removed. It may cause injury.



1. Turn off the air conditioner.
2. Open the front panel. Grasp the filter by the handle and pull it out.



3. Use a vacuum cleaner to clean the air filter. If the air filter is very dirty, wash it in warm water with a mild detergent. Do not wash the air filter in the dishwasher or use any chemical cleaners. Air dry the filter completely before replacing to ensure maximum efficiency.
4. Replace the air filter back into the air conditioner.

CLEANING THE FRONT PANEL

1. Turn off the air conditioner.
2. Clean the front panel with a soft, damp cloth.
3. Air dry the front panel completely.

REPAIRING PAINT DAMAGE

Check once or twice a year for paint damage. This is very important, especially in areas near oceans or where rust is a problem. If needed, touch up with a good grade enamel paint.



ANNUAL MAINTENANCE

Your air conditioner needs annual maintenance to help ensure steady, top performance throughout the year. Call your local authorized dealer to schedule an annual checkup. The expense of an annual inspection is your responsibility.


REMOVING AC FROM WINDOW

1. Turn AC off, and disconnect power cord.
2. Remove the EVA foam.
3. Remove sash seal from between windows and unscrew safety lock.
4. Remove screws installed through frame and frame lock.
5. Close the curtain housing.
6. Keeping a firm grip on air conditioner, raise sash and carefully remove.
7. Be careful not to spill any standing water while lifting unit from window.
8. Remove the support bracket.
9. Store parts with the AC.

Troubleshooting

Problem	Solution
Air conditioner will not operate	<p>DANGER: ELECTRICAL SHOCK HAZARD</p>  <ol style="list-style-type: none"> 1. Plug into a grounded 3-prong outlet. 2. Do not remove ground prong. 3. Do not use an adapter. 4. Do not use an extension cord. 5. Failure to follow these instructions can result in death, fire, or electrical shock. <ol style="list-style-type: none"> 1. The power supply cord is unplugged. Plug into grounded 3-prong outlet. See "ELECTRICAL REQUIREMENTS". 2. The power supply cord has tripped (RESET button has popped out). Press and release RESET to resume operation. 3. A household fuse has blown, or circuit breaker has tripped. Replace the fuse or reset the circuit breaker. If the problem continues, call an electrician. See "ELECTRICAL REQUIREMENTS". 4. The Power button has not been pressed. Press the Power button. 5. The local power has failed. Wait for power to be restored.
Air conditioner blows fuses or trips circuit breakers	<ol style="list-style-type: none"> 1. Too many appliances are being used on the same circuit. Unplug or relocate appliances that share the same circuit. 2. Time-delay fuse or circuit breaker of the wrong capacity is being used. Replace with a time-delay fuse or circuit breaker of the correct capacity. See "ELECTRICAL REQUIREMENTS". 3. An extension cord is being used. Do not use an extension cord with this or any other appliance. 4. You are trying to restart the air conditioner too soon after turning off the air conditioner. Wait at least 3 minutes after turning off the air conditioner before trying to restart the air conditioner.
Air conditioner power supply cord trips (Reset button pops out)	<ol style="list-style-type: none"> 1. Disturbances in your electrical current can trip (RESET button will pop out) the power supply cord. Press and release RESET to resume operation. 2. Electrical overloading, overheating, cord pinching or aging can trip (RESET button will pop out) the power supply cord. After correcting the problem, press and release RESET to resume operation. <p> NOTE: A damaged power supply cord must be replaced with a new power supply cord obtained from the product manufacturer and must not be repaired.</p>

Troubleshooting

Problem	Solution
Air conditioner seems to run too much	<ol style="list-style-type: none"> 1. The current air conditioner replaced an older model. The use of more efficient components may cause the air conditioner to run longer than an older model, but the total energy consumption will be less. Newer air conditioners do not emit the “blast” of cold air you may be accustomed to from older air conditioners, but this is not an indication of lesser cooling capacity or efficiency. Refer to the efficiency rating (EER) and capacity rating (in Btu/h) marked on the air conditioner. 2. The air conditioner is in a heavily occupied room, or heat producing appliances are in use in the room. Use exhaust vent fans while cooking or bathing and try not to use heat producing appliances during the hottest part of the day. A higher capacity air conditioner may be required, depending on the size of the room being cooled.
Air conditioner cycles on and off too much or does not cool	<ol style="list-style-type: none"> 1. The air conditioner is not properly sized for your room. Check the cooling capabilities of your room air conditioner. Room air conditioners are not designed to cool multiple rooms. 2. The filter is dirty or obstructed by debris. Clean the filter. 3. The inside evaporator and outside condenser coils are dirty or obstructed by debris. See “ANNUAL MAINTENANCE”. 4. There is excessive heat or moisture (open container cooking, showers, etc.) in the room. Use a fan to exhaust heat or moisture from the room. Try not to use heat producing appliances during the hottest part of the day. 5. The louvers are blocked. Install the air conditioner in a location where the louvers are free from curtains, blinds, furniture, etc. 6. The temperature of the room you are trying to cool is extremely hot. Allow extra time for the air conditioner to cool off a very hot room. 7. Windows or doors to the outside are open. Close all windows and doors. 8. The Temp control is not at a cool enough setting. Adjust the Temp control to a cooler setting by pressing the minus button to reduce the temperature. Set the Fan Speed control to the highest setting.
Water drips from cabinet into your house	<ol style="list-style-type: none"> 1. The air conditioner is not properly leveled. The air conditioner should slope slightly downward toward the outside. Level the air conditioner to provide a downward slope toward the outside to ensure proper drainage. See the Installation Instructions. <div>  NOTE: Do not drill a hole in the bottom of the metal base and condensate pan. </div>