

MEG Series

Motherboard

MEG Z890 GODLIKE

User Guide

Contents


| Quick Start | 4 |
|---|----|
| Specifications | 16 |
| Special Features | 22 |
| Package Contents | 23 |
| Back Panel Connectors | 24 |
| 5Gbps LAN Port LED Status Table | 26 |
| 10Gbps LAN Port LED Status Table | 26 |
| Audio Jacks Connection | 27 |
| Installing Antennas | 29 |
| Overview of Components | 30 |
| CPU Socket | 33 |
| DDR5 DIMM Slots | 35 |
| PCI_E1~3: PCIe Expansion Slots | 37 |
| CPU PCIe Lanes Configuration | 38 |
| M2_1~6: M.2 Slots (Key M) | 41 |
| SATA_5~8: SATA 6Gb/s Connectors | 53 |
| JAUD1: Front Audio Connector | |
| JFP1, JFP2: Front Panel Connectors | 54 |
| JTPM1: TPM Module Connector | 55 |
| CPU_PWR1~2, ATX_PWR1, PCIE_PWR1, PD_PWR1, JSATA_PWR1: Power Connectors | 56 |
| JBRG_HUB1: EZ Link Connectors | |
| JCI1: Chassis Intrusion Connector | 59 |
| JUSBC2: USB 20Gbps Type-C Front Panel Connector | |
| JUSBC1: Thunderbolt™ 4 USB-C Front Panel Port | |
| JUSB2~3: USB 5Gbps Connectors | 61 |
| JUSB1, JUSB_BRG_1: USB 2.0 Connectors | 62 |
| T_SEN1~2: Thermal Sensor Connectors | |
| JTBT5_1: Thunderbolt™ 5 Expansion Card Connector | 63 |
| Installing Thunderbolt™ 5 Expansion card | 65 |
| CPU_FAN1, PUMP_SYS1~2, SYS_FAN1~7: Fan Connectors | 66 |
| JDASH1: Tuning Controller connector | 67 |
| W_FLOW1: Water Flow Meter Connector | |
| JLN1~2: Low Temperature Booting Jumper | 68 |
| JSLOW1: Slow Mode Booting Jumper | |
| POWER1, RESET1: Power Button, Reset Button | |
| V-Check Points Lite | 69 |

| JOC_FS1: Safe Boot Jumper | 70 |
|---|----|
| JOC_RT1: OC Retry Button Connector | 70 |
| M.2 XPANDER-Z SLIDER GEN5 card | 71 |
| BIOS_SW1: Multi-BIOS Switch | 75 |
| JDASH_SW1: EZ BRIDGE Switch | 75 |
| JRGB1: RGB LED connector | 76 |
| JARGB_V2_1~3: A-RAINBOW V2 (ARGB Gen2) LED connectors | 77 |
| JAF_2: EZ Conn-Header V2 | 79 |
| Onboard LEDs | 80 |
| EZ Debug LED | 80 |
| JPWRLED1: LED power input | 81 |
| LED_SW1: EZ LED Control | 81 |
| DYNAMIC DASHBOARD III | 82 |
| Installing OS, Drivers & MSI Center | 90 |
| Installing Drivers with MSI Driver Utility Installer | 91 |
| MSI Center User Guide | 93 |
| UEFI BIOS | 94 |
| BIOS Setup | 95 |
| Entering BIOS Setup | |
| Resetting BIOS | 97 |
| Updating BIOS | 97 |
| Block Diagram | 99 |
| Regulatory Notices | i |
| INCENTION & INCHESTION INCHES | I |

Quick Start

This Quick Start provides clear diagrams to help you install the motherboard. Video demonstrations are also available for some installations. Visit these videos by clicking the provided URL on your phone or tablet's web browser. Alternatively, you can scan the QR code to access the video directly.

Preparing Tools and Components



Safety Information


- The components included in this package are prone to damage from electrostatic discharge (ESD). Please adhere to the following instructions to ensure successful computer assembly.
- Ensure that all components are securely connected. Loose connections may cause the computer to not recognize a component or fail to start.
- Hold the motherboard by the edges to avoid touching sensitive components.
- It is recommended to wear an electrostatic discharge (ESD) wrist strap when
 handling the motherboard to prevent electrostatic damage. If an ESD wrist strap
 is not available, discharge yourself of static electricity by touching another metal
 object before handling the motherboard.
- Store the motherboard in an electrostatic shielding container or on an anti-static pad whenever the motherboard is not installed.
- Before turning on the computer, ensure that there are no loose screws or metal components on the motherboard or anywhere within the computer case.
- Do not boot the computer before installation is completed. This could cause permanent damage to the components as well as injury to the user.
- If you need help during any installation step, please consult a certified computer technician.
- Always turn off the power supply and unplug the power cord from the power outlet before installing or removing any computer component.
- Keep this user guide for future reference.
- Keep this motherboard away from humidity.
- Make sure that your electrical outlet provides the same voltage as is indicated on the PSU, before connecting the PSU to the electrical outlet.
- Place the power cord such a way that people can not step on it. Do not place anything over the power cord.
- All cautions and warnings on the motherboard should be noted.
- If any of the following situations arises, get the motherboard checked by service personnel:
 - Liquid has penetrated into the computer.
 - The motherboard has been exposed to moisture.
 - The motherboard does not work well or you can not get it work according to user guide.
 - The motherboard has been dropped and damaged.
 - The motherboard has obvious sign of breakage.
- Do not leave this motherboard in an environment above 60°C (140°F), it may damage the motherboard

Case stand-off notification


To prevent damage to the motherboard, any unnecessary mounting stand-off between the motherboard circuits and the computer case is prohibited. The Case standoff keep out zone signs will be marked on the backside of motherboard (as shown below) to serve as a warning to user.

Avoid collision notification

Protective paint is printed around each screw hole to prevent parts from being scratched.



^{*} The illustration above is for reference only and may vary from the motherboard you purchased.





Installing DDR5 memory





• https://msi.gm/S647FF99






Connecting the Front Panel Header







• https://msi.gm/S8EF7577





Installing the Motherboard






Connecting the Power Connectors







Installing a Graphics Card



Connecting Peripheral Devices



Power On



Specifications

| <u> </u> | | | | | |
|------------------|--|--|--|--|--|
| СРИ | Supports Intel® Core™ Ultra Processors (Series 2)* Processor socket LGA1851 * Please go to www.msi.com to get the newest support status as new processors are released. | | | | |
| Chipset | Intel® Z890 Chipset | | | | |
| Memory | 4x DDR5 memory slots*, supporting up to 256GB** Supports Intel® POR Speed and JEDEC Speed Supports Memory Overclocking and Intel® XMP 3.0 Supports Dual-Controller Dual-Channel mode Supports Non-ECC, Un-buffered memory Supports CUDIMM *The DIMM slots on this motherboard only have single-sided latches. *Memory compatibility and supported speeds can vary depending on the CPU and memory configuration. For detailed information, please refer to the Memory Compatibility List available on the product's Support page or visit https://www.msi.com/support/. | | | | |
| Expansion Slots | 2x PCle x16 slots* PCl_E1 slot (From CPU) Supports up to PCle 5.0 x16 PCl_E2 slot (From CPU) Supports up to PCle 5.0 x8 1x PCle x4 slot PCl_E3** slot (From Z890 Chipset) Supports up to PCle 4.0 x4 *For detailed information on PCle bifurcation, please refer to CPU PCle Lanes Configuration Table on page 38. *** PCl_E3 will be unavailable when installing M.2 SSD in M2_5 slot. | | | | |
| Onboard Graphics | 2 x Thunderbolt [™] 4 ports supporting DisplayPort 2.1 over USB Type-C [®] , with a maximum resolution of 4K 120Hz/8K 60Hz*/** * Available only on processors featuring integrated graphics. *** Graphics specifications may vary depending on the CPU installed. | | | | |
| SATA Ports | • 4x SATA 6Gb/s ports (From Z890 chipset) | | | | |

| M.2 SSD Slots | 8x M.2 slots (Key M) M2_1 slot (From CPU) Supports up to PCle 5.0 x4 Supports 2260/ 2280 storage devices M2_2 slot (From CPU) Supports up to PCle 4.0 x4 Supports 2260/ 2280 storage devices M2_3 slot (From Z890 chipset) Supports up to PCle 4.0 x4 Supports 2260/ 2280 storage devices M2_4 slot (From Z890 chipset) Supports up to PCle 4.0 x4 Supports up to PCle 4.0 x4 Supports 2260/ 2280/ 22110 storage devices M2_5* slot (From Z890 chipset) Supports up to PCle 4.0 x4 Supports up to PCle 4.0 x4 Supports up to SATA 6Gb/s Supports up to SATA 6Gb/s Supports up to PCle 5.0 x4 (From Z890 Chipset) Supports up to PCle 5.0 x4 (From CPU)** Supports up to PCle 5.0 x4 (From CPU)** Supports 2242/ 2280 storage devices M.2 XPANDER-Z SLIDER GEN5 2x M.2 slots (Key M) Supports up to PCle 5.0 x4 (From CPU)** Supports 2280 storage devices**** *PCI_E3 will be unavailable when installing M.2 SSD in M2_5 slot. *** PCI_E1 slot will run at x8 speed and PCI_E2 slot will run at x4 speed when installing PCle 5.0 M.2 device in M2_6 slot. For detailed information on PCle bifurcation, please refer to CPU PCle Lanes Configuration Table on page 38. *** The operating speed depends on the PCle slot specification of motherboard. **** Only support the M.2 SSD as the data disk. |
|---------------|---|
| RAID | Supports RAID 0, RAID 1, RAID 5 and RAID 10 for SATA storage devices Supports RAID 0, RAID 1, RAID 5 and RAID 10 for M.2 NVMe storage devices |

| Audio | Realtek® ALC4082 Codec + ESS® ES9219 QUAD DAC 7.1-Channel USB High Performance Audio Supports up to 32-bit/384kHz playback on front panel Supports S/PDIF output | | | | |
|---|---|--|--|--|--|
| LAN | 1x Intel® Killer E5000B 5Gbps LAN controller 1x Marvell® AQC113CS 10Gbps LAN controller | | | | |
| Wi-Fi & Bluetooth® | Wi-Fi 7 The Wireless module is pre-installed in the M.2 (Key-E)slot Supports MU-MIMO TX/RX, 2.4GHz/5GHz/6GHz* (320MHz) up to 5.8Gbps Supports 802.11 a/ b/ g/ n/ ac/ ax/ be Supports Bluetooth® 5.4**, MLO, 4KQAM *6GHz band support may depend on every country's regulations and Wi-Fi 7 will be ready in Windows 11 version 24H2. **The Bluetooth version may be updated, please refer to the Wi-Fi chipset vendor's website for details. Bluetooth 5.4 will be ready in Windows 11 version 24H2. | | | | |
| 1x 24-pin ATX main power connector 2x 8-pin +12V power connectors 1x 8-pin PCIe power connector 1x 8-pin PD power connector 1x 8-pin PD power connector* * To achieve USB PD 60W fast charging, the PD_PWR1 connector neconnected to the power supply unit. | | | | | |
| Internal USB Connectors | 1x Thunderbolt™ 4 40Gbps Type-C front panel port (From CPU) Supports DisplayPort over USB Type-C® Each port can daisy-chain up to three Thunderbolt™ 4 devices or five Thunderbolt™ 3 devices 1x USB 20Gbps Type-C front panel port* (From Z890 chipset) Supports USB PD 60W fast charging** 2x USB 5Gbps connectors (From Hub GL3523) Supports additional 4 USB 5Gbps ports 1x USB 2.0 connector (From Hub GL850G) Supports additional 2 USB 2.0 ports JUSBC2 does not support Quick Charge(QC) 3.0. To achieve USB PD 60W fast charging for JUSBC2, the PD_PWR1 connector needs to be connected to the power supply unit. | | | | |

| • 1x 4-pin CPU fan connector • 2x 4-pin water-pump/ system fan connectors | | | |
|---|---|--|--|
| EZ BRIDGE | 2x System panel connectors 2x 2-pin Thermal sensor connectors 1x Tuning controller connector 1x EZ Conn-Header V2 (JAF_2) 1x USB 2.0 Type-A connector (From Hub GL850G) Supports additional 2 USB 2.0 ports 1x 14-pin EZ Link connector 1x Power Button 1x Reset Button | | |
| 1x 3-pin Water flow connector 7x 4-pin System fan connectors 1x 4-pin RGB LED connector 2x 3-pin A-RAINBOW V2 (ARGB Gen2) LED connectors 1x 14-pin EZ Link connector 1x SATA power connector | | | |
| • 1x Front panel audio connector • 1x Chassis Intrusion connector • 1x TPM module connector • 1x TBT connector (Supports RTD3) | | | |
| Jumpers | 1x Clear CMOS jumper 1x Slow mode booting jumper 2x Low temperature booting jumpers 1x Safe Boot jumper 1x OC Retry jumper | | |
| Switches | 1x EZ LED control switch 1x Multi-BIOS switch 1x EZ BRIDGE switch | | |
| LED Features | 1x 3-pin A-RAINBOW V2 (ARGB Gen2) LED connector 4x EZ Debug LED 1x LED Demo connector | | |

| Back Panel Connectors & Others | 1x Smart button 1x 5G LAN (RJ45) port 1x 10G LAN (RJ45) port 4x USB 10Gbps Type-A ports (From Hub RTS5420) 2x USB 10Gbps Type-A ports (From Z890 chipset) 2x USB 10Gbps Type-A ports (From Hub RTS5429E) 5x USB 10Gbps Type-C ports (From Hub RTS5429E) 1x USB 20Gbps Type-C port (From Z890 chipset) 1x Thunderbolt™ 4 40Gbps USB-C ports (From CPU) Supports DisplayPort over USB Type-C® Each port can daisy-chain up to three Thunderbolt™ 4 devices or five Thunderbolt™ 3 devices 2x Wi-Fi Antenna connectors 2x Audio jacks 1x Optical S/PDIF Out connector NUVOTON NCT6687D-M Controller Chip |
|--------------------------------------|---|
| Hardware Monitor | CPU/ System/ Chipset temperature detection CPU/ System/ Pump fan speed detection CPU/ System/ Pump fan speed control |
| Form Factor | E-ATX Form Factor 12 in. x 10.9 in. (304.8 mm x 277 mm) |

| BIOS Features | Dual BIOS 2x 256 Mb flash UEFI AMI BIOS ACPI 6.5, SMBIOS 3.7 Multi-language |
|---------------|--|
| Software | Drivers MSI Center Acrobat Adobe Creative Cloud AIDA64 Extreme - MSI Edition CPU-Z MSI GAMING Dropbox MSI App Player (BlueStacks) Norton 360 Intel® Killer Networking |

Special Features

MSI Center

- MSI AI Engine
- · Game Highlights
- Cooling Wizard
- · Mystic Light
- Ambient Link
- Frozr AI Cooling
- · Hardware Monitoring
- · Live Update
- MSI Companion
- · System Diagnosis
- True Color
- User Scenario
- Super Charger +

EZ DIY

- Magnetic M.2 Shield Frozr
- EZ M.2 Clip II
- EZ PCIe Release
- Smart Button
- · Flash BIOS Button
- Clear CMOS Button
- Pre-installed I/O Shield
- Metal Backplate
- F7 Antenna
- EZ Front Panel Cable
- EZ Conn-Design
- PCI-E STEEL ARMOR II
- EZ LED
- EZ LED Control
- · Dynamic Dashboard III

Thermal Features

- · All Aluminum Design
- · Wavy Fin Design
- · Cross Heat-pipe
- Double-sided M.2 Shield Frozr
- K9 MOSFET thermal pad / K5 Extra choke pad
- Fan headers (CPU + Combo + SYSTEM)

Performance

- Core Boost
- Dual CPU Power
- OC Engine
- Memory Boost
- Memory Force
- Lightning Gen 5 PCI-E Slot / M.2
- Lightning Gen 4 PCI-E Slot / M.2
- Front USB Type-C
- USB with PD
- Supplemental PCIe Power Connector
- Server Grade PCB
- · 2oz Copper thickened PCB

Audio

Audio Boost 5 HD

RGB Support

- Mystic Light
- Mystic Light Extension (RGB)
- Mystic Light Extension (ARGB V2)
- Ambient Devices Support

BIOS

- Click BIOS X
- Al Boost
- · Performance Preset

Package Contents

Please check the contents of your motherboard package. It should contain:

Board

• 1x Motherboard

Documentation

- 1x Quick installation guide
- 1x European Union Regulatory Notices

Application

• 1x USB drive

Cables

- 2x SATA cables
- 1x 1 to 2 RGB Extension Cable
- 1x ARGB Extension Cable
- 1x 1 to 3 ARGB Extension Cable
- 2x Thermistor Cables
- 1x EZ Front Panel Cable
- 1x 1 to 3 EZ Conn-Cable (V2)
- 1x EZ link cable
- 1x EZ Control Hub SATA Power Cable
- 1x M.2 Xpander Card FAN Control Cable
- 1x Thunderbolt™ 5 Header Cable


Important

- There is an ISO file in the supplied USB drive. Please do not delete it accidentally. For more information on installing drivers, please refer to Installing OS, Drivers & MSI Center chapter.
- If any of the above items are damaged or missing, please contact your retailer.

Accessories

- 1xEZ CONTROL HUB
- 1x M.2 XPANDER-AERO SLIDER GEN5
- 1x Thunderbolt[™] 5 Expansion card
- 1x EZ Wi-Fi Antenna
- 1x Gaming cable sticker
- 1x M.2 Screw and Plate Standoff Set
- 1x EZ Control Hub screw set
- 1x EZ M.2 Clip II Remover
- 2x M.2 Xpander Card thermal pads


Back Panel Connectors



| Item | Description |
|------|---|
| 1 | USB 10Gbps Type-A port (From Z890 chipset) • Flash BIOS port |
| 2 | USB 10Gbps Type-A port (From Z890 chipset) |
| 3 | USB 10Gbps Type-A port (From Hub RTS5420) |
| 4 | Flash BIOS button - Please refer to page 98 for details about updating BIOS with Flash BIOS button. |
| 5 | Clear CMOS button |
| 6 | Smart button |
| 7 | 10Gbps LAN (RJ45) jack |
| 8 | 5Gbps LAN (RJ45) jack |
| 9 | Wi-Fi antenna connectors |
| 10 | Line-out port |
| 11 | Mic-in port |


| Item | Description |
|------|--|
| 12 | Thunderbolt™ 4 USB-C port (From CPU) • Supports DisplayPort over USB Type-C® • Each port can daisy-chain up to three Thunderbolt™ 4 devices or five Thunderbolt™ 3 devices |
| 13 | USB 10Gbps Type-C port (From Hub RTS5429E) |
| 14 | USB 20Gbps Type-C port (From Z890 chipset) |
| 15 | USB 10Gbps Type-C port (From Hub RTS5429E) |
| 16 | USB 10Gbps Type-A ports (From Hub RTS5429E) |
| 17 | USB 10Gbps Type-C port (From Hub RTS5429E) |
| 18 | Optical S/PDIF Out connector |

5Gbps LAN Port LED Status Table



| Link/ Activity LED | | Speed LED | |
|-------------------------|---------------|-----------|----------------------------|
| Status | Description | Status | Speed |
| Off | No link | Off | 10 Mbps |
| Yellow blinking slowly | Linked | Green | 100 Mbps/ 1 Gbps/ 2.5 Gbps |
| Yellow blinking rapidly | Data activity | Orange | 5 Gbps |


10Gbps LAN Port LED Status Table




| Link/ Activity LED | | Speed LED | |
|------------------------|---------------|-----------|--------------------------------------|
| Status | Description | Status | Speed |
| Off | No link | Off | _ |
| Green blinking slowly | Linked | Green | 100 Mbps/ 1 Gbps/ 2.5 Gbps/ 5Gbps |
| Green blinking rapidly | Data activity | Orange | 10 Gbps |

Audio Jacks Connection


Audio jacks to headphone and microphone diagram




Audio jacks to stereo speakers diagram




Audio jacks to 4-channel speakers diagram



Audio jacks to 5.1-channel speakers diagram




Audio jacks to 7.1-channel speakers diagram




Installing Antennas


- 1. Combine the antenna with the base.
- 2. Connect two antenna cables tight to the Wi-Fi antenna connectors as shown.




3. Place the antenna as high as possible.



Overview of Components




EZ BRIDGE






 $\it EZBRIDGE\ does\ not\ support\ hot\ swapping.$ Do not unplug the connection while it is powered on.

EZ CONTROL HUB



CPU Socket


The LGA1851 socket is the CPU socket that is designed for Intel® desktop processors. It is a land grid array (LGA) socket with 1851 pins. The socket is not compatible with previous generations of Intel® processors.



Installing the CPU to the LGA1851 socket

The surface of the LGA1851 CPU has **two notches** to assist in correctly lining up the CPU for motherboard placement. The golden triangle is the Pin 1 indicator.

To install the CPU, align the two notches on the LGA1851 socket with the two corresponding notches on the CPU.




Distance from the center of the CPU socket to the nearest DIMM slot.


Important

- Please note that LGA1851 and LGA1700 sockets have different physical configurations and pin layouts. Before installation, ensure your CPU is compatible with the LGA1851 socket. Incorrect installation may damage the CPU, socket, and motherboard. DO NOT install a CPU designed for LGA1155, LGA1156, LGA1151, LGA1200, and LGA1700 sockets on the LGA1851 socket.
- Please ensure that the motherboard and power supply are turned off and always disconnect the power cord from the power outlet before installing or removing the CPU.
- Please retain the CPU protective cap after installing the processor. MSI will deal with Return Merchandise Authorization (RMA) requests if only the motherboard comes with the protective cap on the CPU socket.
- Whenever the CPU is not installed, always protect the CPU socket pins by covering the socket with the protective cap.
- The CPU should only fit in one orientation, so do not force it. Gently place the CPU into the socket without applying excessive pressure.
- Please handle the CPU by the edges only; avoid touching the pins or the surface of the CPU. Any damage to the pins can result in a malfunctioning CPU.
- When installing a CPU, always remember to install a CPU heatsink. A CPU heatsink is necessary to prevent overheating and maintain system stability.
- Please install the CPU cooler according to the manufacturer's instructions. Make sure it is securely a tight seal with the CPU and attached to the motherboard to ensure proper heat dissipation.
- Overheating can seriously damage the CPU and motherboard. Always make sure the
 cooling fans work properly to protect the CPU from overheating. Be sure to apply an
 even layer of thermal paste (or thermal tape) between the CPU and the heatsink to
 enhance heat dissipation.
- This motherboard is designed to support overclocking. Before attempting to
 overclock, please make sure that all other system components can tolerate
 overclocking. Any attempt to operate beyond product specifications is not
 recommended. MSI® does not guarantee the damages or risks caused by inadequate
 operation beyond product specifications.


DDR5 DIMM Slots

The DDR5 DIMM slot is a dedicated connector designed to accommodate DDR5 (Double Data Rate 5) memory modules. It represents the latest standard in computer memory, providing enhanced data transfer speeds and efficiency.






Memory module installation recommendation





Always insert memory modules in the DIMMA2 slot first.






Important

- The DIMM slots on this motherboard only have a single latch. Please be careful when installing or removing memory modules to avoid damaging the slots.
- Align the notch on the DDR5 module with the notch on the memory slot to ensure proper orientation. Do not force the module into the slot; it should slide in easily if properly aligned.
- To ensure system stability for Dual channel mode, memory modules must be of the same type, number and density.
- Some memory modules may operate at a lower frequency than the marked value when overclocking due to the memory frequency operates dependent on its Serial Presence Detect (SPD). Go to BIOS and find the **DRAM Speed** to set the memory frequency if you want to operate the memory at the marked or at a higher frequency.
- It is recommended to use a more efficient memory cooling system for full DIMMs installation or overclocking.
- The stability and compatibility of installed memory module depend on installed CPU and devices when overclocking.
- Please refer to www.msi.com for more information on compatible memory.

PCI_E1~3: PCIe Expansion Slots

PCI Express (PCIe) expansion slots are used to connect add-on cards to the motherboard. These cards can provide additional functionality to your computer, such as graphics, networking, or storage.





Important

- If you install a large and heavy graphics card, you need to use a tool such as MSI Graphics Card Bolster to support its weight to prevent deformation of the slot.
- For a single PCle x16 expansion card installation with optimum performance, using the PCl_E1 slot is recommended.
- When adding or removing expansion cards, always turn off the power supply and unplug the power supply power cable from the power outlet. Read the expansion card's documentation to check for any necessary additional hardware or software changes.

CPU PCIe Lanes Configuration

PCIe bifurcation allows a single PCIe slot to split its lanes into multiple smaller groups, which is useful for scenarios like supporting multiple NVMe SSDs or other expansion cards. Below is a description of the different configuration options available, including how Auto settings manage bifurcation.


| Configuration Option | PCI_E1 Slot | PCI_E2 Slot | M2_6 Slot |
|------------------------------------|--------------------|--|------------------|
| | 5.0 x16 (CPU) | N/A | 4.0 x4 (Chipset) |
| | 5.0 x8 (CPU) | 5.0 x8 (CPU) | 4.0 x4 (Chipset) |
| Auto | 5.0 x8 (CPU) | 5.0 x4/x4 (CPU) (M.2 XPANDER-Z SLIDER GEN5 in PCI_E2) | 4.0 x4 (Chipset) |
| PCI_E1 x16 | 5.0 x16 (CPU) | N/A | 4.0 x4 (Chipset) |
| PCI_E1 x8/x8 | 5.0 x8/x8 (CPU) | N/A | 4.0 x4 (Chipset) |
| PCI_E1 x8/x4/x4 | 5.0 x8/x4/x4 (CPU) | N/A | 4.0 x4 (Chipset) |
| PCI_E1 x8 + PCI_E2 x8 | 5.0 x8 (CPU) | 5.0 x8 (CPU) | 4.0 x4 (Chipset) |
| PCI_E1 x8 + PCI_E2 x4/x4 | 5.0 x8 (CPU) | 5.0 x4/x4 (CPU) | 4.0 x4 (Chipset) |
| PCI_E1 x8 + PCI_E2 x4 + M2_6 x4 | 5.0 x8 (CPU) | 5.0 x4 (CPU) | 5.0 x4 (CPU) |

How to Configure PCIe Lanes in BIOS

- Go to BIOS > Advanced > PCIe Sub-system Settings > CPU PCIe Lanes Configuration.
- 2. Choose the appropriate configuration based on your hardware setup.
- 3. Press F10 to save and exit and then press the Enter key to select Yes.


Installing a graphics card into PCI_E1 slot

- Ensure that the EZ PCIe Release Button is in the locked position. If it is unlocked, press the button to lock it.
- 2. Insert the graphics card into the PCIe slot.




Removing a graphics card from PCI_E1 slot

- 1. Ensure that the EZ PCIe Release Button is in the **unlocked** position. If it is locked, press the button to unlock it.
- 2. Gently pull the graphics card out of the PCIe slot.



M2_1~6: M.2 Slots (Key M)

The M.2 slot is a small, high-speed expansion slot on a motherboard. It can be used to connect an M.2 SSD, which is a type of solid-state drive that offers faster performance than traditional SATA SSDs.



Watch the video to learn how to Install M.2 SSD with Screwless M.2 Shield Frozr heatsink.





https://msi.gm/S7F5D000




Important

If your M.2 SSD equips its own heatsink, please note the following:

- Remove the M.2 plate or rubber cube in the M.2 slot before installing M.2 SSD. Do not re-install the heatsink supplied with the motherboard.
- Ensure that the M.2 SSD heatsink you use fits the size limits to prevent damage.


M.2 SSD Heatsink Size Restrictions

If you need to purchase an additional heatsink, please refer to the diagram below to confirm the M.2 installation space dimensions. Please also consider the height of the installed PCIe expansion card when determining M.2 installation space.




Installing M.2 module into M2_1 slot


1. Press and hold the end button of Screwless M.2 Shield Frozr heatsink.




2. Slightly lift up the end part of Screwless M.2 Shield Frozr heatsink and move it forward to uninstall the heatsink.




3. Remove the protective film from the M.2 thermal pads on the M.2 plate.




4. If you install 2260 SSD, use the included EZ M.2 Clip II Remover. Remove the plate screw and install EZ M.2 Clip II in the screw hole by using the EZ M.2 Clip II Remover. Skip this step if you install 2280 SSD.



- 5. Insert your M.2 SSD into the M.2 slot at a 30-degree angle.
- **6.** Use the EZ M.2 Clip II to lock and secure the SSD.



- 7. Remove the protective films from the thermal pads under Screwless M.2 Shield Frozr heatsink.
- **8.** Align the notches under Screwless M.2 Shield Frozr heatsink with the tenons, and then put the heatsink back in place.
- 9. Press the end side of Screwless M.2 Shield Frozr heatsink to lock it completely.




Installing M.2 module into M2_2~M2_5 slots




Important

Please remove all rubber cubes from the M.2 plates before installing the Screwless M.2 Shield Frozr heatsink.


1. Press and hold the end button of Screwless M.2 Shield Frozr heatsink.



2. Slightly lift up the end part of Screwless M.2 Shield Frozr heatsink and move it forward to uninstall the heatsink.




3. Remove the protective film from the M.2 thermal pads on the M.2 plate.



4. Please refer to the following instructions for installation based on the lengths of SSD. Skip this step if you install 2280 SSD.


For 2260 SSD

If you install 2260 SSD, use the included EZ M.2 Clip II Remover. Place the included EZ M.2 Clip II in the screw hole, use the remover to screw it in clockwise and secure it.



For 22110 SSD


Remove the EZ M.2 Clip II from the 2280 screw hole. And if you intend to install both a 2280 SSD and a 22110 SSD simultaneously in M2_4 and M2_5 slots, please remove the EZ M.2 Clip II and install the included M.2 Standoff. Otherwise, you may use the pre-installed EZ M.2 Clip II.



- 5. Insert your M.2 SSD into the M.2 slot at a 30-degree angle.
- Please refer to the following instructions for installation based on the lengths of SSD.


For 2260 / 2280 SSD

Use the EZ M.2 Clip II to automatically lock and secure the SSD.




For 22110 SSD

If you intend to install both a 2280 SSD and a 22110 SSD simultaneously in M2_4 and M2_5 slots, please use the supplied screw to secure it. Otherwise, you may use the EZ M.2 Clip II to automatically lock and secure the SSD.



- 7. Remove the protective films from the thermal pads under Screwless M.2 Shield Frozr heatsink.
- **8.** Align the notches under Screwless M.2 Shield Frozr heatsink with the tenons, and then put the heatsink back in place.
- 9. Press the end side of Screwless M.2 Shield Frozr heatsink to lock it completely.




Removing M.2 SSD using the EZ M.2 Clip II

To remove M.2 SSD from the EZ M.2 Clip II, gently push the spring head on the top of the EZ M.2 Clip II outward while simultaneously pulling the M.2 SSD out.




Installation combination for M2_4 & M2_5 slots

When installing a 22110 SSD in M2_4 slot, a 2260 or 2280 SSD can be installed in M2_5 slot.




When installing a 2260 or 2280 SSD in M2_4 slot, a 2260, 2280, or 22110 SSD can be installed in M2_5 slot.




Installing M.2 module into M2_6 slot

1. Press and hold the end button of Screwless M.2 Shield Frozr heatsink.




2. Slightly lift up the end part of Screwless M.2 Shield Frozr heatsink and move it forward to uninstall the heatsink.




3. Remove the protective film from the M.2 thermal pads on the M.2 plate.




4. If you install 2260 SSD, use the included EZ M.2 Clip II Remover. Remove the plate screw and install EZ M.2 Clip II in the screw hole by using the remover. Skip this step if you install 2280 SSD.



- 5. Insert your M.2 SSD into the M.2 slot at a 30-degree angle.
- 6. Use the EZ M.2 Clip II to lock and secure the SSD.





- 7. Remove the protective films from the thermal pads under Screwless M.2 Shield Frozr heatsink.
- **8.** Align the plate on the front of Screwless M.2 Shield Frozr heatsink with the corresponding notch, and then put the heatsink back in place.
- 9. Press the end side of Screwless M.2 Shield Frozr heatsink to lock it completely.



SATA_5~8: SATA 6Gb/s Connectors

These connectors are SATA 6Gb/s interface ports. Each connector can connect to one SATA device.








! Important

- Please do not fold the SATA cable at a 90-degree angle. Data loss may result during transmission otherwise.
- SATA cables have identical plugs on either sides of the cable. However, it is recommended that the flat connector be connected to the motherboard for space saving purposes.

JAUD1: Front Audio Connector

This connector allows you to connect audio jacks on the front panel.






| Pin | Signal Name | Pin | Signal Name |
|-----|--------------|-----|----------------------|
| 1 | MIC L | 2 | Ground |
| 3 | MIC R | 4 | NC |
| 5 | Head Phone R | 6 | MIC Detection |
| 7 | SENSE_SEND | 8 | No Pin |
| 9 | Head Phone L | 10 | Head Phone Detection |

JFP1, JFP2: Front Panel Connectors

The JFP1 connector controls the power on, power reset, and the LEDs on your PC case/ chassis. Power Switch/ Reset Switch headers allow you to connect power button/ reset button. Power LED header connects to LED light on the PC case, and HDD LED header indicates the activity of the hard disk. The JFP2 connector is for Buzzer and Speaker. For connecting the cables from your PC case to the correct pins on the motherboard, please refer to the following images.






Make sure to connect the Power LED and HDD LED cables to the corresponding positive and negative pins on the motherboard. Otherwise, the LEDs will not function properly.

JTPM1: TPM Module Connector

This connector is designed for a Trusted Platform Module (TPM) to enable secure storage of sensitive data and perform cryptographic operations that ensure the integrity of your system.





| Pin | Signal Name | Pin | Signal Name |
|-----|-----------------------------------|-----|-----------------------------------|
| 1 | SPI Power | 2 | SPI Chip Select |
| 3 | Master In Slave Out (SPI Data) | 4 | Master Out Slave In (SPI Data) |
| 5 | Reserved | 6 | SPI Clock |
| 7 | Ground | 8 | SPI Reset |
| 9 | Reserved | 10 | No Pin |
| 11 | Reserved | 12 | Interrupt Request |




// Important

The TPM module is not included and must be purchased separately.

CPU_PWR1~2, ATX_PWR1, PCIE_PWR1, PD_PWR1, JSATA_PWR1: Power Connectors

These power connectors allow you to connect an ATX power supply.






CPU_PWR1~2



| Pin | Signal Name | Pin | Signal Name |
|-----|-------------|-----|-------------|
| 1 | Ground | 2 | Ground |
| 3 | Ground | 4 | Ground |
| 5 | +12V | 6 | +12V |
| 7 | +12V | 8 | +12V |

ATX_PWR1



| Pin | Signal Name | Pin | Signal Name |
|-----|-------------|-----|-------------|
| 1 | +3.3V | 2 | +3.3V |
| 3 | Ground | 4 | +5V |
| 5 | Ground | 6 | +5V |
| 7 | Ground | 8 | PWR OK |
| 9 | 5VSB | 10 | +12V |
| 11 | +12V | 12 | +3.3V |
| 13 | +3.3V | 14 | -12V |
| 15 | Ground | 16 | PS-ON# |
| 17 | Ground | 18 | Ground |
| 19 | Ground | 20 | Res |
| 21 | +5V | 22 | +5V |
| 23 | +5V | 24 | Ground |

PCIE_PWR1/PD_PWR1

PCIE_PWR1/ PD_PWR1



| Pin | Signal Name | Pin | Signal Name |
|-----|-------------|-----|-------------|
| 1 | +12V | 2 | +12V |
| 3 | +12V | 4 | SENS1 |
| 5 | Ground | 6 | SENS0 |
| 7 | Ground | 8 | Ground |

JSATA_PWR1

JSATA_PWR1



| Pin | Signal Name | Pin | Signal Name |
|-----|-------------|-----|-------------|
| 1 | +12V | 2 | +12V |
| 3 | +12V | 4 | +5V |
| 5 | +5V | 6 | Ground |
| 7 | Ground | 8 | Ground |
| 9 | Ground | 10 | Ground |



Important

Make sure that all the power cables are securely connected to a proper ATX power supply to ensure stable operation of the motherboard.

JSATA_PWR1 Connection

SATA power cable of power supply

Sub-SATA connector

Main-SATA connector

1 to 2 SATA Power Cable

JSATA_PWR1 connector of EZ CONTROL HUB




Important


If your power supply only has one free SATA power cable, always connect it to the Main-SATA connector first.

JBRG_HUB1: EZ Link Connectors

These connectors are specifically designed to connect EZ BRIDGE and EZ CONTROL HUB.



EZ BRIDGE & EZ CONTROL HUB Connection






Watch the video to learn how to connect the EZ BRIDGE and EZ CONTROL HUB.

• https://msi.gm/S6A0E6BB

JCI1: Chassis Intrusion Connector

This connector allows you to connect the chassis intrusion switch cable.



Using chassis intrusion detector


- 1. Connect the JCI1 connector to the chassis intrusion switch/ sensor on the chassis.
- 2. Close the chassis cover.
- 3. Go to BIOS > Security > Chassis Intrusion Configuration.
- 4. Set Chassis Intrusion to Enabled.
- 5. Press F10 to save and exit and then press the Enter key to select Yes.
- **6.** Once the chassis cover is opened again, a warning message will be displayed on screen when the computer is turned on.


Resetting the chassis intrusion warning

- 1. Go to BIOS > Security > Chassis Intrusion Configuration.
- 2. Set Chassis Intrusion to Reset.
- 3. Press F10 to save and exit and then press the Enter key to select Yes.

JUSBC2: USB 20Gbps Type-C Front Panel Connector


This USB connector allows you to connect to the USB Type-C® port on the front panel and supports data transfer speeds of up to 20Gbps. It features a user-friendly design that ensures proper orientation when connecting the cable.





JUSBC1: Thunderbolt™ 4 USB-C Front Panel Port


This port allows you to connect to the ThunderboltTM 4 USB-C port on the front panel and supports data transfer speeds of up to 40Gbps.



JUSB2~3: USB 5Gbps Connectors

These USB connectors allow you to connect to USB ports on the chassis panel and supports data transfer speeds of up to 5Gbps.





| Pin | Signal Name | Pin | Signal Name |
|-----|--------------|-----|--------------|
| 1 | Power | 2 | USB3_RX_DN |
| 3 | USB3_RX_DP | 4 | Ground |
| 5 | USB3_TX_C_DN | 6 | USB3_TX_C_DP |
| 7 | Ground | 8 | USB2.0- |
| 9 | USB2.0+ | 10 | Ground |
| 11 | USB2.0+ | 12 | USB2.0- |
| 13 | Ground | 14 | USB3_TX_C_DP |
| 15 | USB3_TX_C_DN | 16 | Ground |
| 17 | USB3_RX_DP | 18 | USB3_RX_DN |
| 19 | Power | 20 | No Pin |





Important

Note that the Power and Ground pins must be connected correctly to avoid possible damage.

JUSB1, JUSB_BRG_1: USB 2.0 Connectors

These connectors enable the connection of front-panel USB ports supporting speeds of up to $480\,\mathrm{Mbit/s}.$







| Pin | Signal Name | Pin | Signal Name |
|-----|-------------|-----|-------------|
| 1 | VCC | 2 | VCC |
| 3 | USB0- | 4 | USB1- |
| 5 | USB0+ | 6 | USB1+ |
| 7 | Ground | 8 | Ground |
| 9 | No Pin | 10 | NC |





\ Important

- Note that the VCC and Ground pins must be connected correctly to avoid possible damage.
- In order to recharge your iPad, iPhone and iPod through USB ports, please install MSI Center utility.

T_SEN1~2: Thermal Sensor Connectors


These connectors allow you to connect the thermistor cable and use it to monitor the temperature of the detection point.





JTBT5_1: Thunderbolt™ 5 Expansion Card Connector

This connector allows you to connect MSI Thunderbolt™ 5 Expansion Card.





| Pin | Signal Name | Pin | Signal Name |
|-----|---------------|-----|---------------|
| 1 | 5VDUAL | 2 | 5VDUAL |
| 3 | GPIO | 4 | GPIO |
| 5 | SLP_S3# | 6 | GPIO |
| 7 | SLP_S4# | 8 | No Pin |
| 9 | Ground | 10 | PD_EC_I2C_SCL |
| 11 | GPIO | 12 | PD_EC_I2C_SDA |
| 13 | GPIO | 14 | Ground |
| 15 | TBT_CARD_DET# | 16 | PD_EC_I2C_INT |
| 17 | GPIO | 18 | PS_ON# |

Thunderbolt™ 5 Expansion card

Specifications


| Chipset | Intel® JHL9580 Thunderbolt™ 5 Controller | |
|-----------------------|---|--|
| | 2x Thunderbolt™ 5(USB-C) ports Support up to 80Gbps transfer rate with Thunderbolt™ devices | |
| | Support up to 40Gbps transfer rate with USB4 devices Support up to 9V/3A,27W power charging | |
| External connector | Supports up to 8K display (need to connect the DisplayPort of the motherboard or discrete graphics card to the DisplayPort Input port on the Thunderbolt™ 5 card) | |
| | 2x DisplayPort Input ports | |
| | • 1x 18-pin TBT header | |
| | • 1x 6-pin power connector | |
| Interface | PCIe 4.0 x4 (depends on motherboard supportive slot) | |
| Form factor | • 5.2 inch x 4.11 inch (13.2 cm x 10.4 cm) | |

Installing Thunderbolt™ 5 Expansion card

- 1. Insert the Thunderbolt™ 5 Expansion card into the PCIe 4.0 x4 Thunderbolt™ supportive slot.
- 2. Connect JTBT5_1 connector of the Thunderbolt[™] 5 Expansion card to the motherboard. And connect the PCIE_PWR1 power connector to the power supply unit.
- 3. Attach the Thunderbolt[™] 5 Expansion card to the case bay using a screw.
- 4. Refer to the user manual of the motherboard for information on enabling Thunderbolt™ Technology in the BIOS.



- The Displayport signal input by DP1 can only be output via USBC1, and input by DP2 can only be output via USBC2.
- When use only one DisplayPort input, it is recommended to use DP1 as the priority input.



CPU_FAN1, PUMP_SYS1~2, SYS_FAN1~7: Fan Connectors


Fan connectors can be divided into two categories: PWM Mode and DC Mode. PWM Mode fan connectors provide a constant 12V output and adjust fan speed with a speed control signal. DC Mode fan connectors control fan speed by changing voltage. Please refer to the following specification table for the fan connector mode of your motherboard.

You can control fans in **BIOS> HARDWARE MONITOR** panel. Enabling Smart Fan Mode will regulate fan speed based on CPU or system temperature. Disabling Smart Fan Mode will set the fan to full speed.



Important

You can set DC or PWM in **HARDWARE MONITOR** panel to your fan type if your motherboard supports it. Make sure fans are working properly after switching the PWM/ DC mode.



PWM Mode pin definition

| Pin | Signal Name | Pin | Signal Name |
|-----|-------------|-----|----------------------|
| 1 | Ground | 2 | +12V |
| 3 | Sense | 4 | Speed Control Signal |

DC Mode pin definition

| Pin | Signal Name | Pin | Signal Name |
|-----|-------------|-----|-----------------|
| 1 | Ground | 2 | Voltage Control |
| 3 | Sense | 4 | NC |

Fan specifications for fan connectors

| Connector | Fan mode | Max. current | Max. power |
|----------------------|-----------|--------------|------------|
| CPU_FAN1 | Auto mode | 2A | 24W |
| PUMP_SYS1~2 PWM mode | | 3A | 36W |
| SYS_FAN1~7 Auto mode | | 1A | 12W |




Important

The auto mode fan connectors can automatically detect PWM and DC modes.

JDASH1: Tuning Controller connector

This connector is used to connect an optional Tuning Controller module.





| Pin | Signal Name | Pin | Signal Name |
|-----|---------------|-----|---------------|
| 1 | No Pin | 2 | NC |
| 3 | MCU_SMB_SCL_M | 4 | MCU_SMB_SDA_M |
| 5 | VCC5 | 6 | Ground |
| 7 | PSIN#_R | 8 | FP_RST#_R |
| 9 | NC | 10 | OC_FS |
| 11 | BLK+ | 12 | BLK- |
| 13 | CLRCMOS_EN | 14 | NC |

W_FLOW1: Water Flow Meter Connector

This connector allows you to connect a water flow meter to monitor the flow rate of your liquid cooling system.






| Pin | Signal Name | Pin | Signal Name |
|-----|-------------|-----|-------------|
| 1 | Ground | 2 | WFLOW PWR |
| 3 | WFLOW IN | | |

JLN1~2: Low Temperature Booting Jumper

These jumpers allow liquid nitrogen cooling system to boot at an extremely low temperature. Please try to enable the jumper to help the system boot successfully.






lmportant

- Please note that overclocking at an extremely low temperature carries the risk of system instability and may cause damages to the system.
- The overclocking results may vary depending on the CPU you use.
- Do not enable the jumper when the system is power off. Otherwise, the system will be unbootable.

JSLOW1: Slow Mode Booting Jumper

This jumper is used for LN2 cooling solution, that provides the extreme overclocking conditions, to boot at a stable processor frequency and to prevent the system from crashing.









(Please enable this jumper during BIOS POST.)

POWER1, RESET1: Power Button, Reset Button


The Power/ Reset button allows you to power on/ reset the computer.






V-Check Points Lite


These voltage checkpoints are used to measure the current system voltages. A multimeter (not included) will be required to check voltages. To measure voltage, place test leads on the GND (screw mounting hole) and a specific V-Check Point. Please refer to the manual of your multimeter for more information.






JOC_FS1: Safe Boot Jumper

This jumper is used for Safe Boot. When this jumper is enabled, the system will boot with default settings and lower PCIe (from CPU) mode.








JOC_RT1: OC Retry Button Connector


This connector allows you to connect a button. When you press and hold the button, the system will keep retrying OC items until it boot up successfully.







M.2 XPANDER-Z SLIDER GEN5 card



Specifications

| | • 2x M.2 slots (Key M) |
|---------------------|---|
| | Supports up to PCIe 5.0 x 4 (From CPU)* |
| Interface | Supports 2280 M.2 SSD** |
| | * The operating speed depends on the PCIe slot specification of your motherboard. |
| | ** Only support the M.2 SSD as the data disk. |
| | • 1x 6-pin ATX PCIe power connector |
| External connectors | • 1x Fan synchronous connector |
| Externat connectors | For connecting the system fan connector on the |
| | motherboard |
| Control | • 1x Fan switch |
| Switch | Turn on/ off the heatsink fan |
| | • 2x M.2 LED sets |
| 1.50 | Off - M.2 SSD is not detected |
| LEDs | Aqua blue - M.2 SSD has been detected |
| | Blue blinking - M.2 SSD is accessing data |
| Form Factor | • 242 x 135 x 18.57 mm |




Important


- This card does not support the M.2 SSD with the heatsink.
- This card does not support M.2 enclosure hot-plug.
- The M.2 SSDs in this card are exclusively for data storage.

Install the M.2 SSD & Xpander-Z Slider Gen 5 card

- 1. Unlock the M.2 enclosure side cover.
- 2. Hold the side cover and pull the M.2 enclosure out.



- 3. Unlock the M.2 enclosure top cover.
- 4. Lift the cover and move it forward to uninstall it.
- **5.** Remove the protective film from the thermal pad inside the M.2 enclosure.






Watch the video to learn how to install the M.2 XPANDER-Z SLIDER GEN5 card.

• https://msi.gm/SBC78842

6. Please ensure the notch position of the M.2 SSD contacts to correctly install the M.2 SSD into the M.2 enclosure.







Important

All contacts of the M.2 SSD must be fully exposed after you install the M.2 SSD.


- 7. Remove the protective film from the bottom of the top cover.
- **8.** Reinstall the top cover back and ensure it be locked.



- 9. Align the alignment marks on the M.2 enclosure and M.2 bracket. Install the M.2 enclosure back into the slot until it is locked in place.
- 10. Push the M.2 side cover back to lock the M.2 enclosure.



- 11. Install the XPANDER-Z SLIDER GEN5 card into the PCIe slot on the motherboard.
- 12. Connect the PCIE_PWR1 connector to the power supply.






Important

If the system fails to detect the M.2 SSD, please attempt to replace the thermal pad. We provide thermal pads in two varying thicknesses. To ensure a successful connection with the M.2 SSD, please select the appropriate thickness based on your M.2 SSD requirement.

BIOS SW1: Multi-BIOS Switch

This motherboard has two built-in BIOS ROMs. If one is crashed, you can shift to the other for booting by sliding the switch.







\) Important

- Do not use the Multi-BIOS switch when system is booting up.
- You can also use the MSI Center or Flash BIOS Button to flash BIOS. Please refer to BIOS section for details.

JDASH_SW1: EZ BRIDGE Switch

This switch is used to switch between EZ BRIDGE & Tuning Controller module.





JRGB1: RGB LED connector


The JRGB connector allows you to connect the 5050 RGB LED strips 12V.






| Pin | Signal Name | Pin | Signal Name |
|-----|-------------|-----|-------------|
| 1 | +12V | 2 | G |
| 3 | R | 4 | В |

RGB LED Strip Connection



RGB LED Fan Connection







Important

- The JRGB connector supports up to 2 meters continuous 5050 RGB LED strips (12V/G/R/B) with the maximum power rating of 3A (12V).
- Always turn off the power supply and unplug the power cord from the power outlet before installing or removing the RGB LED strip.
- Please use MSI's software to control the extended LED strip.
- Please make sure you insert the RGB connector the right way. Plugging it in backward could damage it.

JARGB_V2_1~3: A-RAINBOW V2 (ARGB Gen2) LED connectors


The JARGB_V2 connectors allow you to connect the ARGB Gen2 and the ARGB-based LED strips. The JARGB_V2 connector supports up to 240 individually addressable RGB LEDs with maximum power rating of 3A (5V).






| Pin | Signal Name | Pin | Signal Name |
|-----|-------------|-----|-------------|
| 1 | +5V | 2 | Data |
| 3 | No Pin | 4 | Ground |

Addressable RGB LED Strip Connection



Addressable RGB LED Fan Connection





CAUTION

Do not connect the wrong type of LED strips. The JRGB connector and the JARGB_V2 connector provide different voltages, and connecting the ARGB 5V LED strip to the JRGB connector will result in damage to the LED strip.




Important


- If you connect the ARGB Gen1 and ARGB Gen2 LED strips into the same connector, it may cause some issues. Please do not mix the ARGB Gen1 LED and the ARGB Gen2 LED strips together.
- It is recommended that you install LED strips with the same specification to achieve the best effects.
- Always turn off the power supply and unplug the power cord from the power outlet before installing or removing the addressable RGB LED strip.
- Please use MSI's software to control the extended LED strip.

JAF_2: EZ Conn-Header V2


This header allows you to connect the ARGB Gen1 and Gen2 LED strips, fans and USB 2.0 devices. It can also be used to connect MPG EZ120 ARGB fans.



Addressable RGB LED Fan Connection



MPG EZ120 ARGB Fan Connection






! Important

- The Fan-JAF1 Cable is included in the packaging of MPG EZ120 ARGB.
- JAF_2 header is compatible with JAF_1 header since pins 1 to 7 carry the same signals. MPG EZ120 ARGB can be connected to the JAF_2 header.
- For more information on how to install MPG EZ120 ARGB, please refer to https://msi. gm/S5035E56.

Onboard LEDs

EZ Debug LED


These LEDs indicate the debug status of the motherboard.



| LED Color | Status |
|-----------|--|
| Red 📕 | CPU is not detected or fail |
| Yellow 🗌 | DRAM is not detected or fail |
| White □ | GPU is not detected or fail |
| Green 🔲 | Booting device is not detected or fail |


JPWRLED1: LED power input


This connector is used by retailers to demonstrate onboard LED lights.



LED_SW1: EZ LED Control

This switch is used to switch on/ off all the LEDs on the motherboard.





DYNAMIC DASHBOARD III

The DYNAMIC DASHBOARD III, a TFT LCD panel, is located on the EZ BRIDGE. It can display system status, temperatures, voltages, BIOS flash status and error messages. You can use MSI Center to configure and customize the displays of the DYNAMIC DASHBOARD III and even upload a .gif/.bmp/.png/.jpg or .mp4 animation file.

Booting screen

DYNAMIC DASHBOARD III will display the progress and error codes during booting and POST. Please refer to the following Debug Code LED table for details.



Main screen

Before installing MSI Center, the main screen of DYNAMIC DASHBOARD III will display some default information as Fig.1 below.

After installing MSI Center, you can configure the hardware monitoring data in MSI Center to be displayed as the main screen of DYNAMIC DASHBOARD III.



Fig.1

DYNAMIC DASHBOARD III Status Table

| System Status | DYNAMIC DASHBOARD III | System Status | DYNAMIC DASHBOARD III |
|--|---|--------------------------|---|
| Power On | A≡G. Endert des | Hardware Monitor page | COV 1048 AVA REPORT 1048 AVA SETTE 1048 AVA COVER 119 |
| CPU/ DDR is not detected or fail | DPU Error DR Error | Flash BIOS (Update) | Updating |
| Graphics card is not detected or fail | VGR Error GENERAL Distant Problem | System Clock page | Z4:00 August 01 |
| S4/S5 (Suspend to Disk/ Shutdown) S3 (Suspend to Ram) | | User profile | 1800*480px.gif/ Ibmp/ jpg/ png/ mp4 |



1mportant

To take full advantage of DYNAMIC DASHBOARD III, you should to install MSI Center and then install the DYNAMIC DASHBOARD APP within MSI Center (MSI Center > Feature Sets > DYNAMIC DASHBOARD).

Debug Code LED Table

The Debug Code LED displays progress and error codes during and after POST. Refer to the Debug Code LED table for details.

SEC Progress Codes

| 01 | Power on. Reset type detection (soft/hard) |
|----|--|
| 02 | AP initialization before microcode loading |
| 03 | System Agent initialization before microcode loading |
| 04 | PCH initialization before microcode loading |
| 06 | Microcode loading |
| 07 | AP initialization after microcode loading |
| 08 | System Agent initialization after microcode loading |
| 09 | PCH initialization after microcode loading |
| ОВ | Cache initialization |

SEC Error Codes

| 0C - 0D | Reserved for future AMI SEC error codes |
|---------|---|
| 0E | Microcode not found |
| 0F | Microcode not loaded |

PEI Progress Codes

| 10 | PEI Core is started |
|---------|---|
| 11 | Pre-memory CPU initialization is started |
| 12 - 14 | Pre-memory CPU initialization (CPU module specific) |
| 15 | Pre-memory System Agent initialization is started |
| 16 - 18 | Pre-Memory System Agent initialization (System Agent module specific) |
| 19 | Pre-memory PCH initialization is started |
| 1A - 1C | Pre-memory PCH initialization (PCH module specific) |
| 2B | Memory initialization. Serial Presence Detect (SPD) data reading |
| 2C | Memory initialization. Memory presence detection |
| 2D | Memory initialization. Programming memory timing information |
| 2E | Memory initialization. Configuring memory |

| 2F | Memory initialization (other) |
|---------|--|
| 31 | Memory Installed |
| 32 | CPU post-memory initialization is started |
| 33 | CPU post-memory initialization. Cache initialization |
| 34 | CPU post-memory initialization. Application Processor(s) (AP) initialization |
| 35 | CPU post-memory initialization. Boot Strap Processor (BSP) selection |
| 36 | CPU post-memory initialization. System Management Mode (SMM) initialization |
| 37 | Post-Memory System Agent initialization is started |
| 38 - 3A | Post-Memory System Agent initialization (System Agent module specific) |
| 3B | Post-Memory PCH initialization is started |
| 3C - 3E | Post-Memory PCH initialization (PCH module specific) |
| 4F | DXE IPL is started |

PEI Error Codes

| 50 | Memory initialization error. Invalid memory type or incompatible memory speed |
|---------|---|
| 51 | Memory initialization error. SPD reading has failed |
| 52 | Memory initialization error. Invalid memory size or memory modules do not match |
| 53 | Memory initialization error. No usable memory detected |
| 54 | Unspecified memory initialization error |
| 55 | Memory not installed |
| 56 | Invalid CPU type or Speed |
| 57 | CPU mismatch |
| 58 | CPU self test failed or possible CPU cache error |
| 59 | CPU micro-code is not found or micro-code update is failed |
| 5A | Internal CPU error |
| 5B | Reset PPI is not available |
| 5C - 5F | Reserved for future AMI error codes |

DXE Progress Codes

| 60 | DXE Core is started |
|---------|--|
| 61 | NVRAM initialization |
| 62 | Installation of the PCH Runtime Services |
| 63 | CPU DXE initialization is started |
| 64 - 67 | CPU DXE initialization (CPU module specific) |
| 68 | PCI host bridge initialization |
| 69 | System Agent DXE initialization is started |
| 6A | System Agent DXE SMM initialization is started |
| 6B - 6F | System Agent DXE initialization (System Agent module specific) |
| 70 | PCH DXE initialization is started |
| 71 | PCH DXE SMM initialization is started |
| 72 | PCH devices initialization |
| 73 - 77 | PCH DXE Initialization (PCH module specific) |
| 78 | ACPI module initialization |
| 79 | CSM initialization |
| 7A - 7F | Reserved for future AMI DXE codes |
| 90 | Boot Device Selection (BDS) phase is started |
| 91 | Driver connecting is started |
| 92 | PCI Bus initialization is started |
| 93 | PCI Bus Hot Plug Controller Initialization |
| 94 | PCI Bus Enumeration 32 |
| 95 | PCI Bus Request Resources |
| 96 | PCI Bus Assign Resources |
| 97 | Console Output devices connect |
| 98 | Console input devices connect |
| 99 | Super IO Initialization |
| 9A | USB initialization is started |

| 9B | USB Reset |
|---------|---|
| 9C | USB Detect |
| 9D | USB Enable |
| 9E -9F | Reserved for future AMI codes |
| A0 | IDE initialization is started |
| A1 | IDE Reset |
| A2 | IDE Detect |
| A3 | IDE Enable |
| A4 | SCSI initialization is started |
| A5 | SCSI Reset |
| A6 | SCSI Detect |
| A7 | SCSI Enable |
| A8 | Setup Verifying Password |
| A9 | Start of Setup |
| AB | Setup Input Wait |
| AD | Ready To Boot event |
| AE | Legacy Boot event |
| AF | Exit Boot Services event |
| В0 | Runtime Set Virtual Address MAP Begin |
| B1 | Runtime Set Virtual Address MAP End |
| B2 | Legacy Option ROM Initialization |
| В3 | System Reset |
| B4 | USB hot plug |
| B5 | PCI bus hot plug |
| В6 | Clean-up of NVRAM |
| В7 | Configuration Reset (reset of NVRAM settings) |
| B8 - BF | Reserved for future AMI codes |

DXE Error Codes

| D0 | CPU initialization error |
|----|---|
| D1 | System Agent initialization error |
| D2 | PCH initialization error |
| D3 | Some of the Architectural Protocols are not available |
| D4 | PCI resource allocation error. Out of Resources |
| D5 | No Space for Legacy Option ROM |
| D6 | No Console Output Devices are found |
| D7 | No Console Input Devices are found |
| D8 | Invalid password |
| D9 | Error loading Boot Option (LoadImage returned error) |
| DA | Boot Option is failed (StartImage returned error) |
| DB | Flash update is failed |
| DC | Reset protocol is not available |

S3 Resume Progress Codes

| E0 | S3 Resume is stared (S3 Resume PPI is called by the DXE IPL) |
|---------|--|
| E1 | S3 Boot Script execution |
| E2 | Video repost |
| E3 | OS S3 wake vector call |
| E4 - E7 | Reserved for future AMI progress codes |

S3 Resume Error Codes

| E8 | S3 Resume Failed |
|---------|-------------------------------------|
| E9 | S3 Resume PPI not Found |
| EA | S3 Resume Boot Script Error |
| EB | S3 OS Wake Error |
| EC - EF | Reserved for future AMI error codes |

Recovery Progress Codes

| F0 | Recovery condition triggered by firmware (Auto recovery) |
|---------|--|
| F1 | Recovery condition triggered by user (Forced recovery) |
| F2 | Recovery process started |
| F3 | Recovery firmware image is found |
| F4 | Recovery firmware image is loaded |
| F5 - F7 | Reserved for future AMI progress codes |

Recovery Error Codes

| F8 | Recovery PPI is not available |
|---------|-------------------------------------|
| F9 | Recovery capsule is not found |
| FA | Invalid recovery capsule |
| FB - FF | Reserved for future AMI error codes |

ACPI States Codes

The following codes appear after booting and the operating system into ACPI modes.

| 01 | System is entering S1 sleep state |
|----|---|
| 02 | System is entering S2 sleep state |
| 03 | System is entering S3 sleep state |
| 04 | System is entering S4 sleep state |
| 05 | System is entering S5 sleep state |
| 10 | System is waking up from the S1 sleep state |
| 20 | System is waking up from the S2 sleep state |
| 30 | System is waking up from the S3 sleep state |
| 40 | System is waking up from the S4 sleep state |
| AC | System has transitioned into ACPI mode. Interrupt controller is in PIC mode. |
| AA | System has transitioned into ACPI mode. Interrupt controller is in APIC mode. |

CPU Temperature

| Displays current CPU temperature after the system has fully booted into the OS. |
|---|
| tile 03. |

Installing OS, Drivers & MSI Center

Please download and update the latest utilities and drivers at www.msi.com

Installing Windows 11

- 1. Power on the computer.
- 2. Insert the Windows 11 installation disc/ USB into your computer.
- 3. Press the **Restart** button on the computer case.
- Press F11 key during the computer POST (Power-On Self Test) to get into Boot Menu.
- 5. Select the Windows 11 installation disc/USB from the Boot Menu.
- Press any key if screen shows Press any key to boot from CD or DVD... message. If not, please skip this step.
- 7. Follow the instructions on the screen to install Windows 11.

Installing Drivers with MSI Driver Utility Installer




Important

- Some new network chips have not been natively supported by Windows 11. It is recommended that the LAN driver be installed before installing drivers with MSI Driver Utility Installer. Please refer to www.msi.com to install the LAN driver for your motherboard.
- The MSI Driver Utility Installer will only pop up once. If you cancel or close it during the process, please refer to the Live Update chapter of the MSI Center manual to install the drivers. You can also go to www.msi.com to search your motherboard and download the drivers.
- MSI Driver Utility Installer needs to be installed over the internet.
- 1. Start up your computer in Windows 11.
- 2. Select Start > Settings > Windows Update, and then select Check for updates.
- 3. MSI Driver Utility Installer will pop up automatically.



 Select the I have read and agree to the MSI Terms of Use check box, and then click Next.



Check the Select All checkbox in the lower-left corner and click Install to install MSI Center and drivers. The installation progress will be shown at the bottom.



6. Once the progress has completed, click Finish.

MSI Center

MSI Center is an application that helps you easily optimize game settings and smoothly use content creation softwares. It also allows you to control and synchronize LED light effects on PCs and other MSI products. With MSI Center, you can customize ideal modes, monitor system performance, and adjust fan speed.

MSI Center User Guide



回路線回 If you would like to know more information about MSI Center, please refer to https://msi.gm/S391169E

or scan the QR code to access.



Important

Functions may vary depending on the product you have.

UFFI BIOS

MSI UEFI BIOS is compatible with UEFI (Unified Extensible Firmware Interface) architecture. UEFI has many new functions and advantages that traditional BIOS cannot achieve, and it will completely replace BIOS in the future. The MSI UEFI BIOS uses UEFI as the default boot mode to take full advantage of the new chipset's capabilities.



🖺 Important

The term BIOS in this user guide refers to UEFI unless otherwise noted.

UEFI advantages

- Fast booting UEFI can directly boot the operating system and save the BIOS self-test process.
- Supports for hard drive partitions larger than 2 TB.
- Supports more than 4 primary partitions with a GUID Partition Table (GPT).
- Supports unlimited number of partitions.
- Supports full capabilities of new devices new devices may not provide backward compatibility.
- Supports secure startup UEFI can check the validity of the operating system to ensure that no malware tampers with the startup process.

Incompatible UEFI cases

- 32-bit Windows operating system this motherboard supports only Windows 11 64-bit operating system.
- Older graphics card the system will detect your graphics card. If you use older graphics cards, it may display a warning message There is no GOP (Graphics Output protocol) support detected in this graphics card.



Important

We recommend that you replace it with a graphics card supporting GOP/UEFI or use CPU with integrated graphics for having normal function.

BIOS Setup

The default settings offer the optimal performance for system stability in normal conditions. You should always keep the default settings to avoid possible system damage or failure booting unless you are familiar with BIOS.



掛 Important

- BIOS items are continuously updated for better system performance. Therefore, the description may be slightly different from the latest BIOS and should be for reference only. You could also refer to the **HELP** information panel in BIOS.
- The BIOS screens, options and settings will vary depending on the products you have.

BIOS User Guide



回路就回 If you'd like to know more instructions on setting up the BIOS, please refer to https://msi.gm/S1154EEB or scan the QR code to access.



/ Important

The appearance of the BIOS user guide may differ based on your motherboard model. Please refer to your motherboard's BIOS for specific settings and options.

Entering BIOS Setup

Press Delete key, when the Press DEL key to enter Setup Menu, F11 to enter Boot Menu message appears on the screen during the boot process.

Function key

+/ -: Incress / decreas the value

Enter: Select the item

ESC: Exit

Tab: Next selection

Ctrl+PageUp: Go to previous main menu **Ctrl+PageDown:** Go to next main menu

Ctrl+F: Enter Search menu **F1**: General Help list

F2: Add/ Remove a favorite item

F3: Enter Favorites menu

F4: Enter CPU core center & memory center information menu

F5: Enter Hardware Monitor menu

F6: Load optimized defaults

F7: Switch between Advanced mode and EZ mode


F8: Enter Overclocking Profile menu

F10: Save Change and Reset*

F12: Take a screenshot and save it to USB flash drive (FAT/ FAT32 format only).

How to find the BIOS version?

After entering the BIOS, find the BIOS version in the information box.



^{*} Pressing **F10** displays a confirmation message summarizing your changes. Select **Yes** or **No** to confirm.

Resetting BIOS

If you encounter certain issues with your computer, restoring the default BIOS settings might help. You can reset the BIOS settings using the following methods:

- Enter the BIOS setup and press **F6** to load the optimized defaults.
- Use the Clear CMOS jumper on the motherboard to reset the BIOS.
- If your motherboard has a Clear CMOS button on the rear I/O panel, press it to reset the BIOS.



Ensure the computer is powered off before clearing the CMOS data. For more details, refer to the Clear CMOS jumper/button section in the manual.

Updating BIOS

Updating BIOS with M-FLASH

Before starting the M-Flash process, make sure you have:

• A USB flash drive with a capacity of 32GB or less that is formatted to FAT32.



/!\ Important

M-Flash only supports FAT32 format, and the USB flash drive should not exceed 32GB.

A computer with internet access.

Please follow the steps below to update BIOS:

- 1. Download the latest BIOS file from the MSI website that matches your motherboard model, and save it to the USB flash drive.
- 2. If your motherboard has a Multi-BIOS switch, switch to the target BIOS ROM.
- 3. Insert the USB flash drive into your motherboard's USB port.
- 4. Enter flash mode by either:
 - Rebooting and pressing Ctrl + F5 during POST, then clicking Yes to reboot the
 - Rebooting and pressing Del during POST to enter BIOS, then clicking the M-FLASH button and clicking Yes to reboot.
- 5. Select a BIOS file from the M-FLASH File menu and press Enter.
- **6.** When prompted by a File Check message, click **Yes** to start the BIOS update.

Once the update reaches 100%, the system will reboot automatically.

Updating BIOS with MSI Center

Before updating:

- Ensure the LAN driver is installed, and the internet connection is working properly.
- Close all other applications before updating the BIOS.

To update BIOS:

- 1. Install and launch MSI Center, then go to **Support** page.
- 2. Select Live Update and click on Advance button.
- 3. Select the BIOS file and click on Install button.
- 4. The installation reminder will appear, then click the **Install** button.

The system will automatically restart to update the BIOS. Once the flashing process is complete, the system will restart.


Updating BIOS with Flash BIOS Button

- Download the latest BIOS file from the MSI website that matches your motherboard model.
- Rename the BIOS file to MSI.ROM, and save it to the root directory of a USB flash device.
- 3. Connect the power supply to CPU_PWR1 and ATX_PWR1. (You don't need to install the CPU and memory.)
- **4.** Plug the USB flash device with the **MSI.ROM** file into the **Flash BIOS Port** on the rear I/O panel.
- 5. Press the Flash BIOS Button to start flashing the BIOS. The LED will start flashing to indicate the process has begun.

The LED will turn off when the process is complete.

Block Diagram

MEG Z890 GODLIKE



Regulatory Notices

FCC-B Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and radiates radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

NOTE

- The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- Shield interface cables and AC power cord, if any, must be used in order to comply with the emission limits.

FCC Conditions

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

MSI Computer Corp.

901 Canada Court, City of Industry, CA 91748, USA (626)913-0828

www.msi.com

CE Conformity

Products bearing the CE marking comply with one or more of the following EU Directives as may be applicable:

- RED 2014/53/EU
- Low Voltage Directive 2014/35/EU
- EMC Directive 2014/30/EU
- RoHS Directive 2011/65/EU
- ErP Directive 2009/125/EC

Compliance with these directives is assessed using applicable European Harmonized Standards.

The point of contact for regulatory matters is MSI-Europe: Eindhoven 5706 5692 ER Son.

Products with Radio Functionality (EMF)

This product incorporates a radio transmitting and receiving device. For computers in normal use, a separation distance of 20 cm ensures that radio frequency exposure levels comply with EU requirements. Products designed to be operated at closer proximities, such as tablet computers, comply with applicable EU requirements in typical operating positions. Products can be operated without maintaining a separation distance unless otherwise indicated in instructions specific to the product.

Restrictions for Products with Radio Functionality



CAUTION: IEEE 802.11x wireless LAN with 5.15~5.35 GHz frequency band is restricted for indoor use only in all European Union member states, EFTA (Iceland, Norway, Liechtenstein), and most other European countries (e.g., Switzerland, Turkey, Republic of Serbia). Using this WLAN application outdoors might lead to interference issues with existing radio services.



Radio frequency bands and maximum power levels

- Features: Wi-Fi 7, BT
- Frequency Range: 2.4 GHz: 2400~2485MHz; 5 GHz: 5150~5350MHz, 5470~5725MHz. 5725~5850MHz: 6 GHz: 5955~6415MHz
- Max Power Level: 2.4 GHz: 20dBm; 5 GHz: 23dBm; 6 GHz: 23dBm



Wireless Radio Use

This device is restricted to indoor use when operating in the 2.4GHz, 5GHz, 6GHz frequency band.

Cet appareil doit être utilisé à l'intérieur.

당해 무선설비는 운용중 전파혼신 가능성이 있음.

この製品は、周波数帯域 2.4GHz, 5GHz, 6GHz で動作しているときは、屋内においてのみ使用可能です。

NCC無線設備警告聲明

工作頻率2.4GHz, 5GHz, 6GHz該頻段限於室內使用。

經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻電機之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。前項合法通信,指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

Compliance Statement of Innovation, Science and Economic Development Canada (ISED)

This device complies with with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

CAN ICES-003(B)/NMB-003(B)

Australia and New Zealand notice

This equipment incorporates a radio transmitting and receiving device. In normal use, a separation distance of 20 cm ensures that radio frequency exposure levels comply with the Australian and New Zealand Standards.

クラスB情報技術装置

この装置は、クラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。取扱説明書に従って正しい取り扱いをして下さい。

VCCI-B

KC인증서

상호: (주)엠에스아이코리아

제품명: 메인보드 모델명: 10-7E21 제조년월: 2024년

R-R-MSI-10-7E21 제조자 및 제조국가: MSI/중국

KC인증서

상호: (주)엠에스아이코리아 제품명: USB FLASH DRIVE 모델명: USB3VR09

제조년월: 2024년 R-R-MSI-USB3VR09 제조자 및 제조국가: MSI/중국

KC인증서



상호: (주)엠에스아이코리아

제품명: M.2 XPANDER-Z SLIDER GEN5

모델명: 10-4494 제조년월: 2024년

R-R-MSI-10-4494 제조자 및 제조국가: MSI/중국

KC인증서



상호: (주)엠에스아이코리아 제품명: EZ CONTROL HUB

모델명: 10-4491 제조년월: 2024년

R-R-MSI-10-4491 제조자 및 제조국가: MSI/중국

KC인증서



상호: (주)엠에스아이코리아 제품명: THUNDERBOLTM5

모델명: 10-4498 제조년월: 2024년

R-R-MSI-10-4498 제조자 및 제조국가: MSI/중국

Battery Information

European Union:



Batteries, battery packs, and accumulators should not be disposed of as unsorted household waste. Please use the public collection system to return, recycle, or treat them in compliance with the local regulations.

BSMI:



廢電池請回收

For better environmental protection, waste batteries should be collected separately for recycling or special disposal.

California, USA:



The button cell battery may contain perchlorate material and requires special handling when recycled or disposed of in California.

For further information please visit:

https://dtsc.ca.gov/perchlorate/

AWARNING

- INGESTION HAZARD: This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours.
- KEEP new and used batteries OUT OF REACH OF CHILDREN
- Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.



- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death. Call a local poison control center for treatment information.
- Battery type: CR2032
- Battery voltage: 3V
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- This product contains an irreplaceable battery.
- This icon indicates that a swallowed button battery can cause serious injury or death. Please keep batteries out of sight or reach of children.

Chemical Substances Information

In compliance with chemical substances regulations, such as the EU REACH Regulation (Regulation EC No. 1907/2006 of the European Parliament and the Council), MSI provides the information of chemical substances in products at:

https://csr.msi.com/global/index

Environmental Policy

- The product has been designed to enable proper reuse of parts and recycling and should not be thrown away at its end of life.
- Users should contact the local authorized point of collection for recycling and disposing of their end-of-life products.



- Visit the MSI website and locate a nearby distributor for further recycling information.
- Users may also reach us at gpcontdev@msi.com for information regarding proper Disposal, Take-back, Recycling, and Disassembly of MSI products.

WEEE (Waste Electrical and Electronic Equipment) Statement

ENGLISH

To protect the global environment and as an environmentalist, MSI must remind you that...

Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2002/96/EC, which takes effect on August 13, 2005, products of "electrical and electronic equipment" cannot be discarded as municipal wastes anymore, and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life. MSI will comply with the product take back requirements at the end of life of MSI-branded products that are sold into the EU. You can return these products to local collection points.

DEUTSCH

Hinweis von MSI zur Erhaltung und Schutz unserer Umwelt

Gemäß der Richtlinie 2002/96/EG über Elektro- und Elektronik-Altgeräte dürfen Elektro- und Elektronik-Altgeräte nicht mehr als kommunale Abfälle entsorgt werden. MSI hat europaweit verschiedene Sammel- und Recyclingunternehmen beauftragt, die in die Europäische Union in Verkehr gebrachten Produkte, am Ende seines Lebenszyklus zurückzunehmen. Bitte entsorgen Sie dieses Produkt zum gegebenen Zeitpunkt ausschliesslich an einer lokalen Altgerätesammelstelle in Ihrer Nähe.

FRANÇAIS

En tant qu' écologiste et afin de protéger l'environnement, MSI tient à rappeler ceci... Au sujet de la directive européenne (EU) relative aux déchets des équipement électriques et électroniques, directive 2002/96/EC, prenant effet le 13 août 2005,

que les produits électriques et électroniques ne peuvent être déposés dans les décharges ou tout simplement mis à la poubelle. Les fabricants de ces équipements seront obligés de récupérer certains produits en fin de vie. MSI prendra en compte cette exigence relative au retour des produits en fin de vie au sein de la communauté

européenne. Par conséquent vous pouvez retourner localement ces matériels dans les points de collecte.

РУССКИЙ

Компания MSI предпринимает активные действия по защите окружающей среды, поэтому напоминаем вам, что....

В соответствии с директивой Европейского Союза (ЕС) по предотвращению загрязнения окружающей среды использованным электрическим и электронным оборудованием (директива WEEE 2002/96/ЕС), вступающей в силу 13 августа 2005 года, изделия, относящиеся к электрическому и электронному оборудованию, не могут рассматриваться как бытовой мусор, поэтому производители вышеперечисленного электронного оборудования обязаны принимать его для переработки по окончании срока службы. МSI обязуется соблюдать требования по приему продукции, проданной под маркой MSI на территории ЕС, в переработку по окончании срока службы. Вы можете вернуть эти изделия в специализированные пункты приема.

ESPAÑOL

MSI como empresa comprometida con la protección del medio ambiente, recomienda: Bajo la directiva 2002/96/EC de la Unión Europea en materia de desechos y/o equipos electrónicos, con fecha de rigor desde el 13 de agosto de 2005, los productos clasificados como "eléctricos y equipos electrónicos" no pueden ser depositados en los contenedores habituales de su municipio, los fabricantes de equipos electrónicos, están obligados a hacerse cargo de dichos productos al termino de su período de vida. MSI estará comprometido con los términos de recogida de sus productos vendidos en la Unión Europea al final de su periodo de vida. Usted debe depositar estos productos en el punto limpio establecido por el ayuntamiento de su localidad o entregar a una empresa autorizada para la recogida de estos residuos.

NEDERLANDS

Om het milieu te beschermen, wil MSI u eraan herinneren dat....

De richtlijn van de Europese Unie (EU) met betrekking tot Vervuiling van Electrische en Electronische producten (2002/96/EC), die op 13 Augustus 2005 in zal gaan kunnen niet meer beschouwd worden als vervuiling. Fabrikanten van dit soort producten worden verplicht om producten retour te nemen aan het eind van hun levenscyclus. MSI zal overeenkomstig de richtlijn handelen voor de producten die de merknaam MSI dragen en verkocht zijn in de EU. Deze goederen kunnen geretourneerd worden op lokale inzamelingspunten.

SRPSKI

Da bi zaštitili prirodnu sredinu, i kao preduzeće koje vodi računa o okolini i prirodnoj sredini, MSI mora da vas podesti da...

Po Direktivi Evropske unije ("EU") o odbačenoj ekektronskoj i električnoj opremi, Direktiva 2002/96/EC, koja stupa na snagu od 13. Avgusta 2005, proizvodi koji spadaju pod "elektronsku i električnu opremu" ne mogu više biti odbačeni kao običan otpad i proizvođači ove opreme biće prinuđeni da uzmu natrag ove proizvode na kraju njihovog uobičajenog veka trajanja. MSI će poštovati zahtev o preuzimanju ovakvih proizvoda kojima je istekao vek trajanja, koji imaju MSI oznaku i koji su prodati u EU. Ove proizvode možete vratiti na lokalnim mestima za prikupljanje.

POLSKI

Aby chronić nasze środowisko naturalne oraz jako firma dbająca o ekologię, MSI przypomina, że...Zgodnie z Dyrektywą Unii Europejskiej ("UE") dotyczącą odpadów produktów elektrycznych i elektronicznych (Dyrektywa 2002/96/EC), która wchodzi w życie 13 sierpnia 2005, tzw. "produkty oraz wyposażenie elektryczne i elektroniczne " nie mogą być traktowane jako śmieci komunalne, tak więc producenci tych produktów będą zobowiązani do odbierania ich w momencie gdy produkt jest wycofywany z użycia. MSI wypełni wymagania UE, przyjmując produkty (sprzedawane na terenie Unii Europejskiej) wycofywane z użycia. Produkty MSI będzie można zwracać w wyznaczonych punktach zbiorczych.

TÜRKÇE

Çevreci özelliğiyle bilinen MSI dünyada çevreyi korumak için hatırlatır: Avrupa Birliği (AB) Kararnamesi Elektrik ve Elektronik Malzeme Atığı, 2002/96/ EC Kararnamesi altında 13 Ağustos 2005 tarihinden itibaren geçerli olmak üzere, elektrikli ve elektronik malzemeler diğer atıklar gibi çöpe atılamayacak ve bu elektonik cihazların üreticileri, cihazların kullanım süreleri bittikten sonra ürünleri geri toplamakla yükümlü olacaktır. Avrupa Birliği'ne satılan MSI markalı ürünlerin kullanım süreleri bittiğinde MSI ürünlerin geri alınması isteği ile işbirliği içerisinde olacaktır. Ürünlerinizi yerel toplama noktalarına bırakabilirsiniz.

ČESKY

Záleží nám na ochraně životního prostředí - společnost MSI upozorňuje...

Podle směrnice Evropské unie ("EU") o likvidaci elektrických a elektronických výrobků 2002/96/EC platné od 13. srpna 2005 je zakázáno likvidovat "elektrické a elektronické výrobky" v běžném komunálním odpadu a výrobci elektronických výrobků, na které se tato směrnice vztahuje, budou povinni odebírat takové výrobky zpět po skončení jejich životnosti. Společnost MSI splní požadavky na odebírání výrobků značky MSI, prodávaných v zemích EU, po skončení jejich životnosti. Tyto výrobky můžete odevzdat v místních sběrnách.

MAGYAR

Annak érdekében, hogy környezetünket megvédjük, illetve környezetvédőként fellépve az MSI emlékezteti Önt, hogy ...

Az Európai Unió ("EU") 2005. augusztus 13-án hatályba lépő, az elektromos és elektronikus berendezések hulladékairól szóló 2002/96/EK irányelve szerint az elektromos és elektronikus berendezések többé nem kezelhetőek lakossági hulladékként, és az ilyen elektronikus berendezések gyártói kötelessé válnak az ilyen termékek visszavételére azok hasznos élettartama végén. Az MSI betartja a termékvisszavétellel kapcsolatos követelményeket az MSI márkanév alatt az EU-n belül értékesített termékek esetében, azok élettartamának végén. Az ilyen termékeket a legközelebbi gyűjtőhelyre viheti.

ITALIANO

Per proteggere l'ambiente, MSI, da sempre amica della natura, ti ricorda che....

In base alla Direttiva dell' Unione Europea (EU) sullo Smaltimento dei Materiali Elettrici ed Elettronici, Direttiva 2002/96/EC in vigore dal 13 Agosto 2005, prodotti appartenenti alla categoria dei Materiali Elettrici ed Elettronici non possono più essere eliminati come rifiuti municipali: i produttori di detti materiali saranno obbligati a ritirare ogni prodotto alla fine del suo ciclo di vita. MSI si adeguerà a tale Direttiva ritirando tutti i prodotti marchiati MSI che sono stati venduti all' interno dell' Unione Europea alla fine del loro ciclo di vita. È possibile portare i prodotti nel più vicino punto di raccolta

日本JIS C 0950材質宣言

日本工業規格JIS C 0950により、2006年7月1日以降に販売される特定分野の電気および電子機器について、製造者による含有物質の表示が義務付けられます。

https://csr.msi.com/tw/Japan-JIS-C-0950-Material-Declarations

India RoHS

This product complies with the "India E-waste (Management and Handling) Rule 2011" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for the exemptions set in Schedule 2 of the Rule.

Türkiye EEE yönetmeliği

Türkiye Cumhuriyeti: EEE Yönetmeliğine Uygundur

Україна обмеження на наявність небезпечних речовин

Обладнання відповідає вимогам Технічного регламенту щодо обмеження використання деяких небезпечних речовин в електричному та електронному обладнані, затвердженого постановою Кабінету Міністрів України від 3 грудня 2008 № 1057.

Việt Nam RoHS

Kể từ ngày 01/12/2012, tất cả các sản phẩm do công ty MSI sản xuất tuân thủ Thông tư số 30/2011/TT-BCT quy định tạm thời về giới hạn hàm lượng cho phép của một số hóa chất độc hại có trong các sản phẩm điện, điện tử"

MS-7E21主板产品中有害物质的名称及含量

| | 有害物质 | | | | | | |
|-------------|------|------|------|----------|-------|--------|--|
| 部件名称 | 铅 | 汞 | 镉 | 六价铬 | 多溴联苯 | 多溴二苯醚 | |
| | (Pb) | (Hg) | (Cd) | (Cr(VI)) | (PBB) | (PBDE) | |
| 印刷电路板组件* | X | 0 | 0 | 0 | 0 | 0 | |
| 纽扣电池 | 0 | 0 | 0 | 0 | 0 | 0 | |
| 外部信号连接头 | X | 0 | 0 | 0 | 0 | 0 | |
| 其他 (例: 线材等) | X | 0 | 0 | 0 | 0 | 0 | |

本表格依据 SJ/T 11364 的规定编制。

- \bigcirc : 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。
- ※: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求,但所有部件都符合欧盟RoHS要求。
- * 印刷电路板组件:包括印刷电路板及其构成的零部件。
- 上述有毒有害物质或元素清单会依型号之部件差异而有所增减。
- 产品部件本体上如有环保使用期限标识,以本体标识为主。

限用物質含有情況標示聲明書

| 設備名稱:電腦主 | 幾板 | 型號(型式):MS-7E21 | | | | | |
|----------|------------|----------------|-----------|----------------------------|---------------|-----------------|--|
| | 限用物質及其化學符號 | | | | | | |
| 單元 | 鉛 (Pb) | 汞 (Hg) | 鎘 (Cd) | 六價鉻 (Cr ⁺⁶) | 多溴聯苯 (PBB) | 多溴二苯醚 (PBDE) | |
| 電路板 | 0 | 0 | 0 | 0 | 0 | 0 | |
| 電子元件 | _ | 0 | 0 | 0 | 0 | 0 | |
| 金屬機構件 | _ | 0 | 0 | 0 | 0 | 0 | |
| 塑膠機構件 | 0 | 0 | 0 | 0 | 0 | 0 | |

備考1. "超出 $0.1\,\mathrm{wt}$ %" 及 "超出 $0.01\,\mathrm{wt}$ %" 係指限用物質之百分比含量超出百分比含量基準值。

備考2. "○"係指該項限用物質之百分比含量未超出百分比含量基準值。

備考3. "─" 係指該項限用物質為排除項目。

| 設備名稱: USB 3.2 Gen1 隨身碟 型號(型式): VR09 3.2 Gen 1 | | | | | | | |
|---|------------|-----------|-----------|----------------------------|---------------|-----------------|--|
| | 限用物質及其化學符號 | | | | | | |
| 單元 | 鉛 (Pb) | 汞 (Hg) | 鎘 (Cd) | 六價鉻 (Cr ⁺⁶) | 多溴聯苯 (PBB) | 多溴二苯醚 (PBDE) | |
| 儲存裝置 | _ | 0 | 0 | 0 | 0 | 0 | |
| 黑色內襯(塑件) | 0 | 0 | 0 | 0 | 0 | 0 | |
| 隨身碟外殼 | 0 | 0 | 0 | 0 | 0 | 0 | |

備考1. "超出0.1 wt %" 及 "超出0.01 wt %" 係指限用物質之百分比含量超出百分比含量基準值。

備考2. "〇" 係指該項限用物質之百分比含量未超出百分比含量基準值。

備考3. "─" 係指該項限用物質為排除項目。

Copyright and Trademarks Notice







Copyright © Micro-Star Int' I Co., Ltd. All rights reserved. The MSI logo used is a registered trademark of Micro-Star Int' I Co., Ltd. All other marks and names mentioned may be trademarks of their respective owners. No warranty as to accuracy or completeness is expressed or implied. MSI reserves the right to make changes to this document without prior notice.



The terms HDMI™, HDMI™ High-Definition Multimedia Interface, HDMI™ Trade dress and the HDMI™ Logos are trademarks or registered trademarks of HDMI™ Licensing Administrator, Inc.

Technical Support

If a problem arises with your system and no solution can be obtained from the user guide, please contact your place of purchase or local distributor. Alternatively, please try the following help resources for further guidance.

- Visit the MSI website for technical guide, BIOS updates, driver updates, and other information: http://www.msi.com
- Register your product at: http://register.msi.com

Revision History

• Version 1.0, 2024/11, First release.

