



H6

Dual Channel Trail camera

Users Manual

Overview

Thank you for choosing REXING! We hope you love your new products as much as we do.

If you need assistance, or have any suggestions to improve it, please contact us. You can reach us via care@rexingusa.com or call us at (203) 800 - 4466. Our support team will respond you as soon as possible.

Always a surprise in Rexing. Check us out here.

<https://www.facebook.com/rexingusa/>

<https://www.instagram.com/rexingdashcam/>

<https://www.rexingusa.com/support/registration/>

Facebook



Instagram



Site



Product Support



Contents

Camera Overview.....	3
Basic Operation.....	5
Setup Menu.....	6
Take Photos & Record Video.....	14
Playback.....	20

Introduction

Congratulations on the purchase of your new device. You have selected a high-quality product. The operating instruction is one constituent of this product. It contains important information about safety, use and disposal. Before using the product, familiarise yourself with all operating and safety instructions. Use this product only as described and only for the specified areas of application.

Copyright

This documentation is subject to copyright protection. Any copying or reproduction, including extracts thereof, and the reproduction of images (even in a modified state), is only permitted with the written authorisation of the manufacturer.

Intended Use

This device is intended only for recording digital photos and videos, particularly for observing wildlife. It is not intended for any other use or for uses extending beyond those stated. This device is not intended for use in commercial or industrial environments.

The manufacturer accepts no responsibility for damage caused by failure to observe these instructions, improper use, incompetent repairs, making unauthorised.

modifications or for using unapproved replacement parts.

The operator alone bears liability.

When the equipment will be placed in the outdoor filming, rapid changes in the weather could lead to error record.

Safety

Please read below safety precautions carefully before using the camera.

- Do not try to disassemble the product case. Only authorized technician can repair the product.
- The camera will be hot after using for too long time. This is normal.
- Please use the accessory provided by our factory.

Camera Overview

1.Display Screen

2.Up/Video Button

3.Shot Button

4.Right Button

5.OK Button

6.Speaker

7.Menu Button

8.Left Button

9.Playback Button


10.Down/Photo Button

11.Micro SD Card Slot


12.AV Jack

13.USB Jack

14.OFF-TEST-ON Mode Button



- 15. Infrared LEDs
- 16. Day Camera
- 17. Front Motion Sensor
- 18. Side Motion Sensor
- 19. Status Indicator
- 20. Night Camera



Power Supply

Please install batteries before using the camera.

- ◆ Open the camera case and remove the battery cover.

Install 8 pieces of 1.5V AA batteries. Please make sure the electrode is correct.

Storage Media

Please prepare a Micro SD card and insert it into the camera for saving more files.

- ◆ Support Micro SD card, up to 512GB.
- ◆ To avoid malfunction, the memory card should be far away water, strong vibration, dust, hot source and direct sunlight.
- ◆ Do not insert the memory card forcibly. Please refer to the marking on the camera.
- ◆ For the first time use, please wait a moment. The camera will be short-circuit, caused by the change of environment's temperature and humidity.
- ◆ If the capacity of memory card is full, the camera will stop recording automatically and the LED lights off.
- ◆ Press the edge of the SD card gently to pop-up the TF card.

Basic Operation

Turn On And Off The Camera

Switch the Mode Button to "Test/On" to turn on the camera.

Switch the Mode Button to “Off” to turn off the camera.

System Setup

Switch Mode Button to “Test”, then you can set the camera's parameters as your need.

1. Press Video/Photo button to switch the two modes.
2. Press Menu button to open the setup menu.
3. Press Up/Down button to scan all menu. Then press OK button to enter the options interface.
4. Press Up/Down button to scan all options. And press OK button to confirm options.
5. Press Menu button again to turn back to last menu or exit the setup menu.

Tips before running the camera

1. ♦ Please make sure the SD card has been inserted
2. ♦ Please install the batteries.

Setup Menu

Mode

Set the working mode. In capture mode, the camera just take pictures. In Video mode, the camera just record video. In capture&video mode, the camera will take a photo first, then start to record video.

Options: **【Photo】 / 【Video】 / 【Photo&Video】** .

Day Photo Resolution

Set the still image resolution.

Options: **【20MP(5200x3900P)】 / 【16MP(4608x3456P)】 / 【12MP(4000x3000P)】 / 【8MP(3264x2448P)】 / 【5MP(2592x1944P)】 / 【3MP(2048x1536P)】 / 【1MP(1280x960P)】** .

Night Photo Resolution

Set the still image resolution.

Options: **【(1920x1080P)】 / 【1280x720P)】 / 【640x480P)】** .

Photo Series

Set the photo number of continuous shooting. In photo mode, the camera will take photos continuously.

Options: 【1 photo】 / 【2 photos in series】 / 【3 photos in series】 / 【10 photos in series】 .

Day Video Resolution

Set the video resolution. The bigger the resolution is ,the longer the video time can be stored.

Options: 【3840x2160P】 / 【2688x1520P】 / 【1920x1080P】 / 【1280x720P】 / 【1280x720P 60FPS】 / 【848x480P】 / 【720x480P】 / 【640x480P】 / 【320x240P】 .

Night Video Resolution

Set the video resolution. The bigger the resolution is ,the longer the video time can be stored.

Options: 【1920x1080P】 / 【1280x720P】 / 【640x480P】 .

Day TL Video Resolution

Set the resolution of time lapse video .

Options: 【5200x3900P】 / 【4608x3456P】 / 【4416x3312P】 / 【4000x3000P】 / 【3648x2736P】 / 【3264x2448P】 / 【3072x2304P】 / 【2592x1944P】 / 【2048x1536P】 .

Night TL Video Resolution

Set the resolution of time lapse video .

Options: 【1920x1080P】 / 【1280x720P】 .

Video Length

Set the duration of recording a video clip. The shortest time is 3 seconds and the longest time is 10 minutes.

Options: 3 seconds~10 minutes.

Audio Recording

Open this function,the camera will record audio when recording video.

Options: 【On】 / 【Off】 .

Shot Lag

Set the time of delay shooting when the camera detects the motion. Within the selected time, the camera will not record any image or video. It can avoid to store too much same events and save more capacity.

Options: 5 seconds~60 minutes.

Side Motion Sensors

Open/close the side motion sensors.

Options: 【On】 / 【Off】 .

Sensitivity Motion Sensors

Set the sensitivity of the sensors. Environmental impact is small indoors, you can choose “Low” . In outdoor, choose “Middle” in normal condition. Choose “High” if the environment impact is huge outdoors. The temperature can also influence the sensor sensitivity. “High Sensitivity” applies to mild environment. “ Low Sensitivity ” applies to cold environment.

Options: 【Low】 / 【Middle】 / 【High】 .

Target Recording Time

Set the target recording time . As shown in below picture, you can set the start and stop time. The camera will work just in the stated time slot. In other time, the camera will keep in standby state.


Options: 【On】 / 【Off】 .

Set			
Target recording time			
Start:		Stop:	
Hr:	Min	Hr:	Min
00	00	00	00
MENU Back		OK Select	

Time Lapse

In Time lapse menu, there are three options as below.

[Normal]: The camera will take pictures automatically as per set time interval. For example, set the interval time to 1 hour, the camera will take a photo each hour. If you want to observe that a plant blooms, the camera will take 24 photos in 24 hours to record the whole process of blooming.



[TL Video]: You can set the interval time. The time range is from 1 second to 24 hours. For example, set the interval to 1 hour, the camera will take a photo each hour. If the camera works for 24 hours, there will be 24 photos. These photos will be converted into a video.

[Off]: Close the time lapse function.

Language

Set the language display on screen.

Options: **【English】 / 【Deutsch】 / 【Dansk】 / 【Suomi】 / 【Svenska】 【español】 / 【French】 / 【Italian】 /**

【Nederlands】 / 【Portuguese】 / 【Simplified Chinese】 /
【Traditional Chinese】 / 【Japanese】 .

Endless Capture

Set the camera to record video in loop,it will loop shooting, the earliest document will be deleted when the card is nearly full, infinite loop.

Options: 【On】 / 【Off】 .

Time & Date

Set the date and time of camera.

The date format: dd/mm/yyyy, yyyy/mm/dd, mm/dd/yyyy.

The time format: 24h, 12h.

Press Left/Right button to choose the item.Press Up/Down button to adjust the value. And press OK button to confirm.

Options: 【Set time&date】 / 【Time format】 / 【Date format】 .

Photo Stamp

Stamp the date&time on the photos or not.

Options: 【Time&date】 / 【Date】 / 【Off】 .

Password Protection

Set the power-on password of the camera. The password is four digits, each digit ranges from 0 to 9 or A to Z.

If you forget the password, please reset the camera. Then all parameters will reset to the factory settings re-flash.

Options: **【On】 / 【Off】** .

Beep Sound

Open/close the button sound.

Options: **【On】 / 【Off】** .

Format Memory Card

Formatting the memory card will delete all data permanently. Before using a new memory card or a card that has been used in another device previously ,please format the memory card.

Options: **【Yes】 / 【No】** .

Serial NO.

Set the unique serial number for the camera. The number is four digits, each digit ranges from 0 to 9 or A to Z.

Options: **【On】 / 【Off】** .

Reset Settings

Restore the camera to factory default settings including password,serial number and so on. All settings will be deleted.

Options: **【Yes】 / 【No】** .

Version

Look up the Firmware information of the camera.

Take Photos,Record Video,Playback

Switch the Mode Button to “Test”. (if the camera is turned on in a bright environment, the day camera will be turned on; if the camera is turned on in a dark environment, the night camera will be turned on).In this mode,you can take photos, record video and playback files manually.

◆ **Take Photos**: Press Photo button to switch to photo mode. Press Shot button to take a picture.

◆ **Record Video**: Press Video button to switch to video mode.Press Shot button to start to record a video clip. Press Shot button again to stop recording.

◆ **Playback**: Press Playback button to enter the playback interface. Press Up/Down button to scan photos or video. When playback video, press OK button to play the video. Press OK button again to have a pause. Press Menu button to stop playback. Press Playback button again to exit the playback mode.

Playback Menu:

- 1) **Delete current file**: Delete the current photo or video. Options: **【Cancel】 / 【Delete】** .
- 2) **Delete all files**: Delete all photo and video files in the memory card. Options: **【Cancel】 / 【Delete】** .
- 3) **Activate slide show**: Playback the photos in slide way. Each photo display 3 seconds. Press OK button to stop playing.
- 4) **Write protect**: Lock the file. It can avoid accident deletion. Options: **【Write-protect current file】 / 【Write-protect all files】 / 【Unlock current file】 / 【Unlock all files】** .

Aligning the camera

In test mode you can adjust the optimum exposure angle and the range of the motion sensors .During alignment, consider whether the use of the side motion sensors may be useful for attaining the desired observation results. You can activate/deactivate the side motion sensors using the above-described menu.

Please adjust the camera as follows:

1. Fasten the camera to a tree or similar object at a height of 1–2 meters and align the camera in the desired direction. Then move slowly from one side of the target area to the other side. While doing this, monitor the motion display.

2. If this lights turn green, you are detected by one of the activated side motion sensors . If lights turn red, you are detected by the front motion sensor . By this way, you can align the camera to the best angle and distance.

Working Mode

Switch the Mode Button to “On”. After turn on the camera, the screen will display 15 seconds countdown. Then the LEDs and screen will go out. The camera begins to operate independently and enter standby mode.

If the wild animals enter the detection range of the motion sensors , the camera will be activated and detect the motion trail.

If the wild animals continue to move to the detection zone of the sensor, The camera will be activated immediately, and according to the working mode set in the menu, take photo or video or take photo + video, after shooting, the camera will return to standby mode; the camera will delay the interval according to the motion sensing set in the menu Time, waiting for the next sensor trigger and shooting.

Day mode

In the daytime or in a brighter environment, the camera automatically turns on the daytime camera to shoot high-

resolution color images with normal brightness during the day.

Night Mode

At night or in a dark environment, the camera will automatically turn on the night camera, and infrared LEDs will turn on automatically to provide necessary light for taking pictures. This makes it possible to take pictures at a distance about 3m to 20m without overexposing at night. However, reflective objects such as traffic signs can cause overexposure if they are located within the recording range.

In night mode, the pictures just can display white and black but it can shoot high-brightness, high-definition, low-noise images in a dark environment at night..

When record a video for long time in the evening, the low voltage may have a great influence on the stability of the machine. Do not record video with low voltage in the evening.

Using the wall bracket

You can mount the camera permanently on a wall or tree using the supplied wall bracket. Before mounting the wall

bracket you should ensure that all existing screws are tight. The best installation height distance from the ground about 1 meter.

Components

1. Tripod screw
2. Lock nut
3. Pivot bolts
4. Drill holes
5. Hexagonal screw
6. Wall plugs
7. Screws



Mounting the wall bracket

Required tools

- Drill
- 6 mm masonry/concrete drill bit
- Phillips head screwdriver

CAUTION

► Ensure that there are no electric lines, water or heating pipes installed at the proposed drilling location.

► The supplied wall plugs are only suitable for mounting on concrete and stone. Before starting the installation, please check your installation location carefully for its suitability for the plugs.

The assembly material used must be suitable for the respective location. If in doubt, consult a professional.

Install Steps

- ◆ Mark the drill holes by holding the foot of the wall bracket at the desired mounting location and marking the hole positions.
- ◆ Use a drill with a 6 mm drill bit to drill the required holes and insert the plugs and insert the wall plugs flush with the wall.
- ◆ Screw the wall bracket to the wall using the supplied screws .
- ◆ Mount the camera on the tripod screw and screw the camera a little way on (about three turns).
- ◆ Turn the camera in the desired direction and lock it with the lock nut .
- ◆ To move the camera into its final position, undo the two pivot bolts a little, position the camera and fix the position by tightening the two pivot bolts .

Connecting To TV

The camera can transfer the video signal to an external monitor or a television. Please follow below instructions to operate.

1. Connect the camera to the TV via provided AV cable.
2. Turn on the TV and set it to AV mode.
3. Turn on the camera, switch the Mode Button to "Test".
4. Once connection is successful, the camera will enter playback mode and the screen turn black. The image will show on the TV.

Download Files To The Computer

There are two ways to download files from the memory card to a computer:

- ❖ By inserting the memory card into a card reader
- ❖ By connecting the camera to a computer using the supplied USB cable.

Using a Card Reader

1. Pop-up the memory card from the camera and insert it into a card reader. Then connect the card reader to a computer.
2. Open [My Computer] or [Windows Explorer] and double-

click the removable disk icon that represents the memory card.

3. Copy image or video files from the memory card to your computer.

Connecting the Camcorder to a PC by the USB Cable

1. Connect the camera to the computer via USB cable. Turn on the camera, the screen will display "MSDC".

2. Open [My Computer] or [Windows Explorer].

A "Removable Disk" appears in the drive list. Double-click the "Removable Disk" icon to view its contents. All files are stored in the folder named "DCIM".

3. Copy the photos or files to your computer.