




### 3 TURNING ON MY TV


#### When can I turn on my TV?

##### WHEN YOUR TV IS IN PLACE:


- 1 Plug one end of the power cord into **AC IN** of your TV.



- 2 Plug into a power outlet.




- 3 Remove the remote cover and install the batteries.




**Tip:** Always replace dead batteries with two brand-new AAA batteries from the same manufacturer. Never use damaged batteries. If your remote gets hot during use, stop using and contact customer support immediately.

### 4 COMPLETE GUIDED SETUP

#### How do I activate my Pioneer Roku TV?

- 1 Press  on your remote.
- 2 Follow the on-screen instructions on your Pioneer Roku TV by using your computer or smartphone to link to a Roku account. If you are not ready to connect to the internet now, you can still use your TV to view content accessible through other connected input sources.

**Note:** When powering on the TV for the very first time, the Guided Setup screens will guide you through the Wi-Fi setup steps.



**Note:** Wi-Fi set up screens may change.

## FREQUENTLY ASKED QUESTIONS


#### Why do I need an internet connection?

You will need an internet connection to stream your favorite apps and for automatic software updates.

#### Why should I enter a payment method?

Saving a payment method makes it easy to rent or buy movies, subscribe to popular channels, and start free trials in just a click. No charges will be made without your authorization. Roku never charges for activation.

To reduce the risk of fire or electric shock, do not remove any cover or expose the device to rain or moisture. No user-serviceable parts are inside. We recommend referring servicing to a qualified service technician.



This symbol indicates that dangerous voltage constituting a risk of electric shock is present within your TV. This label is located on the back of your TV.




This symbol indicates that there are important operating and maintenance instructions in the literature accompanying your TV.

#### SERVICING

Servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock, we recommend you do not perform any servicing other than that contained in the operating instructions, unless you are qualified to do so.

## USING YOUR REMOTE



#### Access the Pioneer TV User Guide

Access the online *User Guide*. Go to [www.usca.pioneer-tv.com](http://www.usca.pioneer-tv.com) and search for your model number. Many questions regarding parts, service, and warranties can be answered by visiting the Support section of our website: [www.usca.pioneer-tv.com](http://www.usca.pioneer-tv.com).

#### Access the Roku TV User Guide

Visit [go.roku.com/tvmanual](http://go.roku.com/tvmanual) for details.

#### Contact Pioneer TV Customer Support Center:

1-888-287-7658 (U.S. or Canada)

#### One-Year Limited Warranty

Visit [www.bestbuy.com](http://www.bestbuy.com) for details.

#### Need Additional help?

Check out our Support Community at [www.bestbuy.com](http://www.bestbuy.com) for helpful information from other Insignia TV owners.

#### We're Here For You

[www.bestbuy.com](http://www.bestbuy.com)

For customer service, call: 1-877-467-4289 (U.S./Canada)



The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress, and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 1992-2019 Dolby Laboratories. All rights reserved.

PIONEER and the Pioneer logo are registered trademarks of Pioneer Corporation, and are used under license.

Not all apps and content available in LED TV (UHD).

Roku, Roku TV, the Roku logo, and the purple d-pad design are the trademarks or registered trademarks of Roku, Inc. in the United States and other countries. All other trademarks and logos herein are the property of their respective owners.

Distributed and warranted by Best Buy Purchasing LLC  
7601 Penn Avenue South, Richfield, MN 55423 USA  
©2025 Best Buy. All rights reserved.