



USER'S MANUAL

SMOKE & CARBON MONOXIDE ALARM 10-YEAR SEALED BATTERY Model SMC10110



IMPORTANT! PLEASE READ CAREFULLY AND SAVE.

The warnings/limitations card and manual contains important information about your Smoke Alarm's operation. If you are installing this Alarm for use with the others, you must leave this manual—or a copy of it—with the end user.

Para el manual del usuario en español, por favor visite firstalert.com

- ▲ WARNING!**
 - This unit will not alert hearing impaired residents. It is recommended that you install specific units which use devices like flashing strobe lights to alert hearing impaired residents.
 - Do not connect this unit to any other Alarm or auxiliary device. It is a single-station unit that cannot be linked to other devices. Connecting anything else to this unit may prevent it from working properly.
 - This unit will not operate without battery power. The Smoke Alarm cannot work until you activate the battery power pack.

- ▲ CAUTION!**
 - Do not install this unit over an electrical junction box. Air currents around junction boxes can prevent smoke from reaching the sensing chamber and prevent the unit from alarming. Only AC powered units are intended for installation over junction boxes.
 - Do not stand too close to the unit when the Alarm is sounding. It is loud to wake you in an emergency. Exposure to the unit at close range may harm your hearing.
 - Do not paint over the unit. Paint may plug the openings to the sensing chamber and prevent the unit from operating properly.

01 INTRODUCTION

Thank you for choosing First Alert® for your Smoke and Carbon Monoxide Alarm needs. You have purchased a state-of-the-art Smoke & Carbon Monoxide Alarm designed to help provide you with early warning of a smoke and/or carbon monoxide danger. Please take the time to read this manual and make the Smoke & Carbon Monoxide Alarm an integral part of your family's safety plan.

BASIC SAFETY INFORMATION

- IMPORTANT!**
 - Dangers, Warnings, and Cautions alert you to important operating instructions or to potentially hazardous situations. Pay special attention to these items.
 - This Smoke/CO Alarm is approved for use in single-family residences. It is **NOT** designed for marine or RV use.

- ▲ CAUTION!**
 - This combination Smoke/Carbon Monoxide Alarm has two separate Alarms. The CO Alarm is not designed to detect fire or any other gas. It will only indicate the presence of carbon monoxide gas at the sensor. Carbon monoxide gas may be present in other areas. The Smoke Alarm will only indicate the presence of smoke that reaches the sensor. The Smoke Alarm is not designed to sense gas, heat or flames.

- ▲ WARNING!**
 - NEVER** ignore any Alarm. See "If Your Smoke/CO Alarm Sounds" for more information on how to respond to an Alarm. Failure to respond can result in injury or death.
 - The Silence Features are for your convenience only and will not correct a problem. See "Using the Silence Features" for details. Always check your home for a potential problem after any Alarm. Failure to do so can result in injury or death.
 - Test this Smoke/CO Alarm once a week. If the Alarm ever fails to test correctly, have it replaced immediately! If the Alarm is not working properly, it cannot alert you to a problem.

02 ABOUT SMOKE ALARMS

TYPES OF ALARMS

All these Smoke Alarms are designed to provide early warning of fires if located, installed and cared for as described in the user's manual, and if smoke reaches the Alarm. If you are unsure which type of Smoke Alarm to install, refer the National Fire Protection Association (NFPA) Standard 72 (National Fire Alarm and Signaling code) and NFPA 101 (Life Safety Code), National Fire Protection Association, One Batterymarch Park, Quincy, MA 02269-9101. Local building codes may also require specific units in new construction or in different areas of the home.

Battery (DC) operated Smoke Alarms: Provide protection even when electricity fails, provided the batteries are fresh and correctly installed. Units are easy to install, and do not require professional installation. They do not, however, provide interconnected functionality.

AC powered Smoke Alarms: Can be interconnected so if one unit senses smoke, all units Alarm. They do not operate if electricity fails.

AC with battery (DC) back-up: will operate if electricity fails, provided the batteries are fresh and correctly installed. AC and AC/DC units must be installed by a qualified electrician.

Wireless interconnected Alarms: Offer the same interconnected functionality as with hardwired Alarms, without wires. Units are easy to install and do not require professional installation. They provide protection even when electricity fails, provided the batteries are fresh and correctly installed.

Smoke Alarms for solar or wind energy users and battery backup power systems: AC powered Smoke Alarms should only be operated with true or pure sine wave inverters. Operating this Smoke Alarm with most batterypowered UPS (uninterruptible power supply) products or square wave or "quasi sine wave" inverters will damage the Alarm. If you are not sure about your inverter or UPS type, please consult with the manufacturer to verify.

Smoke Alarms for the hearing impaired: Special purpose Smoke Alarms should be installed for the hearing impaired. They include a visual Alarm and an audible Alarm horn, and meet the requirements of the Americans With Disabilities Act. These units can be interconnected so if one unit senses smoke, all units Alarm.

Smoke Alarms are not to be used with detector guards unless the combination has been evaluated and found suitable for that purpose.

All First Alert® Smoke Alarms conform to regulatory requirements, including UL217 and are designed to detect particles of combustion. Smoke particles of varying number and size are produced in all fires.

Ionization technology is generally more sensitive than photoelectric technology at detecting small particles, which tend to be produced in greater amounts by flaming fires, which consume combustible materials rapidly and spread quickly. Sources of these fires may include paper burning in a wastebasket, or a grease fire in the kitchen.

Photoelectric technology is generally more sensitive than ionization technology at detecting large particles, which tend to be produced in greater amounts by smoldering fires, which may smolder for hours before bursting into flame. Sources of these fires may include cigarettes burning in couches or bedding.

For maximum protection, use both types of Smoke Alarms on each level and in every bedroom of your home.

03 INSTALLATION

WHERE TO INSTALL THIS ALARM

Minimum coverage for Smoke Alarms, as recommended by the National Fire Protection Association (NFPA), is one Smoke Alarm on every floor, in every sleeping area, and in every bedroom (See "Regulatory Information For Smoke Alarms" for details on the NFPA recommendations).

For CO Alarms, the National Fire Protection Association (NFPA) recommends that a CO Alarm should be centrally located outside of each separate sleeping area in the immediate vicinity of the bedrooms. For added protection, install additional CO Alarms in each separate bedroom, and on every level of your home.

NOTE: For added protection, install an additional Smoke/CO Alarm at least 15 feet (4.6 meters) away from the furnace or fuel burning heat source where possible. In smaller homes or in many detached homes where this distance cannot be maintained, install the Alarm as far away as possible from the furnace or other fuel burning source. Installing the Alarm closer than 15 feet (4.6 meters) will not harm the Alarm, but may increase the frequency of unwanted Alarms.

IN GENERAL, INSTALL COMBINATION SMOKE AND CARBON MONOXIDE ALARMS:

- On every level of your home, including finished attics and basements.
- Inside every bedroom, especially if people sleep with the door partly or completely closed.
- In the hall near every sleeping area. If your home has multiple sleeping areas, install a unit in each. If a hall is more than 40 feet (12 meters) long, install a unit at each end.
- At the top of first-to-second floor stairs.
- At the bottom of the basement stairs.
- For additional coverage, install Alarms in all rooms, halls, and storage areas, where temperatures normally remain between 40° F and 100° F (4.4° C and 37.8° C).

RECOMMENDED PLACEMENT:



Smoke Alarm
On every level and in every bedroom

Carbon Monoxide Alarm
On every level and in every bedroom

Fire Extinguisher
On every level, plus kitchen and garage

- When installing on the wall, the top edge of Smoke Alarms should be placed between 4 inches (102 mm) and 12 inches (305 mm) from the wall/ceiling line.
- When installing on the ceiling, place the Alarm as close to the center as possible.
- In either case, install at least 4 inches (102 mm) from where the wall and ceiling meet.

NOTE: For any location, make sure no door or other obstruction could keep carbon monoxide or smoke from reaching the Alarm.

WHERE NOT TO INSTALL THIS ALARM

FOR BEST PERFORMANCE, IT IS RECOMMENDED YOU AVOID INSTALLING SMOKE/CO ALARMS IN THESE AREAS:

- In garages, furnace rooms, crawl spaces and unfinished attics. Avoid extremely dusty, dirty or greasy areas.
- Where combustion particles are produced. Combustion particles form when something burns. Areas to avoid include poorly ventilated kitchens, garages, and furnace rooms. Keep units at least 20 feet (6 meters) from the sources of combustion particles (stove, furnace, water heater, space heater) if possible. In areas where a 20-foot (6 meter) distance is not possible—in modular, mobile, or smaller homes, for example—it is recommended the Smoke Alarm be placed as far from these fuel-burning sources as possible. The placement recommendations are intended to keep these Alarms at a reasonable distance from a fast-burning source, and thus reduce "unwanted" Alarms. Unwanted Alarms can occur if a Smoke Alarm is placed directly next to a fuel-burning source. Ventilate these areas as much as possible.
- Within 5 feet (1.5 meters) of any cooking appliance, in air streams near kitchens. Air currents can draw cooking smoke into the smoke sensor and cause unwanted Alarms.
- In extremely humid areas. This Alarm should be at least 10 feet (3 meters) from a shower, sauna, humidifier, vaporizer, dishwasher, laundry room, utility room, or other source of high humidity.
- In direct sunlight.
- In turbulent air, like near ceiling fans or open windows. Blowing air may prevent CO or smoke from reaching the sensors.
- In areas where temperature is colder than 40° F (4.4° C) or hotter than 100° F (37.8° C). These areas include non-airconditioned crawl spaces, unfinished attics, uninsulated or poorly insulated ceilings, porches, and garages.
- In insect infested areas. Insects can clog the openings to the sensing chamber.
- Less than 12 inches (305 mm) away from fluorescent lights. Electrical "noise" can interfere with the sensor.
- In "dead air" spaces.

AVOIDING DEAD AIR SPACES

"Dead air" spaces may prevent smoke from reaching the Smoke/CO Alarm. To avoid dead air spaces, follow installation recommendations below.

On ceilings, install Smoke/CO Alarms as close to the center of the ceiling as possible. If this is not possible, install the Smoke/CO Alarm at least 4 inches (102 mm) from the wall or corner.

For wall mounting (if allowed by building codes), the top edge of Smoke/CO Alarms should be placed between 4 inches (102 mm) and 12 inches (305 mm) from the wall/ceiling line.

On a peaked, gabled, or cathedral ceiling, install the first Smoke/CO Alarm within 3 feet (0.9 meters) of the peak of the ceiling, measured horizontally. Additional Smoke/CO Alarms may be required depending on the length, angle, etc. of the ceiling's slope. Refer to NFPA 72 for details on requirements for sloped or peaked ceilings.

HOW TO INSTALL THIS ALARM

This unit is designed to be mounted on the ceiling, or on the wall if necessary.

Tools you will need: pencil, drill with 3/16" (5 mm) drill bit, standard flathead screwdriver, hammer.

THE PARTS OF THIS SMOKE/CO ALARM

A Smoke/CO LED (RED)

B Power LED (GREEN)

C Test/Silence button

1 Mounting Bracket

2 Locking pins (break out of bracket)

3 Mounting Slots

4 Turn this way to remove

5 Turn this way to attach

6 Mounting Hole Sides

7 Test the Smoke Alarm. See "Weekly Testing"

8 Mounting Hole Sides

9 Mounting Hole Sides

10 Mounting Hole Sides

11 Mounting Hole Sides

12 Mounting Hole Sides

13 Mounting Hole Sides

14 Mounting Hole Sides

15 Mounting Hole Sides

16 Mounting Hole Sides

17 Mounting Hole Sides

18 Mounting Hole Sides

19 Mounting Hole Sides

20 Mounting Hole Sides

21 Mounting Hole Sides

22 Mounting Hole Sides

23 Mounting Hole Sides

24 Mounting Hole Sides

25 Mounting Hole Sides

26 Mounting Hole Sides

27 Mounting Hole Sides

28 Mounting Hole Sides

29 Mounting Hole Sides

30 Mounting Hole Sides

31 Mounting Hole Sides

32 Mounting Hole Sides

33 Mounting Hole Sides

34 Mounting Hole Sides

35 Mounting Hole Sides

36 Mounting Hole Sides

37 Mounting Hole Sides

38 Mounting Hole Sides

39 Mounting Hole Sides

40 Mounting Hole Sides

41 Mounting Hole Sides

42 Mounting Hole Sides

43 Mounting Hole Sides

44 Mounting Hole Sides

45 Mounting Hole Sides

46 Mounting Hole Sides

47 Mounting Hole Sides

48 Mounting Hole Sides

49 Mounting Hole Sides

50 Mounting Hole Sides

51 Mounting Hole Sides

52 Mounting Hole Sides

53 Mounting Hole Sides

54 Mounting Hole Sides

55 Mounting Hole Sides

56 Mounting Hole Sides

57 Mounting Hole Sides

58 Mounting Hole Sides

59 Mounting Hole Sides

60 Mounting Hole Sides

61 Mounting Hole Sides

62 Mounting Hole Sides

63 Mounting Hole Sides

64 Mounting Hole Sides

65 Mounting Hole Sides

66 Mounting Hole Sides

67 Mounting Hole Sides

68 Mounting Hole Sides

69 Mounting Hole Sides

70 Mounting Hole Sides

TO LOCK THE MOUNTING BRACKET

- Using needle-nose pliers, detach one locking pin from mounting bracket.
- Insert the locking pin into the lock.
- When you attach the Alarm to the mounting bracket, the locking pin's head will fit into a notch on the bracket.

TO UNLOCK THE MOUNTING BRACKET

- Insert a flathead screwdriver between the mounting bracket pin and the mounting bracket.
- Pry the Alarm away from the bracket by turning both the screwdriver and the Alarm counterclockwise (left) at the same time.

TO PERMANENTLY DEACTIVATE THE SMOKE/CO ALARM

▲ WARNING!
Alarm is sealed. The powercell is not replaceable. Once it reaches the end of its service life, or after 10 years—whichever comes first—you must install a new Smoke/CO Alarm.

After 10 years or after the "low power warning" sounds (whichever comes first):

- Once you deactivate this unit, it will not detect smoke or carbon monoxide, or alarm. It cannot be reactivated. You must install a new unit to continue your protection. Alarm will resist mounting to the bracket after deactivation.
- Use a flathead screwdriver to score label along dotted line.
- Use thumb to pull deactivation tab outward until tab snaps into place. This will discharge the powercell and deactivate the unit.
- Install a new Smoke/CO Alarm immediately!

05 TESTING & MAINTENANCE

WEEKLY TESTING

- ▲ WARNING!**
 - NEVER** use an open flame of any kind to test this unit. You might accidentally damage or set fire to the unit or to your home. **NEVER** use vehicle exhaust! Exhaust may cause permanent damage and voids your warranty.
 - DO NOT** stand close to the Alarm when the horn is sounding. Exposure at close range may be harmful to your hearing. When testing, step away when horn starts sounding.

▲ CAUTION!
It is important to test this unit every week to make sure it is working properly. Using the test button is the recommended way to test this Smoke/CO Alarm.

- Push and release the Test/Silence button on the cover until you hear a "chirp." The "chirp" marks the start of the self-test sequence.
- During testing, you will hear a loud, repeating horn pattern: 3 beeps, pause, 3 beeps, pause, while the red smoke LED flashes. Then you will hear a loud, repeating horn pattern: 4 beeps, pause, 4 beeps, pause, while the red CO test LED flashes.

If the Smoke/CO Alarm does not test properly:

- Make sure the battery is installed correctly.
- Be sure the Alarm is clean and dust-free.
- Test the unit again.

If the Smoke/CO Alarm is still not working properly, replace it immediately. Refer to the "Limited Warranty" at the end of this manual.

▲ WARNING!
If there is still a problem, do not try to fix the Alarm yourself. This will void your warranty!

REGULAR MAINTENANCE

This unit has been designed to be as maintenance-free as possible, but there are a few simple things you must do to keep it working properly:

- Test it at least once a week.
- Clean the Smoke/CO Alarm at least once a month; gently vacuum the outside of the Smoke/CO Alarm using your household vacuum's soft brush attachment. Test the Smoke/CO Alarm. Never use water, cleaners or solvents since they may damage the unit.
- If the Smoke/CO Alarm becomes contaminated by excessive dirt, dust and/or grime, and cannot be cleaned to avoid unwanted Alarms, replace the unit immediately.
- If the green power LED flashes 2 times every minute (horn is silent) it means that the Alarm needs to be cleaned as indicated above. If green light continues to flash, replace Alarm.
- Relocate the unit if it sounds frequent unwanted Alarms. See "Where This Alarm Should Not Be Installed" for details.
- Protect or cover the alarm when doing any maintenance to home i.e. sanding floors, painting, drywall patching, etc. to prevent contamination.

▲ WARNING!
DO NOT spray cleaning chemicals or insect sprays directly on or near the Alarm. **DO NOT** paint over the Alarm. Doing so may permanently damage the Alarm.

TROUBLESHOOTING GUIDE

IF THE ALARM...	PROBLEM...	YOU SHOULD...
Green Power LED is OFF: Unit will not Alarm when you press the Test/Silence button.	Battery may be dead or missing.	Replace Alarm
Horn "chirps" 5 times and Green Power LED flashes 1 time every minute.	Low Battery Signal. Alarm needs to be replaced.	Replace Alarm
Horn "chirps" and Green Power LED flashes 3 times every minute	MALFUNCTION SIGNAL. Device is not working properly, and needs to be replaced.	If unit is under warranty, contact Consumer Support to process a warranty replacement.
Horn "chirps" 5 times and Green Power LED flashes 5 times every minute	END OF LIFE SIGNAL. Alarm needs to be replaced.	Immediately replace the Alarm.
Alarm goes back into Alarm after you pressed the Test/Silence button to silence an Alarm.	Smoke and/or CO levels are still potentially dangerous.	Refer to "If Your Smoke/CO Alarm Sounds" for details on how to respond to an Alarm. If anyone is feeling ill, EVACUATE your home immediately and call 911.
Power LED flashes Green 2 times every minute.	Alarm requires cleaning.	Clean Alarm then press and release the test button. See Regular Maintenance section. If Green LED Continues to flash, contact Consumer Support.

CARBON MONOXIDE ALARM ONLY

CO Alarm goes back into Alarm 4 minutes after you Silence it.	CO levels indicate a potentially dangerous situation.	IF YOU ARE FEELING SYMPTOMS OF CO POISONING, EVACUATE your home and call 911 or the Fire Department. Refer to "If The CO Alarm Sounds" for details.
CO Alarm sounds frequently even though no high levels of CO are revealed in an investigation.	The CO Alarm may be improperly located. Refer to "Where to Install This Alarm" for details.	Relocate your Alarm. If frequent Alarms cannot be avoided, relocate your Alarm. Alarm may be too close to a kitchen, cooking appliance, or steamy bathroom.
Smoke Alarm sounds when no smoke is visible.	Unwanted Alarm may be caused by nonemergency source like cooking smoke.	Silence Alarm using manual button; clean the Alarm's cover with a soft, clean cloth. If frequent unwanted Alarms continue, relocate your Alarm. Alarm may be too close to a kitchen, cooking appliance, or steamy bathroom.

If you have questions that cannot be answered by reading this manual, call the Consumer Support Team at 1-800-323-9005

FIRE SAFETY TIPS

Follow safety rules and prevent hazardous situations: 1) Use smoking materials properly. Never smoke in bed. 2) Keep matches or lighters away from children. 3) Store flammable materials in proper containers. 4) Keep electrical appliances in good condition and don't overload electrical circuits. 5) Keep stoves, barbecue grills, fireplaces and chimneys grease- and debris-free. 6) Never leave anything cooking on the stove unattended; 7) Keep portable heaters and open flames, like candles, away from flammable materials. 8) Don't let rubbish accumulate. Keep Alarms clean, and test them weekly. Replace Alarms immediately if they are not working properly. Smoke Alarms that do not work cannot alert you to a fire. Keep at least one working fire extinguisher on every level, and an additional one in the kitchen. Have fire escape ladders or other reliable means of escape from an upper level in case stairs are blocked; 9) Have an escape plan and practice it regularly.

06 IF YOUR SMOKE/CO ALARM SOUNDS

WHAT TO DO FIRST: IDENTIFY THE TYPE OF ALARM SIGNAL

Refer to previous section "What You Will See And Hear With This Alarm."

IF THE CO ALARM SOUNDS

▲ WARNING!

Activation of your CO Alarm indicates the presence of carbon monoxide (CO) which can kill you. In other words, when your CO Alarm sounds, you must not ignore it!

IF THE CO ALARM SIGNAL SOUNDS:

- Press the Test/Silence button.
- Call your emergency services, fire department or 911. Write down the number of your local emergency service here.
- Immediately move to fresh air—outdoors or by an open door or window. Do a head count to check that all persons are accounted for. Do not re-enter the premises, or move away from the open door or window until the emergency services responder has arrived, the premises have been aired out, and your CO Alarm remains in its normal condition.
- After following steps 1-3, if your CO Alarm reactivates within a 24-hour period, repeat steps 1-3 and call a qualified appliance technician to investigate for sources of CO from fuel-burning equipment and appliances, and inspect for proper operation of this equipment. If problems are identified during this inspection have the equipment serviced immediately. Note any combustion equipment not inspected by the technician, and consult the manufacturers' instructions, or contact the manufacturers directly for more information about CO safety and this equipment. Make sure that motor vehicles are not, and have not, been operating in an attached garage or adjacent to the residence. Write down the number of a qualified appliance technician here:

NOTE: A qualified appliance technician is defined as "a person, firm, corporation, or company that either in person or through a representative, is engaged in and responsible for the installation, testing, servicing, or replacement of heating, ventilation, air conditioning (HVAC) equipment, combustion appliances and equipment, and/or gas fireplaces or other decorative combustion equipment."

IF THE SMOKE ALARM SOUNDS

RESPONDING TO AN ALARM

▲ WARNING!

- If the unit Alarms and you are not testing the unit, it is warning you of a potentially dangerous situation that requires your immediate attention. **NEVER** ignore any Alarm. Ignoring the Alarm may result in injury or death.
- Never remove the batteries from a battery operated Smoke/CO Alarm to stop an unwanted Alarm (caused by cooking smoke, etc.). Removing batteries disables the Alarm so it cannot sense smoke, and removes your protection. Instead open a window or fan the smoke away from the unit. The Alarm will reset automatically.
- If the unit Alarms get everyone out of the house immediately.

WHAT TO DO IN CASE OF FIRE

- Don't panic; stay calm. Follow your family escape plan.
- Get out of the house as quickly as possible. Don't stop to get dressed or collect anything.
- Feel doors with the back of your hand before opening them. If a door is cool, open it slowly. Don't open a hot door. Keep doors and windows closed, unless you must escape through them.
- Cover your nose and mouth with a cloth (preferably damp). Take short, shallow breaths.
- Meet at your planned meeting place outside your home, and do a head count to make sure everybody got out safely.
- Call the Fire Department as soon as possible from outside. Give your address, then your name.
- Never go back inside a burning building for any reason.
- Contact your Fire Department for ideas on making your home safer.

▲ WARNING!

Alarms have various limitations. See "General Limitations of Smoke/CO Alarms" for details.

07 USING THE SILENCE FEATURES

▲ WARNING!

The Silence Feature does not disable the unit—it makes it temporarily less sensitive to smoke. For your safety, if smoke around the unit is dense enough to suggest a potentially dangerous situation, the unit will stay in Alarm or may re-Alarm quickly. If you do not know the source of the smoke, do not assume it is an unwanted Alarm. Not responding to an Alarm can result in property loss, injury, or death. If the unit will not silence and no heavy smoke is present, or if it stays in silence mode continuously, it should be replaced immediately.

Never remove the batteries to quiet an unwanted Alarm. Removing the batteries disables the Alarm and removes your protection.

- The Silence Feature is intended to temporarily silence the horn while you identify and correct the problem. Do not use the Silence Feature in emergency situations. It will not correct a CO problem or extinguish a fire.
- The Silence Feature can temporarily quiet an unwanted Alarm for several minutes. You can silence this Smoke/CO Alarm by pressing the Test/Silence button on the Alarm cover.

Activate the Alarm test, reset or silence function by use of a finger or thumb. Use of any other instrument is strictly prohibited.

When the Smoke Alarm is Silenced	When the CO Alarm is Silenced
----------------------------------	-------------------------------

First Alert shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty. Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or province to province.

HOW TO OBTAIN WARRANTY SERVICE

Service: If service is required, do not return the product to your retailer. In order to obtain warranty service, contact the Consumer Support Team at 1-800-323-9005. To assist us in serving you, please have the model number and date of purchase available when calling.

Disposal: Please follow local guidelines regarding the disposal or recycling of batteries and/or electronics.

The Alarm should be deactivated before disposal. See, "To Permanently Deactivate the Smoke/CO Alarm".

For your records, please record:

Date Purchased: _____

Where Purchased: _____

Date Installed: _____ / _____ Month/Year

Replace Alarm 10 years after installation.

Please write the date in the space provided: _____ / _____ Month/Year

The Alarm will also provide an audible End-of-Life Signal approximately 10 years after installation to remind you to replace the unit.

The End-of-Life Signal can be silenced for up to 2 days. Do not deactivate the Alarm until you get replacement.

Printed in Mexico | M08-170691 01/23

CONFORMS TO UL STD 217 AND UL STD 2034

firstalert.com



© 2023 Resideo Technologies, Inc. All rights reserved. These products are manufactured by Resideo Technologies, Inc. and its affiliates, 3901 Liberty Street, Aurora, IL 60504-8122. Consumer Support Team: (800) 323-9005 | firstalert.com