

## **Powering On the Scooter**

Press and hold the Power Button for 2s.

### **Turning Off the Scooter**

Press and hold the Power Button for 2s.

## **Switching Speed Modes**

Make sure the scooter is on, and press the power button once to switch between 3 speed modes eco, normal and sport. Press again for the next mode.

#### Riding the Scooter

Give a strong kick to begin riding your scooter, then use the throttle to speed up. A minimum speed of 1.8mph (3 km/h) must be reached before you can use the throttle.



@RideHover1



# **Powering On the Scooter**

Press and hold the Power Button for 2s.

# **Turning Off the Scooter**

Press and hold the Power Button for 2s.

# **Switching Speed Modes**

Make sure the scooter is on, and press the power button once to switch between the sport and eco speed modes

# Riding the Scooter

Give a strong kick to begin riding your scooter, then use the throttle to speed up. A minimum speed of 1.8mph (3 km/h) must be reached before you can use the throttle.



@RideHover1



www.Hover-1.com