

PACKAGE CONTENTS

- Portable battery
- USB-C to USB charging/sync cable
- Quick Setup Guide

COMPATIBILITY


- Compatible with most mobile devices, including iPhones.
- If your device requires a different connector, use the cable that came with your device.

Before using your new product, please read these instructions to prevent any damage.

QUICK SETUP GUIDE


FEATURES

- High-speed 18 W USB-C dual-purpose port charges your battery (input) and charges devices (output)
- Additional USB-A port charges a second device
- LED indicator shows your charge status
- Stylish, non-slip fabric sides for a comfortable grip
- 1 ft. (30 cm) USB-C to USB cable



CHARGING YOUR PORTABLE BATTERY


Fully charge your portable battery for four hours before using it for the first time.



- 1 Plug the small end of your included USB cable into the portable battery's USB-C port.
- 2 Plug the other end into a standard USB port on a computer, car charger, or wall charger (not included). Your portable battery automatically begins charging and the LED turns on.

Note: All four LEDs turn on when the portable battery is fully charged.

CHARGING YOUR DEVICES



Note: You can use either USB port to charge a device. You can also use both ports at the same time to charge two devices.

- 1 Plug the large end of the included USB cable into one of your portable battery's USB ports.
- 2 Plug the other end into your device. Your portable battery automatically begins charging your device.

Notes:

- If your device requires a different connector than the one provided, use the cable that came with your device.
- Do not charge another device while your portable battery is charging.

SPECIFICATIONS

Dimensions (H × W × D)	2.7 × .6 × 5.4 in. (68.7 × 16.5 × 137.2 mm)
Cable length	11.8 in. (30 cm)
Input	USB-C: 5 V/3 A, 9 V/2 A
Output	USB-C: 5 V/3 A, 9 V/2 A USB-A: 5 V/1.5 A
Built-in cell capacity	10,000 mAh / 3.7 V (37 Wh)
Power bank capacity	6,600 mAh (5 V / 1.5 A) 6,500 mAh (5 V / 3 A) 3,500 mAh (9 V / 2 A)

Power bank capacity will be less than built-in cell capacity. Performance varies based on settings and environmental conditions, and decreases over time and with use.

**SAFETY INFORMATION/
CAUTION**

- Do not expose your portable battery to heat, fire, or water.
- Do not modify, disassemble, open, drop, crush, puncture, or shred the internal battery.
- This is not a toy. Young children should be supervised to make sure that they do not play with the portable battery.
- Do not charge devices while the portable battery is recharging.
- Recharge the portable battery if it has not been used for more than 90 days.
- Risk of fires and burns. Do not open, crush, heat above 140° F (60° C), or incinerate. Follow the manufacturer's instructions.
- Operating environment temperatures: 32~104° F (0~40° C)

This product is safe for regular use under normal conditions. As with any device using electrical power, some situations may be unsafe and injuries or damages could result. To minimize or avoid unsafe conditions, read and follow the instructions before using.

WARNING

- When using this product, basic precautions should always be followed, including the following:
- Read all the instructions before using the product.
 - To reduce the risk of injury, close supervision is necessary when the product is used near children.
 - Do not put fingers or hands into the product.
 - Do not expose the power bank to rain or snow.
 - Use of a power supply or charger not recommended or sold by the power bank manufacturer may result in a risk of fire or injury to persons.
 - Do not use the power bank in excess of its output rating. Overload outputs above that rating may result in a risk of fire or injury to persons.
 - Do not use a power bank that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior, resulting in fire, explosion or risk of injury.
 - Do not disassemble the power bank. Take it to a qualified service person when service or repair are required. Incorrect reassembly may result in a risk of injury to persons.

- Do not expose a power bank to fire or excessive temperature. Exposure to fire or temperature above 212°F (100°C) may cause explosion.
- Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.
- Unplug the power bank when not in use.

LEGAL NOTICES

Declaration of Conformity:
Brand name/model number: MODAL MD-MB10C21PP/MD-MB10C21BG
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Suppliers Name: Best Buy Purchasing, LLC. Suppliers Address (USA): 7601 Penn Ave South, Richfield, MN 55423 U.S.A.
Suppliers phone number: 1-800-499-3402.
FCC Caution:
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
FCC Statement:
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**ONE-YEAR LIMITED
WARRANTY**

CONTACT MODAL:

For customer support, call
1-800-499-3402
(U.S. and Canada)
www.bestbuy.com/modal

iPhone is a trademark of Apple Inc., registered in the U.S. and other countries.
MODAL is a trademark of Best Buy and its affiliated companies
Distributed by Best Buy Purchasing, LLC
7601 Penn Ave South, Richfield, MN 55423 U.S.A.
©2020 Best Buy. All rights reserved.