6.0 Detailed Function List

Turn on	1. Manual: the earbuds are in the off state, long press for 3 still the blue light is on. Search for the last connected record within 10s. If it is not found, it will enter the pairing state (red and blue lights flash alternately). 2. Automatic: When the earbuds is in the charging case, you can pick them up and they will automatically turn on. Then within 10 seconds after opening the earbuds, find the mobile phone with the memory of the last connection. If not found, enter the pairing s tate (red and blue lights flash alternately).
Turn off	Manual: Press the panel for 5s till the red light is on and turn off. Automatic: Place the earbuds back into the charging case and close the lid.
Phone Pairing	If the earbuds are in the off state, press the panel for 5s to the paring mode(red and blue light flashes alternately) and search the name "TOZO-NC7" to pair.
Automatically turn off	The earbuds have not been connected for more than 5mins. The earbuds will be out of connection range(10 meters) for more than 5mins.
Reset	If your earbuds accidentally only get one earbud to work, fail to pair or there is no sound from any buds. Please reset. 1. Delete all TOZO-NC7 Bluetooth records on the phone, and turn off Bluetooth. Then press both earbuds for 5 seconds to turn on. 2. Press both earbuds for 5 seconds till the Blue light goes out, and then quickly double-tap the panel. The reset is complete once purple light is on. NOTE: If your device displays [Connection failed]. Please delete all [TOZO-NC7] pairing history and pair again.

Power on and reconnect	1. Tap the MFB touch pannel for 3 seconds and release to turn on the earbuds→ wait for a few seconds for the earbuds to automatically interconnect with each other → wait for a few seconds for the earbuds to connect with the paired phone → the connection is successful. 2. Take out the earbuds from charging case→wait for a few seconds for the earbuds to automatically interconnect with each other →wait for a few seconds for the earbuds to connect with the paired phone → the connection is successful.
Reconnect after exceeding the distance	After the earbud is disconnected from the phone at a long distance, it can automatically reconnect when it returns to the close distance with the phone within 5 minutes. More than 5 minutes, the headset will automatically turn off.
Answer Phone Call	Tap the MFB touch pannel once to answer the incoming call.
Hang up Phone Call	Tap and hold the MFB touch pannel for 2 seconds to hand up the phone.
Reject Incoming Call	Tap and hold the MFB touch pannel for 2 seconds to reject the incoming call.
Cancel dialing	Tap and hold the MFB touch pannel for 2 seconds to cancel dialing before dialing out and the other party fails to answer.
Play/Pause	When playing music, tap the Right MFB touch pannel once to pause/play (The left headset cannot switch to play/pause).
Next Track	Double Tap the Right MFB touch pannel twice for backward when playing music.
Previous Track	Double-Tap the Left MFB touch pannel twice for previous when playing music.

Volume up	Tap and hold the MFB touch pannel on Right earbud when playing music.
Volume down	Tap and hold the MFB touch pannel on Left earbud when playing music.
Voice interaction of Siri	In standby mode, quickly tap the MFB touch pannel 3 times to turn on voice interaction of mobile phone.
Primary / Secondary switch automatically	When listening to music, put either headset back into the charging case, and the other headset will not be affected.

7.0 Function List

7.1 Left earbud

Turn On	Pick up the earbuds from the case it will turn on automatically. Tap the MFB Touch Pannel for 3 seconds to turn on.
Turn Off	Put back into the charging case, it will turn off & charge automatically. Tap the MFB Touch Pannel for 5 seconds to turn off when not playing. Automatically turn off after no connection for more than 5 minutes.
Previous Track	Tap the MFB Touch Pannel to play backward.
Volume down	Tap and hold the MFB Touch Pannel to reduce volume.
Active Noise Cancellation Mode	Tap the MFB Touch Pannel Once.
Transparent mode	Tap the MFB Touch Pannel Once.
Answer Phone Call	Tap the MFB Touch Pannel Once.
Hang up Phone Call	Long press the MFB Touch Pannel for 2 seconds.
Reject Incoming Call	Long press the MFB Touch Pannel for 2 seconds.
Cancell Phone Call	Long press the MFB Touch Pannel for 2 seconds.

7.2 Right earbud

Turn On	Pick up the earbuds from the case it will turn on automatically. Tap the MFB Touch Pannel for 3 seconds to turn on:
Turn Off	Put back into the charging case, it will turn off & charge automatically. Tap the MFB Touch Pannel for 5 seconds to turn off when not playing. Automatically turn off after no connection for more than 5 minutes.
Next Track	Tap the MFB Touch Pannel twice to play backward.
Volume up	Tap and hold the MFB Touch Pannel to increase volume.
Play/Pause	Tap the MFB Touch Pannel Once.
Answer Phone Call	Tap the MFB Touch Pannel Once.
Hang up Phone Call	Long press the MFB Touch Pannel for 2 seconds.
Reject Incoming Call	Long press the MFB Touch Pannel for 2 seconds.
Cancel Phone Call	Long press the MFB Touch Pannel for 2 seconds.

SPECIAL REMINDER:

Wipe the hardware contacts of the headset and charging box when the headset is not charging.

Note:
If your problem is not answered above, please contact us via email , we will respond within 24 hours.
Email: info@tozostore.com

Battery Warning!
This product has built-in lithium battery. Do not expose the product to strong sunlight, fire or throw it into the fire to avoid explosion.

NC7 ACTIVE NOISE CANCELLATION
User Manual

1.0 Product description

MFB Touch Pannel
Indicator Light
Medial (Ear Canal) NoiseCancelling Microphone
Outside Noise Cancelling Microphone
Magnet
Metal connector
Optical sensor
Indicator Lights of the Charging Case

2.0 Wearing Steps

Step 1: Ensure the earbud tip facing downwards, then place earbuds into ear.
Step 2: Rotate earbuds back to auricle side to fit snugly.

Step 1   Step 2

Step 1
Step 2
The ear cap facing up is an incorrect way to wear the earbuds.

3.0 Operation of earbuds

3.1 How to pair

1. Take out the 2 earbuds form the charging case, they will power on and pair within 10s.
2. The two earbuds flash red and blue alternately.(Pairing Mode)
3. Search for pairing name [TOZO · NC7]

3.2 Power on/off

Power on :
1.Open the lid, the earbuds will turn on automatically.
2.Press & hold both earbuds' MFB Touch Pannel for more than 3s.

Power off :
1. Put the earbuds back into the case and close the lid, the earbuds will power off automatically.
2. When earbuds are not playing music, long press MFB Touch Pannel for 5 seconds to turn off.
3. The earbuds will turn off automatically after it is disconnected for more than 5 minutes.

3.3 Reset

If your earbuds accidentally only get one earbud to work, or fail to pair. Please reset it.
1. Delete all TOZO-NC7 Bluetooth records on the phone, and turn off Bluetooth. Take earbuds out from the charging case, press the touch panel for 5 seconds to turn the earbuds off.
2. Press both earbuds for 5 seconds till the Blue light goes out, and then quickly double-tap the panel. The reset is complete once purple light is on.

3.4 Optical sensor

The earbuds can automatically monitor whether the bud is worn on the ear. The music will pause automatically when you take off the earbuds(or either of it), and will continue to play when you wear them again.

NOTE: Simply tap the panel to play the music if you manually pause the music.

4.0 Switch between different modes

Tap the left earbud to switch to Transparent Mode,Active Noise Cancellation Mode or Active Noise Cancellation Off.There is no Active Noise Cancellation function when only wearing a single bud.

NOTE: please try to reconnect or change place.

4.1 Active noise cancellation mode

With the active noise reduction function, the outward-facing microphone can detect external sounds, and then your TOZO NC7 earbuds will use anti-noise technology to cancel these sounds, thereby eliminating them before you hear them. An inward facing microphone will listen to unwanted internal sounds in your ears, and your TOZO NC7 earbuds can also counteract these sounds through noise reduction.

Active Noise Cancellation

4.2 Transparency mode

Transparency mode can enhance the voice frequency band and improve the perception of the surrounding sound, so you can hear what's going on around you with out taking off the earbuds.
Active Noise Cancellation and Transparency mode work best when your TOZO NC7 fit well and wearing correctly.

4.3 Active Noise Cancellation Off Mode

Active Noise Cancellation Mode is the default mode.

5.0 BOX Wireless Charging (Wireless charger is not included)

Designed for the modern life, never be strangled by headphone cables.

Place the charging case vertically for wireless charging

Thank you for purchasing the TOZO authentic product.
For more latest products, parts and accessories, please visit: www.tozostore.com
For any assistance please contact Email: info@tozostore.com