rocketfish™

Rocketfish Laptop AC Power Adapter/ Rocketfish Laptop AC Power Adapter with USB

Adaptateur d'alimentation c.a. pour ordinateur portatif de Rocketfish/Adaptateur d'alimentation c.a. pour ordinateur portatif avec port USB

Adaptador de alimentación CA para laptop de Rocketfish/Adaptador de alimentación CA para laptop con puerto USB

RF-AC9023/RF-AC9023-CAM
RF-ACU9025/RF-ACU9025-CAM

Before using your new product, please read these instructions to prevent any damage.
Avant l'utilisation de ce produit neuf, lire ces instructions afin d'éviter tout dommage.
Antes de usar su producto nuevo, lea estas instrucciones para evitar cualquier daño.

Tip Compatibility Guide / Guide de compatibilité des connecteurs / Guía de compatibilidad de las puntas

To locate the correct tip for your laptop:

1 Find your laptop manufacturer (Acer, Dell, HP, etc.) in the table.

2 Find your laptop model (Aspire, Tablet, ThinkPad, etc.)

3 Find the tip model number.

Pour identifier le connecteur correct pour l'ordinateur portatif :

1 Identifier le fabricant de l'ordinateur portatif (Acer, Dell, HP, etc.) dans le tableau.

2 Identifier le modèle d'ordinateur portatif (Aspire, tablette, ThinkPad, etc.)

3 Identifier le numéro du modèle de connecteur.

Para identificar la punta correcta para su laptop:

1 Identifique el fabricante de su laptop (Acer, Dell, HP, etc.) en la tabla.

2 Identifique el modelo de su laptop (Aspire, tableta, ThinkPad, etc.)

3 Identifique el número del modelo de punta.

	Model / Modèle / Modelo	
Acer	Aspire 1200	32
Acer	Aspire 1300	41
Acer	Aspire 1350	41
Acer	Aspire 1410	32
Acer	Aspire 1415	32
Acer	Aspire 1450	32
Acer	Aspire 1520	32
Acer	Aspire 1640	32
Acer	Aspire 1800	32
Acer	Aspire 2000	32
Acer	Aspire 2010	32
Acer	Aspire 2200	32
Acer	Aspire 2930	32
Acer	Aspire 3000	32
Acer	Aspire 3005	5
Acer	Aspire 3100	32
Acer	Aspire 3500	32
Acer	Aspire 3600	32
Acer	Aspire 3610	32
Acer	Aspire 3620	32
Acer	Aspire 3680	32
Acer	Aspire 4520	32
Acer	Aspire 4551	32
Acer	Aspire 4710	32
Acer	Aspire 4730	32
Acer	Aspire 4730Z	32
Acer	Aspire 4738	32
Acer	Aspire 4738Z	32
Acer	Aspire 4745Z	32
Acer	Aspire 4750G	32

	Model / Modèle / Modelo	
Acer	Aspire 4820	32
Acer	Aspire 4820G	32
Acer	Aspire 4820T	32
Acer	Aspire 4920	32
Acer	Aspire 5000	32
Acer	Aspire 5002	5
Acer	Aspire 5100	32
Acer	Aspire 5110	32
Acer	Aspire 5250	32
Acer	Aspire 5251	32
Acer	Aspire 5252	32
Acer	Aspire 5300	32
Acer	Aspire 5310	32
Acer	Aspire 5315	32
Acer	Aspire 5332	32
Acer	Aspire 5334	32
Acer	Aspire 5335	32
Acer	Aspire 5335Z	32
Acer	Aspire 5336	32
Acer	Aspire 5338	32
Acer	Aspire 5500	32
Acer	Aspire 5550	32
Acer	Aspire 5600	41
Acer	Aspire 5610	32
Acer	Aspire 5620	41
Acer	Aspire 5625	32
Acer	Aspire 5625G	32
Acer	Aspire 5630	32
Acer	Aspire 5670	32
Acer	Aspire 5672	5

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.

REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.

NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

Model / Modèle / Modelo		
Acer	Aspire 5680	32
Acer	Aspire 5710	32
Acer	Aspire 5715	32
Acer	Aspire 5720	32
Acer	Aspire 5730	32
Acer	Aspire 5740	32
Acer	Aspire 5750	32
Acer	Aspire 5810T	32
Acer	Aspire 5820	32
Acer	Aspire 5830T	32
Acer	Aspire 5910G	32
Acer	Aspire 5920	32
Acer	Aspire 5930	32
Acer	Aspire 5930G	32
Acer	Aspire 5935	32
Acer	Aspire 5935G	32
Acer	Aspire 5940	32
Acer	Aspire 5940G	32
Acer	Aspire 5942	32
Acer	Aspire 6530	32
Acer	Aspire 6920	32
Acer	Aspire 6930	32
Acer	Aspire 6935	32
Acer	Aspire 7000	32
Acer	Aspire 7003WSMi	32
Acer	Aspire 7100	32
Acer	Aspire 7103WSMi	32
Acer	Aspire 7104	32
Acer	Aspire 7104WSMi	32
Acer	Aspire 7110	32
Acer	Aspire 7111WSMi	32
Acer	Aspire 7112WSMi	32
Acer	Aspire 7220	32
Acer	Aspire 7230	32
Acer	Aspire 7235	32
Acer	Aspire 7250	32
Acer	Aspire 7315	32
Acer	Aspire 7320	32
Acer	Aspire 7320G	32

Model / Modèle / Modelo		
Acer	Aspire 7330	32
Acer	Aspire 7520	32
Acer	Aspire 7530	32
Acer	Aspire 7540	32
Acer	Aspire 7540G	32
Acer	Aspire 7551	32
Acer	Aspire 7560	32
Acer	Aspire 7735	32
Acer	Aspire 7735Z	32
Acer	Aspire 7735ZG	32
Acer	Aspire 7736	32
Acer	Aspire 7738	32
Acer	Aspire 7738G	32
Acer	Aspire 7739	32
Acer	Aspire 7740	32
Acer	Aspire 7740G	32
Acer	Aspire 7741	32
Acer	Aspire 7745	32
Acer	Aspire 7750G Series	32
Acer	Aspire 8730	32
Acer	Aspire 8920	32
Acer	Aspire 8930	32
Acer	Aspire 9300	32
Acer	Aspire 9400	32
Acer	Aspire 9502	32
Acer	Aspire 9503	32
Acer	Aspire E1	32
Acer	Aspire M5	32
Acer	Aspire S3	32
Acer	Aspire S5	32
Acer	Aspire Timeline Ultra M5	32
Acer	Aspire Timeline Ultrabook (14-inch)	32
Acer	Aspire Timeline Ultrabook (15-inch)	32
Acer	Aspire TimelineX 1830T	32
Acer	Aspire TimelineX 3820	32
Acer	Aspire TimelineX 4820	32
Acer	Aspire TimelineX 5820	32
Acer	Aspire V3	32
Acer	Aspire V5	32

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.
REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.
NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

	Model / Modèle / Modelo	
Acer	Extensa 4120	32
Acer	Extensa 4130	32
Acer	Extensa 4220	32
Acer	Extensa 4230	32
Acer	Extensa 4420	32
Acer	Extensa 4620	32
Acer	Extensa 4630	32
Acer	Extensa 5120	32
Acer	Extensa 5210	32
Acer	Extensa 5230	32
Acer	Extensa 5235	32
Acer	Extensa 5620	32
Acer	Extensa 5630	32
Acer	Extensa 7230	32
Acer	Extensa 7630	32
Acer	Ferrari 1000	32
Acer	Ferrari 1100	32
Acer	Ferrari 3000	41
Acer	Ferrari 4000	41
Acer	Ferrari 5000	32
Acer	TravelMate 3200	32
Acer	TravelMate 3400LMi	32
Acer	TravelMate 4000	32
Acer	TravelMate 4011	32
Acer	TravelMate 4020	32
Acer	TravelMate 4021	32
Acer	TravelMate 4060	32
Acer	TravelMate 4100	32
Acer	TravelMate 4150	32
Acer	TravelMate 4200	32
Acer	TravelMate 4202	32
Acer	TravelMate 4210	32
Acer	TravelMate 4220	32
Acer	TravelMate 4230	32
Acer	Travelmate 4330	32
Acer	Travelmate 4335	32
Acer	TravelMate 4404	41
Acer	TravelMate 4500	32
Acer	TravelMate 4520	32

	Model / Modèle / Modelo	
Acer	TravelMate 4650	32
Acer	TravelMate 4670	32
Acer	TravelMate 4720	32
Acer	TravelMate 4730	32
Acer	Travelmate 4730G	32
Acer	TravelMate 4740	32
Acer	TravelMate 4750	32
Acer	TravelMate 5100	32
Acer	TravelMate 5220	32
Acer	TravelMate 5310	32
Acer	TravelMate 5330	32
Acer	TravelMate 5472	32
Acer	TravelMate 5520	32
Acer	TravelMate 5542	32
Acer	TravelMate 5600	32
Acer	TravelMate 5710	32
Acer	TravelMate 5735	32
Acer	TravelMate 5742	32
Acer	TravelMate 6000	32
Acer	TravelMate 7520	32
Acer	TravelMate 7530	32
Acer	TravelMate 7720	32
Acer	TravelMate 7740	32
Acer	TravelMate 8000	32
Acer	TravelMate Alpha 550	32
Acer	TravelMate Alpha 551	32
Acer	TravelMate C100	32
Acer	TravelMate C200	32
Acer	TravelMate C300	32
Acer	TravelMate P243	32
Acer	TravelMate P453	32
Acer	TravelMate P633	32
Acer	TravelMate P643	32
Acer	TravelMate P653	32
Acer	TravelMate Timeline 8372T	32
Acer	TravelMate TimelineX 6495T	32
Acer	TravelMate TimelineX 8372	32
Acer	TravelMate TimelineX 8473T	32
Acer	TravelMate TimelineX 8481T	32

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.

REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.

NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

Model / Modèle / Modelo		
Acer	TravelMate TimelineX 8573T	32
Asus	A3 series	5
Asus	A3000 series	5
Asus	A4000 series	41
Asus	A43 Series	41
Asus	A45 Series	41
Asus	A53 Series	41
Asus	A54	41
Asus	A55 Series	41
Asus	A6 series	41
Asus	A72F	41
Asus	A73E	41
Asus	A83	41
Asus	A9	41
Asus	B43	41
Asus	B53	41
Asus	B80A	41
Asus	F3Q	41
Asus	F50	41
Asus	F6	41
Asus	F70	41
Asus	F7000	5
Asus	F75 Series	41
Asus	F8 Series	41
Asus	F80	41
Asus	G1S	41
Asus	G2	41
Asus	G60	41
Asus	K40	41
Asus	K42	41
Asus	K43	41
Asus	K50	41
Asus	K52	41
Asus	K53	41
Asus	K55	41
Asus	K60i	41
Asus	K70	41
Asus	K72	41
Asus	K73	41

Model / Modèle / Modelo		
Asus	L5	5
Asus	L50	41
Asus	L5000	5
Asus	L5800	5
Asus	L7000	5
Asus	L7200	5
Asus	L7300	5
Asus	L8400	5
Asus	M50	41
Asus	M51	41
Asus	M60VP	41
Asus	M70	41
Asus	N10	41
Asus	N43SL	41
Asus	N45	41
Asus	N46	41
Asus	N50	41
Asus	N55	41
Asus	N56	41
Asus	N61	41
Asus	N70	41
Asus	N73 Series	41
Asus	N75	41
Asus	N76	41
Asus	N80 Series	41
Asus	N81 Series	41
Asus	N82 Series	41
Asus	N90	41
Asus	P30A	41
Asus	P43E	41
Asus	P53E	41
Asus	Q400A	41
Asus	Q500A	41
Asus	R1E	41
Asus	R500	41
Asus	R704A	41
Asus	S400CA	41
Asus	S46	41
Asus	S56	41

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.
REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.
NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

	Model / Modèle / Modelo	
Asus	U20	41
Asus	U24	41
Asus	U30	41
Asus	U31	41
Asus	U32	41
Asus	U36	41
Asus	U43	41
Asus	U44SG	41
Asus	U46	41
Asus	U47	41
Asus	U50	41
Asus	U52	41
Asus	U53	41
Asus	U56	41
Asus	U57A	41
Asus	U6	41
Asus	U80	41
Asus	U81	41
Asus	U89	41
Asus	UL30	41
Asus	UL50	41
Asus	UL80	41
Asus	UX50	41
Asus	X301A	41
Asus	X401	41
Asus	X44H	41
Asus	X501	41
Asus	X53	41
Asus	X54	41
Asus	X55	41
Asus	X71	41
Asus	X75	41
Asus	X83	41
Asus	Z54C	41
Asus	Z83V	5
Asus	Z91	5
Asus	Z9100	5
Averatec	1000 Series	41
Averatec	3150H	41

	Model / Modèle / Modelo	
Averatec	3150HD	41
Averatec	3150HS	41
Averatec	3150HW	41
Averatec	3150P	41
Averatec	3260 Series	41
Averatec	3270 Series	41
Averatec	3280 Series	41
Averatec	3700 Series	41
Averatec	3715EDI	41
Averatec	3800 Series	41
Averatec	4100 Series	41
Averatec	4200 Series	41
Averatec	5110 Series	41
Averatec	5110H	41
Averatec	5110HX	41
Averatec	5110P	41
Averatec	6100A Series	41
Averatec	6200 Series	41
Averatec	AV1020-ED1	41
Averatec	AV1050-EB1	41
Averatec	AV3100 series	41
Averatec	AV3120V	41
Averatec	AV3150H	41
Averatec	AV3150HS	41
Averatec	AV3150P	41
Averatec	AV3200 series	41
Averatec	AV3220H1	41
Averatec	AV3225HS	41
Averatec	AV3250H1	41
Averatec	AV3250HS	41
Averatec	AV3250HX	41
Averatec	AV3250PX	41
Averatec	AV3255P1	41
Averatec	AV3270EH1	41
Averatec	AV3300 series	41
Averatec	AV3360-EG1	41
Averatec	AV3360-EH1	41
Averatec	AV3500T60	41
Averatec	AV4155-EH1	41

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.
REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.
NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

Model / Modèle / Modelo		
Averatec	AV5500	41
Averatec	AV6110	41
Averatec	AV6200H60	41
Averatec	AV6210X60	41
Averatec	AV6235	41
Averatec	AV6240	41
Averatec	AV6240-EH1	41
Averatec	AV7170-EC1	41
Averatec	C3500	41
Averatec	SL3150HD-01	41
Compaq	Mini 311c-1000 series	5
Compaq	Presario 1000	41
Compaq	Presario 1200	41
Compaq	Presario 1200XL	41
Compaq	Presario 12XL	41
Compaq	Presario 1400	41
Compaq	Presario 14XL series	41
Compaq	Presario 1500	5
Compaq	Presario 1600	41
Compaq	Presario 1700	41
Compaq	Presario 17XL series	41
Compaq	Presario 1800	41
Compaq	Presario 18XL series	41
Compaq	Presario 2100	41
Compaq	Presario 2200	5
Compaq	Presario 2500	41
Compaq	Presario 2700 series	41
Compaq	Presario 2800	5
Compaq	Presario A916NR	5
Compaq	Presario A931NR	5
Compaq	Presario A940NR	5
Compaq	Presario B1800 Series	5
Compaq	Presario B2800 Series	5
Compaq	Presario C300	5
Compaq	Presario C500 Series	5
Compaq	Presario C700 Series	5
Compaq	Presario CQ32	55
Compaq	Presario CQ40	55
Compaq	Presario CQ41 Series	55

Model / Modèle / Modelo		
Compaq	Presario CQ42 Series	55
Compaq	Presario CQ43 Series	55
Compaq	Presario CQ45	55
Compaq	Presario CQ50 Series	55
Compaq	Presario CQ56 Series	55
Compaq	Presario CQ57 Series	55
Compaq	Presario CQ60 Series	55
Compaq	Presario CQ61 Series	55
Compaq	Presario CQ62 Series	55
Compaq	Presario CQ70 Series	55
Compaq	Presario CQ71 Series	55
Compaq	Presario CQ72 Series	55
Compaq	Presario F500 Series	5
Compaq	Presario F700 Series	5
Compaq	Presario M2000 series	5
Compaq	Presario V2000 series	5
Compaq	Presario V3000 Series	5
Compaq	Presario V3500 Series	5
Compaq	Presario V4000 series	5
Compaq	Presario V5000 series	5
Compaq	Presario V6000 Series	5
Compaq	Presario V6500 Series	5
Compaq	Presario X1000 series	5
Dell	Alienware M11X	23
Dell	Inspiron 1000	41
Dell	Inspiron 1150	23
Dell	Inspiron 1200	41
Dell	Inspiron 13	23
Dell	Inspiron 1300	41
Dell	Inspiron 1318	23
Dell	Inspiron 1320	23
Dell	Inspiron 1320n	23
Dell	Inspiron 1370	23
Dell	Inspiron 13R	23
Dell	Inspiron 13z	23
Dell	Inspiron 14	23
Dell	Inspiron 1410	23
Dell	Inspiron 1420	23
Dell	Inspiron 1421	23

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.
REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.
NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

	Model / Modèle / Modelo	
Dell	Inspiron 1435	23
Dell	Inspiron 1440	23
Dell	Inspiron 1464	23
Dell	Inspiron 1470	23
Dell	Inspiron 1470n	23
Dell	Inspiron 14BR	23
Dell	Inspiron 14R	23
Dell	Inspiron 14v	23
Dell	Inspiron 14z	23
Dell	Inspiron 15	23
Dell	Inspiron 1501	23
Dell	Inspiron 1520	23
Dell	Inspiron 1521	23
Dell	Inspiron 1525	23
Dell	Inspiron 1526	23
Dell	Inspiron 1535	23
Dell	Inspiron 1545	23
Dell	Inspiron 1546	23
Dell	Inspiron 1564	23
Dell	Inspiron 1570	23
Dell	Inspiron 15N	23
Dell	Inspiron 15R	23
Dell	Inspiron 15z	23
Dell	Inspiron 17	23
Dell	Inspiron 1720	23
Dell	Inspiron 1721	23
Dell	Inspiron 1735	23
Dell	Inspiron 1750	23
Dell	Inspiron 1764	23
Dell	Inspiron 17R	23
Dell	Inspiron 2200	41
Dell	Inspiron 3000	41
Dell	Inspiron 300m	23
Dell	Inspiron 3200	41
Dell	Inspiron 3500	41
Dell	Inspiron 500m	23
Dell	Inspiron 510m	23
Dell	Inspiron 5150	23
Dell	Inspiron 5160	23

	Model / Modèle / Modelo	
Dell	Inspiron 6000	23
Dell	Inspiron 600m	23
Dell	Inspiron 630m	23
Dell	Inspiron 6400	23
Dell	Inspiron 640m	23
Dell	Inspiron 7000	41
Dell	Inspiron 700m	23
Dell	Inspiron 710m	23
Dell	Inspiron 740m	23
Dell	Inspiron 8500	23
Dell	Inspiron 8600	23
Dell	Inspiron 9200	23
Dell	Inspiron 9300	23
Dell	Inspiron 9400	23
Dell	Inspiron B120	41
Dell	Inspiron B130	41
Dell	Inspiron E1405	23
Dell	Inspiron E1505	23
Dell	Inspiron E1505n	23
Dell	Inspiron E1705	23
Dell	Inspiron M101	23
Dell	Inspiron M101z	23
Dell	Inspiron M101ZD	23
Dell	Inspiron M101ZR	23
Dell	Inspiron M102z	23
Dell	Inspiron M102ZD	23
Dell	Inspiron M4010	23
Dell	Inspiron M501	23
Dell	Inspiron M5010	23
Dell	Inspiron M501R	23
Dell	Inspiron M5040	23
Dell	Inspiron N3010	23
Dell	Inspiron N311z	23
Dell	Inspiron N4010	23
Dell	Inspiron N4020	23
Dell	Inspiron N4020D	23
Dell	Inspiron N4030	23
Dell	Inspiron N4030D	23
Dell	Inspiron N411z	23

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.

REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.

NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

	Model / Modèle / Modelo	
Dell	Inspiron N5010	23
Dell	Inspiron N5030	23
Dell	Inspiron N5040	23
Dell	Inspiron N7010	23
Dell	Inspiron N7110	23
Dell	Inspiron XPS	23
Dell	Inspiron XPS Gen 2	23
Dell	Latitude 100L	23
Dell	Latitude 110L	41
Dell	Latitude 120L	41
Dell	Latitude 13	23
Dell	Latitude 131L	23
Dell	Latitude 2010	23
Dell	Latitude 2100	23
Dell	Latitude 2110	23
Dell	Latitude 2120	23
Dell	Latitude ATG D620	23
Dell	Latitude D400	23
Dell	Latitude D410	23
Dell	Latitude D420	23
Dell	Latitude D430	23
Dell	Latitude D500	23
Dell	Latitude D505	23
Dell	Latitude D510	23
Dell	Latitude D520	23
Dell	Latitude D530	23
Dell	Latitude D531	23
Dell	Latitude D600	23
Dell	Latitude D610	23
Dell	Latitude D620	23
Dell	Latitude D630	23
Dell	Latitude D630 ATG	23
Dell	Latitude D630c	23
Dell	Latitude D630N	23
Dell	Latitude D631	23
Dell	Latitude D800	23
Dell	Latitude D810	23
Dell	Latitude D820	23
Dell	Latitude D830	23

	Model / Modèle / Modelo	
Dell	Latitude E4200	23
Dell	Latitude E4300	23
Dell	Latitude E4310	23
Dell	Latitude E5400	23
Dell	Latitude E5400a	23
Dell	Latitude E5410	23
Dell	Latitude E5420	23
Dell	Latitude E5430	23
Dell	Latitude E5500	23
Dell	Latitude E5500a	23
Dell	Latitude E5510	23
Dell	Latitude E5520	23
Dell	Latitude E5530	23
Dell	Latitude E6220	23
Dell	Latitude E6230	23
Dell	Latitude E6320	23
Dell	Latitude E6330	23
Dell	Latitude E6400	23
Dell	Latitude E6400 ATG	23
Dell	Latitude E6400 XFR	23
Dell	Latitude E6410	23
Dell	Latitude E6410 ATG	23
Dell	Latitude E6420	23
Dell	Latitude E6420 ATG	23
Dell	Latitude E6420 XFR	23
Dell	Latitude E6430	23
Dell	Latitude E6430 ATG	23
Dell	Latitude E6430s	23
Dell	Latitude E6430U	23
Dell	Latitude E6500	23
Dell	Latitude E6510	23
Dell	Latitude E6520	23
Dell	Latitude E6530	23
Dell	Latitude LX450	3
Dell	Latitude PP22L	23
Dell	Latitude X300	23
Dell	Latitude XFR D630	23
Dell	Latitude XP	3
Dell	Latitude XT Tablet PC	23

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.
REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.
NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

	Model / Modèle / Modelo	
Dell	Latitude XT2	23
Dell	Latitude XT2 Tablet PC	23
Dell	Latitude XT2 XFR Tablet PC	23
Dell	Latitude Z	23
Dell	Latitude Z600	23
Dell	Studio 14	23
Dell	Studio 1435	23
Dell	Studio 1435n	23
Dell	Studio 1436	23
Dell	Studio 1440	23
Dell	Studio 1440n	23
Dell	Studio 1440Z	23
Dell	Studio 1450	23
Dell	Studio 1457	23
Dell	Studio 1458	23
Dell	Studio 14z	23
Dell	Studio 14zn	23
Dell	Studio 15	23
Dell	Studio 1535	23
Dell	Studio 1536	23
Dell	Studio 1537	23
Dell	Studio 1555	23
Dell	Studio 1557	23
Dell	Studio 1558	23
Dell	Studio 1569	23
Dell	Studio 17	23
Dell	Studio 1735	23
Dell	Studio 1736	23
Dell	Studio 1737	23
Dell	Studio 1745	23
Dell	Studio 1747	23
Dell	Studio 1749	23
Dell	Studio XPS 13	23
Dell	Studio XPS 1340	23
Dell	Studio XPS 16	23
Dell	Studio XPS 1640	23
Dell	Studio XPS 1645	23
Dell	Studio XPS 1647	23
Dell	Vostro 1000	23

	Model / Modèle / Modelo	
Dell	Vostro 1014	23
Dell	Vostro 1015	23
Dell	Vostro 1200	23
Dell	Vostro 1220	23
Dell	Vostro 1220n	23
Dell	Vostro 13	23
Dell	Vostro 1310	23
Dell	Vostro 1320	23
Dell	Vostro 1400	23
Dell	Vostro 1440	23
Dell	Vostro 1500	23
Dell	Vostro 1510	23
Dell	Vostro 1520	23
Dell	Vostro 1540	23
Dell	Vostro 1700	23
Dell	Vostro 1710	23
Dell	Vostro 1720	23
Dell	Vostro 2420	23
Dell	Vostro 2510	23
Dell	Vostro 2520	23
Dell	Vostro 3300	23
Dell	Vostro 3350	23
Dell	Vostro 3360	23
Dell	Vostro 3400	23
Dell	Vostro 3460	23
Dell	Vostro 3500	23
Dell	Vostro 3560	23
Dell	Vostro 3700	23
Dell	Vostro 500	23
Dell	Vostro A840	23
Dell	Vostro A860	23
Dell	Vostro A860n	23
Dell	Vostro V131	23
Dell	Vostro V131D	23
Dell	Vostro V131R	23
Dell	Vostro V1710	23
Dell	Vostro V1720	23
Dell	XPS 14	23
Dell	XPS 14Z	23

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.
REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.
NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

Model / Modèle / Modelo		
Dell	XPS 15	23
Dell	XPS 15Z	23
Dell	XPS L401X	23
Dell	XPS L501X	23
Dell	XPS L502X	23
Dell	XPS M1210	23
Dell	XPS M1330	23
Dell	XPS M140	23
Dell	XPS M1500	23
Dell	XPS M1530	23
E-Machines	D525	32
E-Machines	D620	32
E-Machines	D725	32
E-Machines	E525	32
E-Machines	E527	32
E-Machines	E528	32
E-Machines	E620	32
E-Machines	E625	32
E-Machines	E627	32
E-Machines	E720	32
E-Machines	E725	32
E-Machines	E732	32
E-Machines	eMD525-2925	32
E-Machines	EMD528-2496	32
E-Machines	eMD620-5777	32
E-Machines	EME442	32
E-Machines	EME525-2200	41
E-Machines	M2105	5
E-Machines	M2350	41
E-Machines	M5000 Series	5
E-Machines	M6000 Series	5
Fujitsu	LifeBook A Series	41
Fujitsu	LifeBook C1010	41
Fujitsu	LifeBook C1020	41
Fujitsu	LifeBook C1320	41
Fujitsu	LifeBook C1320D	41
Fujitsu	LifeBook C1321	41
Fujitsu	LifeBook C1321D	41
Fujitsu	LifeBook C2110	41

Model / Modèle / Modelo		
Fujitsu	LifeBook C2111	41
Fujitsu	LifeBook C2210	41
Fujitsu	LifeBook C2220	41
Fujitsu	LifeBook C2230	41
Fujitsu	LifeBook C2310	41
Fujitsu	LifeBook C2320	41
Fujitsu	LifeBook C2330	41
Fujitsu	LifeBook C2340	41
Fujitsu	LifeBook C4175	41
Fujitsu	LifeBook C6175	41
Fujitsu	LifeBook C6185	41
Fujitsu	LifeBook C6597	41
Fujitsu	LifeBook E2010	41
Fujitsu	LifeBook E4010	41
Fujitsu	LifeBook E4010D	41
Fujitsu	LifeBook E7000 series	41
Fujitsu	LifeBook E751	41
Fujitsu	LifeBook E751/C	41
Fujitsu	LifeBook E752	41
Fujitsu	LifeBook E780	41
Fujitsu	LifeBook E8410	41
Fujitsu	LifeBook E8420	41
Fujitsu	LifeBook E8420E	41
Fujitsu	LifeBook E8420LA	41
Fujitsu	LifeBook L1010	41
Fujitsu	LifeBook LF700	41
Fujitsu	LifeBook LH532	41
Fujitsu	LifeBook N3410	41
Fujitsu	LifeBook N3500	41
Fujitsu	LifeBook N3510	41
Fujitsu	LifeBook N3511	41
Fujitsu	LifeBook N3520	41
Fujitsu	LifeBook N3530	41
Fujitsu	LifeBook N7010	41
Fujitsu	LifeBook NH532	41
Fujitsu	LifeBook NH570	41
Fujitsu	LifeBook P701	41
Fujitsu	LifeBook P701/C	41
Fujitsu	LifeBook P702	41

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.
REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.
NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

	Model / Modèle / Modelo	
Fujitsu	LifeBook P710	41
Fujitsu	LifeBook P770	41
Fujitsu	LifeBook P771	41
Fujitsu	LifeBook P771/C	41
Fujitsu	LifeBook P771A	41
Fujitsu	LifeBook P772	41
Fujitsu	LifeBook P8110	41
Fujitsu	LifeBook PH701	41
Fujitsu	LifeBook PH702	41
Fujitsu	LifeBook S561	41
Fujitsu	LifeBook S6310	41
Fujitsu	LifeBook S6311	41
Fujitsu	LifeBook S7010	41
Fujitsu	LifeBook S7010D	41
Fujitsu	LifeBook S7020	41
Fujitsu	LifeBook S7020D	41
Fujitsu	LifeBook S7111	41
Fujitsu	LifeBook S751	41
Fujitsu	LifeBook S751/C	41
Fujitsu	LifeBook S752	41
Fujitsu	LifeBook S760	41
Fujitsu	LifeBook S761	41
Fujitsu	LifeBook S761/C	41
Fujitsu	LifeBook S761/D	41
Fujitsu	LifeBook S762	41
Fujitsu	LifeBook SH561	41
Fujitsu	LifeBook SH761	41
Fujitsu	LifeBook T4010	41
Fujitsu	LifeBook T4010D	41
Fujitsu	LifeBook T4020	41
Fujitsu	LifeBook T4020D	41
Fujitsu	LifeBook T4210	41
Fujitsu	LifeBook T4215	41
Fujitsu	LifeBook T4220	41
Fujitsu	LifeBook T580	41
Fujitsu	LifeBook T580 Tablet PC	41
Fujitsu	LifeBook T731	41
Fujitsu	LifeBook T901	41
Fujitsu	LifeBook U772	41

	Model / Modèle / Modelo	
Gateway	200ARC	12
Gateway	200X	12
Gateway	200XL	12
Gateway	3520GZ	41
Gateway	3522GZ	41
Gateway	3525GB	41
Gateway	3545GZ	41
Gateway	3550GH	41
Gateway	3550GZ	41
Gateway	400SD4	41
Gateway	4012GZ	41
Gateway	4024GZ	41
Gateway	4025GZ	41
Gateway	4026GZ	41
Gateway	4028GZ	41
Gateway	4028JP	41
Gateway	4030GZ	41
Gateway	450RGH	41
Gateway	450ROG	41
Gateway	450S	41
Gateway	450SX4	41
Gateway	450X	41
Gateway	4520GZ	41
Gateway	4525GZ	41
Gateway	4530GH	41
Gateway	4530GZ	41
Gateway	4535GX	41
Gateway	4535GZ	41
Gateway	4536GZ	41
Gateway	4538GZ	41
Gateway	4540GZ	41
Gateway	4541BZ	41
Gateway	4542GP	41
Gateway	4543BZ	41
Gateway	600YG2	41
Gateway	600YGR	41
Gateway	6010GZ	41
Gateway	6018GH	41
Gateway	6018GZ	41

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.
REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.
NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

Model / Modèle / Modelo		
Gateway	6020GZ	41
Gateway	6021GH	41
Gateway	6021GZ	41
Gateway	6022GZ	41
Gateway	6023GP	41
Gateway	6510GZ	41
Gateway	6518GZ	41
Gateway	6520GZ	41
Gateway	6525GP	41
Gateway	6531GZ	41
Gateway	6834MX	41
Gateway	7110GX	41
Gateway	7305GZ	41
Gateway	7324GZ	41
Gateway	7325GZ	41
Gateway	7326GZ	41
Gateway	7405GH	5
Gateway	7405GX	5
Gateway	7410GX	5
Gateway	7415GX	41
Gateway	7422GX	5
Gateway	7422GZ	5
Gateway	7426GX	5
Gateway	7430JP	5
Gateway	7508GX	5
Gateway	7510GX	5
Gateway	7510GZ	5
Gateway	8510GH	41
Gateway	8510GZ	41
Gateway	8515GZ	41
Gateway	C120X	41
Gateway	C-141X	41
Gateway	C-5815	41
Gateway	CX200S	41
Gateway	CX200X	41
Gateway	CX210	41
Gateway	CX210X	41
Gateway	CX2608	41
Gateway	CX2610	41

Model / Modèle / Modelo		
Gateway	CX2615	41
Gateway	CX2618	41
Gateway	CX2619	41
Gateway	CX2620	41
Gateway	CX2720	41
Gateway	CX2724	41
Gateway	CX2726	41
Gateway	CX2728	41
Gateway	E-100M	41
Gateway	E-155C	41
Gateway	E-265M	41
Gateway	E-295	41
Gateway	E-475M	41
Gateway	EMD525-2925	32
Gateway	EMD620-5777	32
Gateway	EME525-2200	41
Gateway	ID47H Series	32
Gateway	ID49C	41
Gateway	LT3201U	32
Gateway	M-1408J	41
Gateway	M-1410J	41
Gateway	M-1411J	41
Gateway	M-1412	41
Gateway	M-150S	41
Gateway	M-150X	41
Gateway	M-151 Series	41
Gateway	M-152 Series	41
Gateway	M-153 Series	41
Gateway	M-1615	41
Gateway	M-1617	41
Gateway	M-1618	41
Gateway	M-1618N	41
Gateway	M-1618R	41
Gateway	M-1619J	41
Gateway	M-1622	41
Gateway	M-1622H	41
Gateway	M-1624	41
Gateway	M-1625	41
Gateway	M-1626	41

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.
REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.
NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

	Model / Modèle / Modelo	
Gateway	M-1628	41
Gateway	M-1629	41
Gateway	M-1630J	41
Gateway	M-1631J	41
Gateway	M-1632J	41
Gateway	M-1634U	41
Gateway	M-2000	41
Gateway	M210	41
Gateway	M-2400 Series	41
Gateway	M250	41
Gateway	M255-E	41
Gateway	M-2623U	41
Gateway	M-2624U	41
Gateway	M-2625U	41
Gateway	M-2626U	41
Gateway	M280	41
Gateway	M280E	41
Gateway	M285-E	41
Gateway	M285-E SB	41
Gateway	M320	41
Gateway	M320S	41
Gateway	M320X	41
Gateway	M320XL	41
Gateway	M325	41
Gateway	M360	41
Gateway	M360A	41
Gateway	M360B	41
Gateway	M360C	41
Gateway	M460B	41
Gateway	M460QS	41
Gateway	M465-E	41
Gateway	M465-E SB	41
Gateway	M465-G	41
Gateway	M-6205M	41
Gateway	M-6206M	41
Gateway	M-6207M	41
Gateway	M-6300	41
Gateway	M-6705	41
Gateway	M-6750	41

	Model / Modèle / Modelo	
Gateway	M-6750H	41
Gateway	M-6752	41
Gateway	M-6755	41
Gateway	M680	41
Gateway	M-6800 Series	41
Gateway	M-7000	41
Gateway	MC7801	41
Gateway	MC7825U	32
Gateway	MD2419U	41
Gateway	MD2601U	41
Gateway	MD2614U	41
Gateway	MD7309U	41
Gateway	MD7334U	32
Gateway	MD7801U	41
Gateway	MD7818U	41
Gateway	MD7822U	41
Gateway	ML3109	41
Gateway	ML3706	41
Gateway	ML6226b	41
Gateway	ML6228	41
Gateway	ML6228h	41
Gateway	ML6230	41
Gateway	ML6232	41
Gateway	ML6714	41
Gateway	ML6720	41
Gateway	ML6721	41
Gateway	ML6725	41
Gateway	ML6732	41
Gateway	MP6954	41
Gateway	MP8708	41
Gateway	MP8709	41
Gateway	MS2273	32
Gateway	MS2274	32
Gateway	MS2285	41
Gateway	MT3418	41
Gateway	MT3419	41
Gateway	MT3421	41
Gateway	MT3422	41
Gateway	MT3423	41

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.

REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.

NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

	Model / Modèle / Modelo	
Gateway	MT3705	41
Gateway	MT3707	41
Gateway	MT3707b	41
Gateway	MT6000	41
Gateway	MX1023	41
Gateway	MX1023h	41
Gateway	MX1025	41
Gateway	MX1026	41
Gateway	MX1027	41
Gateway	MX3000	41
Gateway	MX6000	41
Gateway	MX7000	41
Gateway	MX8500	41
Gateway	MX8700	41
Gateway	NE51B	32
Gateway	NE56R	32
Gateway	NE71B	32
Gateway	NV49C	32
Gateway	NV50A	32
Gateway	NV51B	32
Gateway	NV5200	32
Gateway	NV52L	32
Gateway	NV53	32
Gateway	NV53A	32
Gateway	NV54	32
Gateway	NV55C	32
Gateway	NV55S	32
Gateway	NV56R	32
Gateway	NV57H	32
Gateway	NV59	32
Gateway	NV59C	32
Gateway	NV59Z	32
Gateway	NV75	32
Gateway	NV76R	32
Gateway	NV77H	32
Gateway	NV78	41
Gateway	NV79C	32
Gateway	NX100X	41
Gateway	NX200	41

	Model / Modèle / Modelo	
Gateway	NX500	41
Gateway	NX850X	41
Gateway	NX850XL	41
Gateway	NX860	41
Gateway	NX860S	41
Gateway	NX860X	41
Gateway	NX860XL	41
Gateway	P-170	41
Gateway	P-6000	41
Gateway	S-7000	41
Gateway	T-140X	41
Gateway	T-1600	41
Gateway	T-6000	41
Gateway	W322	41
Gateway	W340UI	41
Gateway	W350A	41
Gateway	W350i	41
Gateway	W6501	41
Gateway	W650i	41
Hewlett Packard	2000 Series	55
Hewlett Packard	EliteBook 2530p	55
Hewlett Packard	EliteBook 2540p	55
Hewlett Packard	EliteBook 2560p	55
Hewlett Packard	EliteBook 2730p	55
Hewlett Packard	EliteBook 2740p	55
Hewlett Packard	EliteBook 2760p	55
Hewlett Packard	EliteBook 8440P	55
Hewlett Packard	EliteBook 8440w	55
Hewlett Packard	EliteBook 8460p	55
Hewlett Packard	EliteBook 8460w	55
Hewlett Packard	EliteBook 8560p	55
Hewlett Packard	Envy 13-1000 Series	5
Hewlett Packard	Envy 14	55
Hewlett Packard	Envy 14 Spectre	55
Hewlett Packard	Envy 14-1000 Series	55
Hewlett Packard	Envy 14-2000 Series	55
Hewlett Packard	Envy 14-3010NR Spectre	55
Hewlett Packard	Envy 14-3090CA	55
Hewlett Packard	Envy 14-3210nr	55

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.
REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.
NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

	Model / Modèle / Modelo	
Hewlett Packard	Envy 14t-1100 CTO	55
Hewlett Packard	Envy 14t-3000	55
Hewlett Packard	Envy 15-1000 Series	55
Hewlett Packard	Envy 15t-3000	55
Hewlett Packard	Envy 17 Series	55
Hewlett Packard	Envy 17-1000 series	55
Hewlett Packard	Envy 17-1200	55
Hewlett Packard	Envy 17-2000	55
Hewlett Packard	Envy 17-3000	55
Hewlett Packard	Envy 17t	55
Hewlett Packard	Envy 4-1030CA	5
Hewlett Packard	Envy 4-1050CA	5
Hewlett Packard	Envy 4-1195CA-T	5
Hewlett Packard	Envy 6-1000	55
Hewlett Packard	Envy DV4-5200	55
Hewlett Packard	Envy DV4-5300 Series	55
Hewlett Packard	Envy DV4T-5200 CTO	55
Hewlett Packard	Envy DV4T-5300	55
Hewlett Packard	Envy DV6-7200 Series	55
Hewlett Packard	Envy DV6-7300	55
Hewlett Packard	Envy DV6T-7200 Series	55
Hewlett Packard	Envy DV6T-7300 Series	55
Hewlett Packard	Envy DV6Z-7200	55
Hewlett Packard	Envy DV7-7200 Series	55
Hewlett Packard	Envy DV7-7300 Series	55
Hewlett Packard	Envy DV7t-7200	55
Hewlett Packard	Envy DV7t-7300 Series	55
Hewlett Packard	Envy M4-1015DX	55
Hewlett Packard	Envy M4-1115DX	55
Hewlett Packard	Envy M6-1100	55
Hewlett Packard	Envy Sleekbook 6-1000	55
Hewlett Packard	Envy Sleekbook 6z-1000	55
Hewlett Packard	Envy Sleekbook 6z-1100	55
Hewlett Packard	Envy Spectre 14t-3200	55
Hewlett Packard	Envy Spectre XT 13-2000 Series	5
Hewlett Packard	Envy Spectre XT Pro	5
Hewlett Packard	Envy Spectre XT Ultrabook 13t-2000	5
Hewlett Packard	Envy Spectre XT Ultrabook 15t-4000	5
Hewlett Packard	Envy TouchSmart UltraBook 4-1215DX	5
Hewlett Packard	Envy Ultrabook 4-1050ca	5
Hewlett Packard	Envy Ultrabook 4t-1100	55
Hewlett Packard	G4 Series	55
Hewlett Packard	G4-1000 Series	55
Hewlett Packard	G4-1300 Series	55
Hewlett Packard	G42 Series	55
Hewlett Packard	G4-2000 Series	55
Hewlett Packard	G42t	55
Hewlett Packard	G50 Series	55
Hewlett Packard	G5000 Series	5
Hewlett Packard	G56 Series	55
Hewlett Packard	G56-100 series	55
Hewlett Packard	G6 Series	55
Hewlett Packard	G60 Series	55
Hewlett Packard	G6000 Series	5
Hewlett Packard	G61 Series	55
Hewlett Packard	G6-1000 series	55
Hewlett Packard	G6-1300 Series	55
Hewlett Packard	G6-1a00 Series	55
Hewlett Packard	G6-1b00 Series	55
Hewlett Packard	G6-1c00 Series	55
Hewlett Packard	G6-1d00 Series	55
Hewlett Packard	G62 Series	55
Hewlett Packard	G6-2000 Series	55
Hewlett Packard	G62-100 series	55
Hewlett Packard	G62-400 series	55
Hewlett Packard	G62-a00 series	55
Hewlett Packard	G62-b00 series	55
Hewlett Packard	G62x	55
Hewlett Packard	G7 Series	55
Hewlett Packard	G70 Series	55
Hewlett Packard	G7000 Series	5
Hewlett Packard	G71 Series	55
Hewlett Packard	G7-1000 Series	55
Hewlett Packard	G72 Series	55
Hewlett Packard	G7-2000 Series	55

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.

REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.

NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

Model / Modèle / Modelo		
Hewlett Packard	G72-100 series	55
Hewlett Packard	G72-a00 series	55
Hewlett Packard	G72-b00 series	55
Hewlett Packard	HDX 16 Series	55
Hewlett Packard	HDX 18 Series	55
Hewlett Packard	HDX X16-1000 Series	55
Hewlett Packard	HDX X18-1100	55
Hewlett Packard	HDX X18-1200	55
Hewlett Packard	HDX X18-1300	55
Hewlett Packard	HDX16	55
Hewlett Packard	HDX16t	55
Hewlett Packard	HDX18-1101EG	55
Hewlett Packard	Mini 2140	55
Hewlett Packard	Mini 311-1000 series	5
Hewlett Packard	Mini Note 2133	55
Hewlett Packard	Mini Note 2140	55
Hewlett Packard	Mobile Workstation NW8000	5
Hewlett Packard	Pavilion DM1-1000 Series	5
Hewlett Packard	Pavilion DM1-2000 Series	55
Hewlett Packard	Pavilion DM1-3000 series	55
Hewlett Packard	Pavilion DM1-4000 Series	55
Hewlett Packard	Pavilion DM1Z	55
Hewlett Packard	Pavilion DM3-1000 Series	5
Hewlett Packard	Pavilion DM3-3000 Series	55
Hewlett Packard	Pavilion DM4-1000 series	55
Hewlett Packard	Pavilion DM4-1100 series	55
Hewlett Packard	Pavilion DM4-2000 series	55
Hewlett Packard	Pavilion DM4-3000 Series	55
Hewlett Packard	Pavilion DV1000 series	5
Hewlett Packard	Pavilion DV2000 Series	5
Hewlett Packard	Pavilion DV2-1000 series	5
Hewlett Packard	Pavilion DV2200 Series	5
Hewlett Packard	Pavilion DV2700 Series	5
Hewlett Packard	Pavilion DV3000 Series	55
Hewlett Packard	Pavilion DV3-1000 series	55
Hewlett Packard	Pavilion DV3-2000 series	55
Hewlett Packard	Pavilion DV3-4000 series	55
Hewlett Packard	Pavilion DV3500	55
Hewlett Packard	Pavilion DV3600	55

Model / Modèle / Modelo		
Hewlett Packard	Pavilion DV4 Series	55
Hewlett Packard	Pavilion DV4000 series	5
Hewlett Packard	Pavilion DV4-1000 series	55
Hewlett Packard	Pavilion DV4-2000 series	55
Hewlett Packard	Pavilion DV4-5000 Series	55
Hewlett Packard	Pavilion DV4i	55
Hewlett Packard	Pavilion DV4T	55
Hewlett Packard	Pavilion DV4T-4200	55
Hewlett Packard	Pavilion DV5000 series	5
Hewlett Packard	Pavilion DV5-1000 series	55
Hewlett Packard	Pavilion DV5-2000 series	55
Hewlett Packard	Pavilion DV5t	55
Hewlett Packard	Pavilion DV5t-1000	55
Hewlett Packard	Pavilion DV5z	55
Hewlett Packard	Pavilion DV5z-1000	55
Hewlett Packard	Pavilion DV6 Series	55
Hewlett Packard	Pavilion DV6000 Series	5
Hewlett Packard	Pavilion DV6-1000 series	55
Hewlett Packard	Pavilion DV6-2000 series	55
Hewlett Packard	Pavilion DV6-3000 series	55
Hewlett Packard	Pavilion DV6-4000 Series	55
Hewlett Packard	Pavilion DV6-6000 series	55
Hewlett Packard	Pavilion DV6-7000 Series	55
Hewlett Packard	Pavilion DV6-8000 Series	55
Hewlett Packard	Pavilion DV6T	5
Hewlett Packard	Pavilion DV6z	55
Hewlett Packard	Pavilion DV7-1000 series	55
Hewlett Packard	Pavilion DV7-2000 series	55
Hewlett Packard	Pavilion DV7-3000 Series	55
Hewlett Packard	Pavilion DV7-4000 series	55
Hewlett Packard	Pavilion DV7-6000 Series	55
Hewlett Packard	Pavilion DV7-7000 Series	55
Hewlett Packard	Pavilion DV7T Series	55
Hewlett Packard	Pavilion DV8000 Series	5
Hewlett Packard	Pavilion DV9000 Series	5
Hewlett Packard	Pavilion DX6000	5
Hewlett Packard	Pavilion G4 Series	55
Hewlett Packard	Pavilion G4-1000 Series	55
Hewlett Packard	Pavilion G50 Series	55

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.
REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.
NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

	Model / Modèle / Modelo	
Hewlett Packard	Pavilion G6 Series	55
Hewlett Packard	Pavilion G60 Series	55
Hewlett Packard	Pavilion G7 Series	55
Hewlett Packard	Pavilion G7-1000 Series	55
Hewlett Packard	Pavilion G7-2000 Series	55
Hewlett Packard	Pavilion HDX 16	55
Hewlett Packard	Pavilion M6-1000	55
Hewlett Packard	Pavilion M7	55
Hewlett Packard	Pavilion N3000 series	41
Hewlett Packard	Pavilion N5100 series	41
Hewlett Packard	Pavilion N5200 series	41
Hewlett Packard	Pavilion N5300 series	41
Hewlett Packard	Pavilion N5400 series	41
Hewlett Packard	Pavilion N5500 series	41
Hewlett Packard	Pavilion N6000 series	41
Hewlett Packard	Pavilion Sleekbook 14	5
Hewlett Packard	Pavilion Sleekbook 15	5
Hewlett Packard	Pavilion tx1000 Series	5
Hewlett Packard	Pavilion tx2000 Series	5
Hewlett Packard	Pavilion XF series	41
Hewlett Packard	Pavilion XH series	41
Hewlett Packard	Pavilion XT series	41
Hewlett Packard	Pavilion XZ series	41
Hewlett Packard	Pavilion ZE1000 series	41
Hewlett Packard	Pavilion ZE2000 series	5
Hewlett Packard	Pavilion ZE4000 Series	41
Hewlett Packard	Pavilion ZE5000 series	41
Hewlett Packard	Pavilion ZT series	41
Hewlett Packard	Special Edition L2000 (LiveStrong)	5
Hewlett Packard	Special Edition L2000 series	5
Hewlett Packard	Spectre 14t-3200	55
Hewlett Packard	Spectre XT 13	5
Hewlett Packard	Spectre XT Pro	5
Hewlett Packard	SpectreXT TouchSmart 15-4010nr	5
Hewlett Packard	Tablet PC TC1100	5
Hewlett Packard	Tablet PC TC4200	5
Hewlett Packard	TouchSmart TM2-1000	55
Hewlett Packard	TouchSmart TM2-2000	55
Hewlett Packard	TouchSmart TM2t	55

	Model / Modèle / Modelo	
Hewlett Packard	TouchSmart TX2-1020US	5
Hewlett Packard	TouchSmart TX2-1025DX	5
Hewlett Packard	TouchSmart TX2-1375DX	5
HP/Compaq	Business Notebook 2510p	55
HP/Compaq	Business Notebook 2710p	55
HP/Compaq	Business Notebook 510	5
HP/Compaq	Business Notebook 515	55
HP/Compaq	Business Notebook 516	55
HP/Compaq	Business Notebook 530	5
HP/Compaq	Business Notebook 540	55
HP/Compaq	Business Notebook 541	55
HP/Compaq	Business Notebook 6510b	55
HP/Compaq	Business Notebook 6515b	55
HP/Compaq	Business Notebook 6520s	55
HP/Compaq	Business Notebook 6530B	55
HP/Compaq	Business Notebook 6530S	55
HP/Compaq	Business Notebook 6531S	55
HP/Compaq	Business Notebook 6535B	55
HP/Compaq	Business Notebook 6535S	55
HP/Compaq	Business Notebook 6710b	55
HP/Compaq	Business Notebook 6710s	55
HP/Compaq	Business Notebook 6715b	55
HP/Compaq	Business Notebook 6715s	55
HP/Compaq	Business Notebook 6720s	5
HP/Compaq	Business Notebook 6730B	55
HP/Compaq	Business Notebook 6730S	55
HP/Compaq	Business Notebook 6735B	55
HP/Compaq	Business Notebook 6910p	55
HP/Compaq	Business NoteBook 8510p	55
HP/Compaq	Business Notebook N1050V	41
HP/Compaq	Business Notebook NC2400	55
HP/Compaq	Business Notebook NC4000	5
HP/Compaq	Business Notebook NC4010	5
HP/Compaq	Business Notebook NC4200	5
HP/Compaq	Business Notebook NC6000	5
HP/Compaq	Business Notebook NC6100	5
HP/Compaq	Business Notebook NC6110	55
HP/Compaq	Business Notebook NC6120	5
HP/Compaq	Business Notebook NC6125	5

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.

REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.

NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

	Model / Modèle / Modelo	
HP/Compaq	Business Notebook NC6140	55
HP/Compaq	Business Notebook NC6200	5
HP/Compaq	Business Notebook NC6220	5
HP/Compaq	Business Notebook NC6230	5
HP/Compaq	Business Notebook NC6320	55
HP/Compaq	Business Notebook NC6325	5
HP/Compaq	Business Notebook NC6400	55
HP/Compaq	Business Notebook NC8000	5
HP/Compaq	Business Notebook NC8200	5
HP/Compaq	Business Notebook NC8230	5
HP/Compaq	Business Notebook NC8430	55
HP/Compaq	Business Notebook NW8000	5
HP/Compaq	Business Notebook NW8200	5
HP/Compaq	Business Notebook NW8240	5
HP/Compaq	Business Notebook NW8440	55
HP/Compaq	Business Notebook NX4800	5
HP/Compaq	Business Notebook NX4820	5
HP/Compaq	Business Notebook NX5000	5
HP/Compaq	Business Notebook NX6100	5
HP/Compaq	Business Notebook NX6110	5
HP/Compaq	Business Notebook NX6115	55
HP/Compaq	Business Notebook NX6120	5
HP/Compaq	Business Notebook NX6125	5
HP/Compaq	Business Notebook NX6130	5
HP/Compaq	Business Notebook NX6310	55
HP/Compaq	Business Notebook NX6315	55
HP/Compaq	Business Notebook NX6320	55
HP/Compaq	Business Notebook NX6325	55
HP/Compaq	Business Notebook NX6330	55
HP/Compaq	Business Notebook NX7000	5
HP/Compaq	Business Notebook NX7010	5
HP/Compaq	Business Notebook NX7100	5
HP/Compaq	Business Notebook NX7300	55
HP/Compaq	Business Notebook NX7400	55
HP/Compaq	Business Notebook NX8200	5
HP/Compaq	Business Notebook NX8220	5
HP/Compaq	Business Notebook NX8410	55
HP/Compaq	Business Notebook NX8420	55
HP/Compaq	Business Notebook NX9000	41

	Model / Modèle / Modelo	
HP/Compaq	Business Notebook NX9005	41
HP/Compaq	Business Notebook NX9010	41
HP/Compaq	Business Notebook NX9020	5
HP/Compaq	Business Notebook NX9030	5
HP/Compaq	Business Notebook NX9040	5
HP/Compaq	Business Notebook NX9420	55
HP/Compaq	ProBook 4320s	55
HP/Compaq	ProBook 4320t	55
HP/Compaq	ProBook 4321s	55
HP/Compaq	ProBook 4325s	55
HP/Compaq	ProBook 4326s	55
HP/Compaq	ProBook 4330s	55
HP/Compaq	ProBook 4331s	55
HP/Compaq	ProBook 4410s	55
HP/Compaq	ProBook 4411s	55
HP/Compaq	ProBook 4415s	55
HP/Compaq	ProBook 4416s	55
HP/Compaq	ProBook 4420s	55
HP/Compaq	ProBook 4421s	55
HP/Compaq	ProBook 4425s	55
HP/Compaq	ProBook 4430s	55
HP/Compaq	ProBook 4431s	55
HP/Compaq	ProBook 4435s	55
HP/Compaq	ProBook 4436s	55
HP/Compaq	ProBook 4510s	55
HP/Compaq	ProBook 4515s	55
HP/Compaq	ProBook 4520s	55
HP/Compaq	ProBook 4525s	55
HP/Compaq	ProBook 4530s	55
HP/Compaq	ProBook 4535s	55
HP/Compaq	ProBook 4540	55
HP/Compaq	ProBook 4710s	55
HP/Compaq	ProBook 4720s	55
HP/Compaq	ProBook 4730s	55
HP/Compaq	ProBook 5330m	55
HP/Compaq	ProBook 6360b	55
HP/Compaq	ProBook 6450b	55
HP/Compaq	ProBook 6455b	55
HP/Compaq	ProBook 6460b	55

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.
REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.
NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

	Model / Modèle / Modelo	
HP/Compaq	ProBook 6465b	55
HP/Compaq	ProBook 6470b	55
HP/Compaq	ProBook 6475b	55
HP/Compaq	ProBook 6560b	55
HP/Compaq	ProBook 6565b	55
HP/Compaq	ProBook 6570b	55
Lenovo	3000 C100	44
Lenovo	3000 C200	44
Lenovo	3000 G400	41
Lenovo	3000 G410	41
Lenovo	3000 G430	41
Lenovo	3000 G450	41
Lenovo	3000 G510	41
Lenovo	3000 G530	41
Lenovo	3000 N100	44
Lenovo	3000 N200	44
Lenovo	3000 N500	41
Lenovo	3000 V100	44
Lenovo	3000 V200	44
Lenovo	3000 Y400	41
Lenovo	3000 Y410	41
Lenovo	3000 Y500	41
Lenovo	3000 Y510	41
Lenovo	Essential B570	41
Lenovo	Essential G455	41
Lenovo	Essential G460	41
Lenovo	Essential G550	41
Lenovo	Essential G555	41
Lenovo	Essential G560	41
Lenovo	Essential G570	41
Lenovo	Essential G575	41
Lenovo	Essential G770	41
Lenovo	IdeaPad B470	41
Lenovo	IdeaPad B560	41
Lenovo	IdeaPad B570	41
Lenovo	IdeaPad B575	41
Lenovo	IdeaPad G430	41
Lenovo	IdeaPad G460	41
Lenovo	IdeaPad G465	41

	Model / Modèle / Modelo	
Lenovo	IdeaPad G470	41
Lenovo	IdeaPad G475	41
Lenovo	IdeaPad G480	41
Lenovo	IdeaPad G485	41
Lenovo	IdeaPad G530	41
Lenovo	IdeaPad G550	41
Lenovo	IdeaPad G560	41
Lenovo	IdeaPad G565	41
Lenovo	IdeaPad G570	41
Lenovo	IdeaPad G575	41
Lenovo	IdeaPad G580	41
Lenovo	IdeaPad G585	41
Lenovo	IdeaPad P580	41
Lenovo	IdeaPad P585	41
Lenovo	IdeaPad U150	41
Lenovo	IdeaPad U300	41
Lenovo	IdeaPad U310	41
Lenovo	IdeaPad U330	41
Lenovo	IdeaPad U400	41
Lenovo	IdeaPad U410	41
Lenovo	IdeaPad U450P	41
Lenovo	IdeaPad U510	44
Lenovo	IdeaPad V350	41
Lenovo	IdeaPad V360	41
Lenovo	IdeaPad V370	41
Lenovo	IdeaPad V430a	41
Lenovo	IdeaPad V450a	41
Lenovo	IdeaPad V470	41
Lenovo	IdeaPad V560	41
Lenovo	IdeaPad V570	41
Lenovo	IdeaPad Y310	41
Lenovo	IdeaPad Y330	41
Lenovo	IdeaPad Y400	41
Lenovo	IdeaPad Y410	41
Lenovo	IdeaPad Y430	41
Lenovo	IdeaPad Y510	41
Lenovo	IdeaPad Y530	41
Lenovo	IdeaPad Y550	41
Lenovo	IdeaPad Y560	41

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.

REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.

NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

Model / Modèle / Modelo		
Lenovo	IdeaPad Y570	41
Lenovo	IdeaPad Y710	41
Lenovo	IdeaPad Y730	41
Lenovo	IdeaPad Z370	41
Lenovo	IdeaPad Z380	41
Lenovo	IdeaPad Z460	41
Lenovo	IdeaPad Z465	41
Lenovo	IdeaPad Z470	41
Lenovo	IdeaPad Z560	41
Lenovo	IdeaPad Z565	41
Lenovo	IdeaPad Z570	41
Lenovo	IdeaPad Z575	41
Lenovo	IdeaPad Z580	44
Lenovo	IdeaPad Z585	44
Lenovo	ThinkPad E120	44
Lenovo	ThinkPad E220s	44
Lenovo	ThinkPad E40	44
Lenovo	ThinkPad E50	44
Lenovo	ThinkPad Edge 13"	44
Lenovo	ThinkPad Edge 14"	44
Lenovo	ThinkPad Edge 15"	44
Lenovo	ThinkPad Edge E120	44
Lenovo	ThinkPad Edge E125	44
Lenovo	ThinkPad Edge E130	44
Lenovo	ThinkPad Edge E135	44
Lenovo	ThinkPad Edge E220s	44
Lenovo	ThinkPad Edge E320	44
Lenovo	ThinkPad Edge E325	44
Lenovo	ThinkPad Edge E330	44
Lenovo	ThinkPad Edge E335	44
Lenovo	ThinkPad Edge E420	44
Lenovo	ThinkPad Edge E520	44
Lenovo	ThinkPad Edge E525	44
Lenovo	ThinkPad L412	44
Lenovo	ThinkPad L430	44
Lenovo	ThinkPad L512	44
Lenovo	ThinkPad L530	44
Lenovo	ThinkPad R400 7443	44
Lenovo	ThinkPad R500	44

Model / Modèle / Modelo		
Lenovo	ThinkPad R60	44
Lenovo	ThinkPad R60e	44
Lenovo	ThinkPad R61	44
Lenovo	ThinkPad R61 (14.1" widescreen)	44
Lenovo	ThinkPad R61e	44
Lenovo	ThinkPad R61e (15.4" widescreen)	44
Lenovo	ThinkPad R61i (15.4" widescreen)	44
Lenovo	ThinkPad R61i Series (14.1" widescreen)	44
Lenovo	ThinkPad Reserve Edition 8748	44
Lenovo	ThinkPad SL400	44
Lenovo	ThinkPad SL410	44
Lenovo	ThinkPad SL500	44
Lenovo	ThinkPad SL510	44
Lenovo	ThinkPad T400	44
Lenovo	ThinkPad T400s	44
Lenovo	ThinkPad T410	44
Lenovo	ThinkPad T420	44
Lenovo	ThinkPad T430	44
Lenovo	ThinkPad T500	44
Lenovo	ThinkPad T510	44
Lenovo	ThinkPad T510i	44
Lenovo	ThinkPad T520	44
Lenovo	ThinkPad T530	44
Lenovo	ThinkPad T60	44
Lenovo	ThinkPad T60p	44
Lenovo	ThinkPad T61	44
Lenovo	ThinkPad Twist	44
Lenovo	ThinkPad Twist 12.5" Touchscreen Ultrabook (Black)	44
Lenovo	ThinkPad Twist S230u	44
Lenovo	ThinkPad W500	44
Lenovo	ThinkPad X1	44
Lenovo	ThinkPad X1 Carbon	44
Lenovo	ThinkPad X100e	44
Lenovo	ThinkPad X120e	44
Lenovo	ThinkPad X121e	44
Lenovo	ThinkPad X130e	44
Lenovo	ThinkPad X200	44

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.
REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.
NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

	Model / Modèle / Modelo	
Lenovo	ThinkPad X201	44
Lenovo	ThinkPad X220	44
Lenovo	ThinkPad X230	44
Lenovo	ThinkPad X300	44
Lenovo	ThinkPad X301	44
Lenovo	ThinkPad X60	44
Lenovo	ThinkPad X60s	44
Lenovo	ThinkPad Z60m	44
Lenovo	ThinkPad Z60t	44
Lenovo	ThinkPad Z61e	44
Lenovo	ThinkPad Z61m	44
Lenovo	ThinkPad Z61p	44
Lenovo	ThinkPad Z61t	44
Samsung	N150	12
Samsung	NP200A	12
Samsung	NP300E	12
Samsung	NP300V	12
Samsung	NP305E5A	12
Samsung	NP305E7A	12
Samsung	NP305V5A	12
Samsung	NP350V5C	12
Samsung	NP355V5C	12
Samsung	NP365E5C	12
Samsung	NP510R	12
Samsung	NP520U	12
Samsung	NP530	12
Samsung	NP535U4C	12
Samsung	NP550P5C	12
Samsung	NP550P7C	12
Samsung	NP600B4B	12
Samsung	NP700Z	12
Samsung	NP770Z7	12
Samsung	NP780Z5E	12
Samsung	NP-N110	12
Samsung	NP-N120	12
Samsung	NP-N150	12
Samsung	NP-Q320	12
Samsung	NP-Q430	12

	Model / Modèle / Modelo	
Samsung	NP-QX410	12
Samsung	NP-QX411	12
Samsung	NP-R430	12
Samsung	NP-R480	12
Samsung	NP-R519	12
Samsung	NP-R522	12
Samsung	NP-R530	12
Samsung	NP-R540	12
Samsung	NP-R580	12
Samsung	NP-R620	12
Samsung	NP-R780	12
Samsung	NP-RC512	12
Samsung	NP-RF511	12
Samsung	NP-RF711-S	12
Samsung	NP-RV510	12
Samsung	NP-RV511	12
Samsung	NP-RV515	12
Samsung	NP-RV520	12
Samsung	NP-RV711	12
Samsung	NP-SF410	12
Samsung	NP-SF510	12
Samsung	NP-SF511	12
Samsung	P460	12
Samsung	P560	12
Samsung	Q210	12
Samsung	Q310	12
Samsung	Q320	12
Samsung	Q430	12
Samsung	QX410	12
Samsung	R430	12
Samsung	R458	12
Samsung	R460	12
Samsung	R480	12
Samsung	R519	12
Samsung	R522	12
Samsung	R530	12
Samsung	R540	12
Samsung	R580	12
Samsung	R60	12

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.

REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.

NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

Model / Modèle / Modelo		
Samsung	R610	12
Samsung	R620	12
Samsung	R780	12
Samsung	RC512	12
Samsung	RF510	12
Samsung	RV510	12
Samsung	RV511	12
Samsung	RV515	12
Samsung	RV520	12
Samsung	RV711	12
Samsung	Series 2	12
Samsung	Series 3 NP300	12
Samsung	Series 3 NP305	12
Samsung	Series 3 NP350	12
Samsung	Series 3 NP-RV515	12
Samsung	Series 5 NP510	12
Samsung	Series 5 NP530	12
Samsung	Series 5 NP535	12
Samsung	Series 5 NP550	12
Samsung	Series 6	12
Samsung	Series 7 NP700	12
Samsung	Series 7 NP770	12
Samsung	Series 7 NP780	12
Samsung	SF410-A	12
Samsung	SF510-A	12
Samsung	V20	12
Samsung	VM-6000	12
Samsung	VM8000	41
Samsung	X460	12
Sony	VAIO SVE series	3
Sony	VAIO SVS series	3
Sony	VAIO SVZ series	3
Sony	VAIO VGC-LB	3
Sony	VAIO VGC-LJ series	3
Sony	VAIO VGN-A series	3
Sony	VAIO VGN-AR series	3
Sony	VAIO VGN-AW series	3
Sony	VAIO VGN-AX570	3
Sony	VAIO VGN-BX series	3

Model / Modèle / Modelo		
Sony	VAIO VGN-BZ series	3
Sony	VAIO VGN-C series	3
Sony	VAIO VGN-CR series	3
Sony	VAIO VGN-CS series	3
Sony	VAIO VGN-E series	3
Sony	VAIO VGN-FE series	3
Sony	VAIO VGN-FJ series	3
Sony	VAIO VGN-FS series	3
Sony	VAIO VGN-FW series	3
Sony	VAIO VGN-FZ series	3
Sony	VAIO VGN-N series	3
Sony	VAIO VGN-NR series	3
Sony	VAIO VGN-NS series	3
Sony	VAIO VGN-NW series	3
Sony	VAIO VGN-S series	3
Sony	VAIO VGN-SR series	3
Sony	VAIO VGN-SZ series	3
Sony	VAIO VGN-Z series	3
Sony	VAIO VPC-B series	3
Sony	VAIO VPC-CA series	3
Sony	VAIO VPC-CB series	3
Sony	VAIO VPC-CW series	3
Sony	VAIO VPC-EA series	3
Sony	VAIO VPC-EB series	3
Sony	VAIO VPC-EC series	3
Sony	VAIO VPC-EE series	3
Sony	VAIO VPC-EG series	3
Sony	VAIO VPC-EH series	3
Sony	VAIO VPC-EJ series	3
Sony	VAIO VPC-EK series	3
Sony	VAIO VPC-EL series	3
Sony	VAIO VPC-F series	3
Sony	VAIO VPC-M series	3
Sony	VAIO VPC-S series	3
Sony	VAIO VPC-SA series	3
Sony	VAIO VPC-SC series	3
Sony	VAIO VPC-SC1AFM/S	3
Sony	VAIO VPC-SE series	3
Sony	VAIO VPC-W series	3

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.
REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.
NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

	Model / Modèle / Modelo	
Sony	VAIO VPC-Y series	3
Sony	VAIO VPC-YA series	3
Sony	VAIO VPC-YB series	3
Sony	VAIO VPC-Z series	3
Toshiba	Portege M800	41
Toshiba	Portege R630	41
Toshiba	Portege R700	41
Toshiba	Portege R705	41
Toshiba	Portege R830	41
Toshiba	Portege R835	41
Toshiba	Portege R840	41
Toshiba	Portege R930	41
Toshiba	Portege R935 Series	41
Toshiba	Qosmio F45 series	41
Toshiba	Qosmio F60	41
Toshiba	Satellite A100	41
Toshiba	Satellite A105	41
Toshiba	Satellite A110	41
Toshiba	Satellite A130	41
Toshiba	Satellite A135	41
Toshiba	Satellite A200	41
Toshiba	Satellite A205	41
Toshiba	Satellite A215	41
Toshiba	Satellite A300	41
Toshiba	Satellite A305	41
Toshiba	Satellite A305D	41
Toshiba	Satellite A355	41
Toshiba	Satellite A355D	41
Toshiba	Satellite A505	41
Toshiba	Satellite A60	41
Toshiba	Satellite A660	41
Toshiba	Satellite A665	41
Toshiba	Satellite A665D	41
Toshiba	Satellite A80	41
Toshiba	Satellite A85 series	41
Toshiba	Satellite C600 Series	41
Toshiba	Satellite C645	41
Toshiba	Satellite C645D	41
Toshiba	Satellite C650	41

	Model / Modèle / Modelo	
Toshiba	Satellite C650D	41
Toshiba	Satellite C655	41
Toshiba	Satellite C655D	41
Toshiba	Satellite C675	41
Toshiba	Satellite C675D	41
Toshiba	Satellite C850 Series	41
Toshiba	Satellite C850D Series	41
Toshiba	Satellite C855 Series	41
Toshiba	Satellite C855D Series	41
Toshiba	Satellite C870 Series	41
Toshiba	Satellite C875 Series	41
Toshiba	Satellite C875D Series	41
Toshiba	Satellite E100	41
Toshiba	Satellite E105	41
Toshiba	Satellite E200	41
Toshiba	Satellite E205	41
Toshiba	Satellite L10	41
Toshiba	Satellite L15	41
Toshiba	Satellite L20	41
Toshiba	Satellite L25	41
Toshiba	Satellite L300	41
Toshiba	Satellite L300D	41
Toshiba	Satellite L305	41
Toshiba	Satellite L305D	41
Toshiba	Satellite L310	41
Toshiba	Satellite L315	41
Toshiba	Satellite L35	41
Toshiba	Satellite L355	41
Toshiba	Satellite L355D	41
Toshiba	Satellite L45	41
Toshiba	Satellite L450	41
Toshiba	Satellite L455	41
Toshiba	Satellite L455D	41
Toshiba	Satellite L500	41
Toshiba	Satellite L505	41
Toshiba	Satellite L505D	41
Toshiba	Satellite L505D-GS6000	41
Toshiba	Satellite L515	41
Toshiba	Satellite L550	41

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.

REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.

NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

	Model / Modèle / Modelo	
Toshiba	Satellite L550D	41
Toshiba	Satellite L555	41
Toshiba	Satellite L600	41
Toshiba	Satellite L630	41
Toshiba	Satellite L640	41
Toshiba	Satellite L640D	41
Toshiba	Satellite L645	41
Toshiba	Satellite L645D	41
Toshiba	Satellite L650	41
Toshiba	Satellite L650D	41
Toshiba	Satellite L655	41
Toshiba	Satellite L655D	41
Toshiba	Satellite L670	41
Toshiba	Satellite L675	41
Toshiba	Satellite L675D	41
Toshiba	Satellite L735	41
Toshiba	Satellite L735D	41
Toshiba	Satellite L740	41
Toshiba	Satellite L745D	41
Toshiba	Satellite L750 Series	41
Toshiba	Satellite L750D	41
Toshiba	Satellite L755	41
Toshiba	Satellite L755D Series	41
Toshiba	Satellite L770	41
Toshiba	Satellite L775	41
Toshiba	Satellite L775D	41
Toshiba	Satellite L840	41
Toshiba	Satellite L850	41
Toshiba	Satellite L850	41
Toshiba	Satellite L850D Series	41
Toshiba	Satellite L855 Series	41
Toshiba	Satellite L855D	41
Toshiba	Satellite L870 Series	41
Toshiba	Satellite L870D Series	41
Toshiba	Satellite L875 Series	41
Toshiba	Satellite L875D Series	41
Toshiba	Satellite M105	41
Toshiba	Satellite M115	41
Toshiba	Satellite M200	41

	Model / Modèle / Modelo	
Toshiba	Satellite M205	41
Toshiba	Satellite M300	41
Toshiba	Satellite M305	41
Toshiba	Satellite M305D	41
Toshiba	Satellite M30X series	41
Toshiba	Satellite M35X series	41
Toshiba	Satellite M45	41
Toshiba	Satellite M505	41
Toshiba	Satellite M505D	41
Toshiba	Satellite M55	41
Toshiba	Satellite M60 series	41
Toshiba	Satellite M645	41
Toshiba	Satellite M65	41
Toshiba	Satellite M70	41
Toshiba	Satellite P205	41
Toshiba	Satellite P205D	41
Toshiba	Satellite P305	41
Toshiba	Satellite P305D	41
Toshiba	Satellite P305D-S8828	41
Toshiba	Satellite P500	41
Toshiba	Satellite P505	41
Toshiba	Satellite P505D	41
Toshiba	Satellite P505-S8941	41
Toshiba	Satellite P740	41
Toshiba	Satellite P745	41
Toshiba	Satellite P755	41
Toshiba	Satellite P755D Series	41
Toshiba	Satellite P775	41
Toshiba	Satellite P775D	41
Toshiba	Satellite P840 Series	41
Toshiba	Satellite P845 Series	41
Toshiba	Satellite P850 Series	41
Toshiba	Satellite P855 Series	41
Toshiba	Satellite P870 Series	41
Toshiba	Satellite P875 Series	41
Toshiba	Satellite Pro A200	41
Toshiba	Satellite Pro C650	41
Toshiba	Satellite Pro L300 Series	41
Toshiba	Satellite Pro L630	41

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.
REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.
NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

	Model / Modèle / Modelo	
Toshiba	Satellite Pro L640	41
Toshiba	Satellite Pro L650	41
Toshiba	Satellite Pro M300	41
Toshiba	Satellite Pro P300	41
Toshiba	Satellite Pro R850	41
Toshiba	Satellite Pro U400	41
Toshiba	Satellite R630	41
Toshiba	Satellite R830	41
Toshiba	Satellite R845 Series	41
Toshiba	Satellite R850	41
Toshiba	Satellite S850	41
Toshiba	Satellite S855 Series	41
Toshiba	Satellite S855D Series	41
Toshiba	Satellite S870 Series	41
Toshiba	Satellite S875 Series	41
Toshiba	Satellite T135	41
Toshiba	Satellite T135D	41
Toshiba	Satellite T215D	41
Toshiba	Satellite T235	41
Toshiba	Satellite T235D	41
Toshiba	Satellite U300	41
Toshiba	Satellite U305	41
Toshiba	Satellite U400	41
Toshiba	Satellite U405	41
Toshiba	Satellite U405D	41
Toshiba	Satellite U505 series	41
Toshiba	Satellite U940 Series	41
Toshiba	Satellite U945 Series	41
Toshiba	Tecra M8	41
Toshiba	Tecra R700	41
Toshiba	Tecra R840	41
Toshiba	Tecra R850	41
Toshiba	Tecra R850	41
Toshiba	Tecra R940 Series	41
Toshiba	Tecra R950 Series	41

NOTE: Not all compatible models may be listed. Go to the *Tip Wizard* on www.rocketfishproducts.com to find additional model listings.
REMARQUE : Tous les modèles compatibles peuvent ne pas être listés. Aller sur le site www.rocketfishproducts.com et utiliser l'assistant d'identification des connecteurs (*Tip Wizard*) pour trouver la liste des modèles supplémentaires.
NOTA: se puede que ciertos modelos compatibles no sean listados. Visite el sitio www.rocketfishproducts.com y use el asistente de selección de puntas (*Tip Wizard*) para encontrar la lista de los modelos adicionales.

This page left blank intentionally.
Cette page est volontairement laissée vierge.
Esta página se dejo en blanco intencionalmente.



www.rocketfishproducts.com (800) 620-2790

ROCKETFISH is a registered trademark of BBY Solutions, Inc. Registered in some countries.
Distributed by Best Buy Purchasing, LLC, 7601 Penn Ave South, Richfield, MN 55423 U.S.A.
©2013 BBY Solutions, Inc. All Rights Reserved.

www.rocketfishproducts.com (800) 620-2790

ROCKETFISH est une marque déposée de BBY Solutions Inc. Déposée dans certains pays.
Distribué par Best Buy Purchasing, LLC, 7601 Penn Av. South, Richfield, MN 55423 É.-U.
© 2013 BBY Solutions, Inc. Tous droits réservés.

www.rocketfishproducts.com (800) 620-2790

ROCKETFISH es una marca comercial registrada de BBY Solutions, Inc. Registrada en ciertos países.
Distribuido por Best Buy Purchasing, LLC, 7601 Penn Av. South, Richfield, MN 55423 E.U.A.
© 2013 BBY Solutions, Inc. Todos los derechos reservados.

V10 13-0653