INSIGNIA™

Quick Setup Guide | NS-22D420NA18

22" 1080p 60Hz • LED TV

INCLUDED ACCESSORIES

Remote control and two AAA batteries

TV stands



ST4 screws (14 mm length) (4 pcs.)



Wall Mount screws:
M4 screws (10 mm length) (4 pcs.)



FIND YOUR *USER GUIDE* ONLINE!
On a computer, go to www.insigniaproducts.com, enter your model in the search box, then press **ENTER**.

Next to *Features*, click **Support & Downloads**, then next to *User Manual*, click the language you want.

STOP
Do not plug your power cord in until all other devices have been connected.

Before using your new product, please read these instructions to prevent any damage.

1 START HERE

How do I attach the stand to my TV? (not for wall mounting)

You'll need: Soft surface and Phillips screwdriver

A Place your TV face-down on a cushioned, clean surface.

B Align the screw holes on the TV stands with the holes on the bottom of your TV, then secure each stand to your TV with two of the provided screws.



ST4 screws (14 mm length) (4 pcs.)

WALL MOUNT

How do I prepare my TV for wall mounting? (not for use with a TV stand)

You'll need: Soft surface and Phillips screwdriver

A Carefully place your TV face-down on a cushioned, clean surface.

OR **B** See the instructions that came with your wall mount for more information about how to correctly mount your TV.



Your TV has four VESA mounting holes on the back. If you attach a wall-mount bracket to the back of your TV, **the bracket must be securely attached, using all four holes**. If you do not use all four mounting holes, your TV may fall and cause property damage or personal injury. See the documentation that came with your wall-mount for complete mounting instructions.

FEATURES



2 MAKING CONNECTIONS

How do I watch TV (cable, satellite, or antenna) or connect a device, such as a DVD or Blu-ray disc player, game console, or tablet?

WHICH CABLES DO YOU HAVE?

HDMI (BEST)
Best video quality



Multi-purpose jacks: You can plug any device that uses HDMI into either HDMI jack. However, certain devices must be connected to the **ARC** jack. See the instructions that came with your ARC device for more information.

AV (GOOD)



COAXIAL (GOOD)

3 CONNECTING AUDIO DEVICES

How do I connect my TV to external speakers?

USING DIGITAL AUDIO



On the *AUDIO* menu on your TV, select **Digital Audio Format/Audio Delay**, then set **Audio Format** to **PCM**.

OR

USING ANALOG AUDIO



Note: See the instructions that came with your speakers or soundbar for more information.

4 TURNING ON MY TV

When can I turn on my TV?

WHEN YOUR TV IS IN PLACE:

1 Plug the power cord into a power outlet.



2 Remove the remote control cover and install the batteries.



3 Press (power) on your remote control.

4 Follow the on-screen instructions.



USING YOUR REMOTE CONTROL



I already have a universal remote control. How do I make it control this TV?

If you already have a universal remote control that you would like to program to work with your TV and don't want to use the included Insignia remote control, see the table below for common codes.

UNIVERSAL REMOTE CONTROL CODES	
AT&T U-verse	1034, 1035, 1040, 1398, 1465, 1596, 1437, 1507, 12049, 11641, 11564, 11326,11423, 11892, 11517, 10171, 10463, 11385, 11660, 11963, 12184, 13227
Cablevision	068, 069, 078, 096, 100, 164, 168, 229, 026
Charter	2002, 1204, 1423, 1517, 0171, 1963, 0463, 1463, 0842, 1326, 167, 415, 424, 450, 456, 461, 507, 523, 567, 577, 586
Comcast	10463, 10171, 11204, 11326, 11463, 11517, 11641, 11780, 11785, 11892, 11963, 12002, 01877, 00276, 01982, 01376, 00810, 01187, 01106, 00877, 00476
Cox	1326, 1463
DirecTV	10463, 10171, 11204, 11326, 11517, 11564, 11641, 11963, 12002, 11463, 12049
Dish Network	834, 720, 222, 898, 365, 777, 754
RCA	135, 12049, 11423, 11564, 10171, 10463, 11810, 11892, 11963, 12184, 12417
Rogers	0463, 1326, 2049, 1785, 1780, 1423, 1963
Time Warner	400, 450, 461, 456, 10463, 1463, 0463
Verizon	0198, 0490

For an up-to-date list of codes for other cable providers and universal remote brands, visit www.insigniaproducts.com/remotecodes

INSIGNIA™

ONE-YEAR LIMITED WARRANTY
Visit www.insigniaproducts.com for details.

NEED ADDITIONAL HELP?
See your online *User Guide*!
This comprehensive guide includes everything from basic how-to steps to more advanced features. A copy of your *User Guide* is not provided in the box but is available online.

On a computer, go to www.insigniaproducts.com, enter your model in the search box, then press **ENTER**.

Next to *Features*, click **Support & Downloads**, then next to *User Manual*, click the language you want.

Check out our **Support Community** http://community.insigniaproducts.com/ for helpful information from other Insignia TV owners.

WE'RE HERE FOR YOU
www.insigniaproducts.com
For customer service, call:
877-467-4289 (U.S./Canada)

U.S. and Canada:
INSIGNIA is a trademark of Best Buy and its affiliated companies.
Registered in some countries.
Distributed by Best Buy Purchasing, LLC
7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2017 Best Buy. All rights reserved.
Made in China

V1 ENGLISH 17-0412