



More info at:
WWW.TRAKRACER.COM




or follow us at:



@TRAKRACER

TR1605 - MANUAL VERSION 1A



TR1605 SIMULATOR

Assembly Guide



IMPORTANT: Different regions may have different models. Please ensure the part numbers on the following pages match those on your product packaging.

SYMBOL LEGEND

01

SYMBOL LEGEND

01

02

PART LIST

02

03

ASSEMBLY NOTES

TR1605

04

04

ASSEMBLY INSTRUCTIONS

TR1605

07



IMPORTANT: Since there are different versions of each product based on your region, please make sure you are using the correct set of instructions. The part numbers on the following page should match the numbers on your product packaging.



IMPORTANT: Due to the nature of cut aluminum profiles, some metal shavings may remain despite our thorough QA cleaning process. We recommend opening boxes and packaging on a hard surface.



NOTE: Some screws and washers may be pre-installed. These are included in the parts list and will need to be loosened and reattached according to the instructions.



Recommended:
Two people for the task



Safety glasses required



Tighten the hardware



Attention/Priority needed



Keep the hardware loose
for adjustments



Reserve for the next step



Make the necessary adjustments




Mirrored components
(same on both sides)



Break the tab off the corner bracket

PART LIST


COMPONENTS




PART LIST



ACCESSORIES




INCLUDED TOOLS




NOTE: Extra hardware may be included as spare parts.

ASSEMBLY NOTES


TR1605



INSTALLATION ORDER FOR SCREWS WASHERS






HOW TO MEASURE SCREWS






ASSEMBLY NOTES

BC-40-BLK & CB-40




These brackets come with quide tabs on the rear. These tabs help align the brackets to the profile when fitted in the same orientation as the profile. When used in the alternate orientation, these tabs are designed to snap off for a flush mount against the profile.



ASSEMBLY NOTES


NS-M8 & NS-M6




ASSEMBLY INSTRUCTIONS

TR1605

01





02





ASSEMBLY INSTRUCTIONS

TR1605



ASSEMBLY INSTRUCTIONS

TR1605




ASSEMBLY INSTRUCTIONS


TR1605

SUPPLIED				
G X2	Q X6	AG X6	AC X6	AI X6
AP-40160-1400	FR-01	NS-M8	SH-M8-20	WF-M8-16

07



08




Please pay attention: the TRAK RACER plate side needs to face outward.

ASSEMBLY INSTRUCTIONS


TR1605

SUPPLIED				
J X2	AF X8			
CB-160	SF-M8-20			

09





10





ASSEMBLY INSTRUCTIONS

TR1605




ASSEMBLY INSTRUCTIONS

TR1605






ASSEMBLY INSTRUCTIONS

TR1605





NOTE:

Thread screws just enough to hold PM in place so screws do not protrude past PM plate.




NOTE:

Adjust position after wheelbase and seat installation.








ASSEMBLY INSTRUCTIONS

TR1605



NOTE:

Adjust position after wheelbase and seat installation.






ASSEMBLY INSTRUCTIONS

TR1605







There are four NS-M8 nuts reserved in Step 11.




ASSEMBLY INSTRUCTIONS

TR1605




ASSEMBLY INSTRUCTIONS

TR1605




ASSEMBLY INSTRUCTIONS

TR1605





ASSEMBLY INSTRUCTIONS

TR1605



Please measure the size with a tape measure,
then cut it out with scissors and insert it into the
corresponding position.



FINISHED PRODUCT