

Porsche (with M.O.S.T. 25 amplifier) **Data Interface 2004-2009**

INTERFACE FEATURES

- Provides accessory power
- Retains R.A.P. (retained accessory power)
- Designed for amplified models
- Provides NAV outputs (parking brake, reverse, speed sense)
- Retains balance
- Micro "B" USB updatable

INTERFACE COMPONENTS

- AX-PO904 interface
- AX-PO904 amplifier interface
- AX-PO904 harness

APPLICATIONS

PORSCHE

911 (997)

2004-2009

Boxster (987)

2004-2009

Cayman (987c)

2004-2009

TABLE OF CONTENTS

Connections to be made	2
Installing the interface	2

TOOLS REQUIRED

- Wire cutter • Crimp tool • Solder gun • Tape
- Connectors (example: butt-connectors, bell caps, etc.)

CAUTION! All accessories, switches, climate controls panels, and especially air bag indicator lights must be connected before cycling the ignition. Also, do not remove the factory radio with the key in the on position, or while the vehicle is running.

CONNECTIONS TO BE MADE

From the aftermarket radio to the AX-P0904 harness:

- Connect the **Black** wire to the ground wire.
- Connect the **Yellow** wire to the battery wire.
- Connect the **Red** wire to the accessory wire.
- If the aftermarket radio has an illumination wire, connect the **Orange** wire to it.
- Connect the **Blue/White** wire to the amp turn-on wire.

The following (3) wires are only for multimedia/navigation radios that require these wires.

- Connect the **Blue/Pink** wire to the VSS/speed sense wire.
- Connect the **Green/Purple** wire to the reverse wire.
- Connect the **Light Green** wire to the parking brake wire.
- Tape off and disregard the following (8) wires, they will not be used in this application:
Gray, Gray/Black, Green, Green/Black, Purple, Purple/Black, White, White/Black
- Connect the **Red** and **White** RCA jacks to the front amplifier output jacks of the aftermarket radio.

INSTALLING THE INTERFACE

With the key in the off position:

- Connect the AX-P0904 harness to the AX-P0904 interface.
- Connect the AX-P0904 harness to the AX-P0904 amplifier interface.
- Remove the dust cover from fiber optic port in the AX-P0904 amplifier interface.
- Connect the factory fiber optic cable into the AX-P0904 amplifier interface.
- Connect the AX-P0904 harness to the wiring harness in the vehicle.



AX-PO904

INSTALLATION INSTRUCTIONS



IMPORTANT

If you are having difficulties with the installation of this product, please call our Tech Support line at 1-800-253-TECH. Before doing so, look over the instructions a second time, and make sure the installation was performed exactly as the instructions are stated. Please have the vehicle apart and ready to perform troubleshooting steps before calling.



KNOWLEDGE IS POWER

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps toward a better tomorrow.



Metra recommends MECP
certified technicians