

QUICK SETUP GUIDE

# 11" Flex™ Tablet for Android™ with Detachable Keyboard

NS-P11A8100

**PACKAGE CONTENTS**


- 11" tablet with Android 7.0 (Nougat)
- Wall charger
- USB type-C cable
- Quick Setup Guide
- Important Information



**FIND YOUR USER GUIDE ONLINE!**


Go to [www.insigniaproducts.com](http://www.insigniaproducts.com), enter **NS-P11A8100** in the search box, then press **ENTER**. Next to *Features*, click **Support & Downloads**, then next to *User Guide*, select the language you want.

**FEATURES**




**SETTING UP YOUR TABLET**

**1** To charge your tablet, connect the USB type-C cable to your tablet and wall charger, then plug the wall charger into a power outlet.




**2** Press and hold the power button to turn on your tablet, then follow the on-screen instructions.



**Setup Tips**


*Connecting to Wi-Fi*

Tap a network to connect. You may have to enter your network password. To view your password, tap **Show password**. If you are taken back to the Wi-Fi list, make sure that you have entered the right password.



*Signing In*

If you have an existing Google account, use it to sign in. Otherwise, you'll need to create a new Google account.



**USING YOUR TABLET**

**Home screen**



**Notifications**

Swipe down from the top edge of the screen with one finger.



**Status items**


Swipe down from the top edge of the screen with two fingers.



## USING YOUR KEYBOARD

### Connecting your keyboard

Align the bottom of your tablet with the connection contacts on your keyboard. Your keyboard automatically connects to your tablet and the keyboard's power indicator lights up.



### Using the USB port

Connect a mouse, flash drive, or other peripheral device to your keyboard's USB port.

**Note:** You cannot charge your tablet through the keyboard's USB port or run high-power devices (such as a DVD drive).

### Turning the touchpad on or off

Press  to turn your touchpad on or off. The touchpad indicator lights up while the touchpad is turned off.

## CONNECTING TO WI-FI

If you skipped Wi-Fi during setup or need to connect to another network:

**1** Tap  Apps >  Settings >  Wi-Fi.




**2** Tap the  slider to turn Wi-Fi **On**, if needed. Your tablet automatically searches for available networks.



**3** Tap a Wi-Fi network.

- If the network is open, your tablet connects automatically.
- If the Wi-Fi icon has a lock (  ), the network is secured. Enter the password, then tap **CONNECT**.

“Connected” appears under the network name.



## NEED ADDITIONAL HELP?

- Troubleshoot common issues using the *Important Information* document in your box.
- Visit [www.support.google.com/android](http://www.support.google.com/android) for tips and tutorials on using Android.
- Check the online FAQs for answers to common questions. Go to [www.insigniaproducts.com](http://www.insigniaproducts.com), then search for your model number. Next to *Features*, select **Support & Downloads**, then select **FAQs**.
- Check out our online community forum for helpful information from other Insignia tablet owners. Go to [www.insigniaproducts.com](http://www.insigniaproducts.com), search for **NS-P11A8100**, then select **FAQs & community discussions** from the *Need help?* box.
- Find your *User Guide* online. Go to [www.insigniaproducts.com](http://www.insigniaproducts.com) and search for **NS-P11A8100** number. Next to *Features*, select **Support & Downloads**, then next to *User Guide*, select the language you want.

## SPECIFICATIONS

See the *Important Information* (in your box) for a complete specifications list.

## ONE-YEAR LIMITED WARRANTY

Visit [www.insigniaproducts.com](http://www.insigniaproducts.com) for details.

## WE'RE HERE FOR YOU

For customer service, call 877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)

[www.insigniaproducts.com](http://www.insigniaproducts.com)

Android, Google, Google Play, and other marks are trademarks of Google Inc.

INSIGNIA is a trademark of Best Buy and its affiliated companies.

Distributed by Best Buy Purchasing, LLC

7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2017 Best Buy. All rights reserved.

**Made in China**