

INSIGNIA™

fire tv

QUICK SETUP GUIDE

32" HD 60Hz LED TV


NS-32F201NA23

INCLUDED ACCESSORIES


Voice Remote with Alexa
and two AAA batteries



TV stands



Power cord




STOP
Before using your new TV, read these instructions to prevent any damage. Do not plug the power cord in until all other devices have been connected.

1 INSTALLING THE STANDS OR A WALL MOUNT

Place your TV face-down on a cushioned, clean surface.

STANDS

- Align the TV stand screw holes with the holes on your TV's bottom.
- Use a Phillips screwdriver and the four provided screws to secure the stands to your TV.



WALL MOUNT

Before you mount your TV, make sure that:

- You remove the stands.
- The wall-mount bracket supports the weight of your TV.


See the instructions that came with your wall mount for more information about how to correctly mount your TV.

WARNING: Your TV has four VESA mounting holes on the back.

You must secure a wall-mount bracket to all four holes.

If you do not use all four holes, your TV may fall and cause property damage or personal injury.


Note: Wall-mount screws are not included.



VESA Mounting Pattern


100 × 100 mm
Screws: type M4, 16 mm to 20 mm length depending on the wall mount

FEATURES



Power/Input button
Press to turn your TV on or off manually. When your TV is on, a short press changes power menu and a long press turns off your TV.


Power indicator
Remote control sensor



Note: Images do not necessarily represent the exact design of your television.

2 MAKING CONNECTIONS

HDMI (best video quality)




Note: You can use the **HDMI1 (ARC)** jack to connect a digital audio system.

AV (good video quality)



Coaxial (good video quality)




Connect an antenna to access live over-the-air TV.


AUDIO OUT




DIGITAL OPTICAL OUTPUT



HDMI OPTIONS



ANALOG




AUDIO IN



SOUNDBAR

DIGITAL



OPTICAL AUDIO IN



SOUNDBAR

AUDIO OPTIONS

You can use the **DIGITAL OPTICAL OUTPUT** jack or the **HDMI1 (ARC)** jack.

Note: If you need to change the digital audio format, go to the **Home** menu, select **Settings**, then select **Display & Sounds**. Select **Audio Output**, then select **Digital Audio Format** and change the setting to **PCM** or your preferred audio format.

ETHERNET (optional)




ETHERNET




Note: You can use a wired Ethernet connection to access the internet instead of a Wi-Fi connection. Plug an Ethernet cable into the **ETHERNET** jack on your TV and your Ethernet connection.

3 TURNING ON YOUR TV

1 Plug the power cord into the back of your TV and a power outlet.



2 Remove the remote control cover and install the batteries.



3 Press on your remote.

4 Follow the on-screen instructions.

4 COMPLETE THE ON-SCREEN SETUP

Your TV should automatically pair to your new Voice Remote with Alexa.


1 If your remote is not paired, press . If you continue to have issues, re-insert or replace the batteries and try again.

2 Select your Wi-Fi network from the displayed network list.
Note: If your Wi-Fi network is password protected, enter your network password using the on-screen keyboard. If your network is hidden, select the **Join Other Network** tile.

3 Select your experience: **Full** (recommended) or **Basic**.
 • Select **Full** to access live TV, over tens of thousands of streaming movies and TV episodes, thousands of apps, and Alexa skills. To get started, sign into or sign up for a free Amazon account.
 • Select **Basic** to access live TV and the six preset streaming apps. Alexa and the full Appstore are not included.

4 If you connected your TV to an antenna or cable wall jack:
A Go to **Settings > Live TV > Channel Scan**.
B Follow the on-screen instructions to scan for channels.
Note: To browse and watch live TV, use the **On Now** row or press on your remote.

USING YOUR VOICE REMOTE WITH ALEXA



FIND YOUR USER GUIDE ONLINE

- 1 Go to www.insigniaproducts.com.
- 2 Use the search bar to find **NS-32F201NA23**.
- 3 Select **Support & Downloads**.
- 4 Next to *User Guide*, select the language you want.

INSIGNIA™



A Smarter TV Is Here
 HD Picture Quality, Fire TV Experience Built-in,
 Voice Remote with Alexa

- Access Your Favorite Content – All Through One Home Screen**
 Fire TV Edition seamlessly integrates live over-the-air TV and streaming channels on a unified home screen
- Endless Entertainment – Netflix, Prime Video, YouTube, Hulu, HBO, and more**
 Watch over 500,000 streaming movies and TV episodes with access to tens of thousands of channels, apps, and Alexa skills
- Control It All With Your Voice – Voice Remote with Alexa**
 Use your voice to watch live TV, launch apps, search for titles, play music, switch inputs, control smart home devices, and more

Full Experience required to access all features described.

ONE-YEAR LIMITED WARRANTY
 Visit www.insigniaproducts.com for details.

NEED ADDITIONAL HELP?
 Check out our **Support Community** at <http://community.insigniaproducts.com/> for helpful information from other Insignia TV owners.

WE'RE HERE FOR YOU
www.insigniaproducts.com
 For customer service, call: **1-877-467-4289** (U.S./Canada)

CONTACT AMAZON FIRE TV CUSTOMER SERVICE
www.amazon.com/deviceservices/support

Press & ask



For DTS patents, see <http://patents.dts.com>.
 Manufactured under license from DTS, Inc.
 DTS, TruSurround and the DTS logo are registered trademarks or trademarks of DTS, Inc. in the United States and other countries.
 © 2020 DTS, Inc. ALL RIGHTS RESERVED.

AMAZON TERMS & POLICIES
 Before using Fire TV Edition, please read the terms located at www.amazon.com/deviceservices/support. Please also read all terms and policies for services related to Fire TV Edition, including but not limited to Amazon's Privacy Notice located at www.amazon.com/privacy, Amazon's Conditions of Use located at www.amazon.com/conditionsofuse, and any other terms or usage provisions available at www.amazon.com/deviceservices/support. All terms, rules, notices, policies, and provisions are, collectively, the "Agreements." By using Fire TV Edition, you agree to be bound by the terms of the Agreements.

Amazon, Fire, Alexa, Prime, and all related logos are trademarks of Amazon.com, Inc. or its affiliates.

Certain services are subject to change at any time, may not be available in all areas, and may require separate subscriptions.



Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 1992–2019 Dolby Laboratories. All rights reserved.

U.S. and Canada:
 INSIGNIA is a trademark of Best Buy and its affiliated companies. Registered in some countries.
 Distributed by Best Buy Purchasing, LLC
 7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2022 Best Buy. All rights reserved.

V1 ENGLISH 21-1031