

USB-C to Ethernet Adapter

Quick Setup Guide

BE-PA3C6E / BE-PA3C6E-C

BEST BUY
essentialsTM

Before using your new product, please read these instructions to prevent any damage.

Package contents

- USB Type-C to Gigabit Ethernet Adapter
- Quick Setup Guide


System requirements

- Windows® 10, macOS X 10.12 or later, Chrome OS 81 or later
- Device with a compatible USB Type-C port

Features


- Provides a fast and reliable gigabit internet connection to your USB Type-C computer
- Adds an Ethernet port to your computer
- Supports 10/100/1000 BASE-T network speeds, ideal for gaming, streaming music or movies, or web browsing
- Small and portable design
- Plug and play operation for easy access

Top view



Connecting the adapter

- 1 Connect an Ethernet cable (not included) to your router.
- 2 Connect the other end of the cable into the adapter.
- 3 Connect the adapter to a USB Type-C port on your computer.



Troubleshooting

My computer does not detect the adapter.

- Make sure that all of the cables are connected securely and correctly
- Make sure that the cables are not damaged
- Try connecting to another USB Type-C port

Legal notices

FCC Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

ICES-003

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

One-year limited warranty

Visit www.bestbuy.com/bestbuyessentials for details.

Contact Best Buy essentials

For customer service, call 866-597-8427 (U.S. and Canada)

www.bestbuy.com/bestbuyessentials

Best Buy essentials is a trademark of Best Buy and its affiliated companies.

Distributed by Best Buy Purchasing, LLC

7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2021 Best Buy. All rights reserved.