

PORTABLE ROOM AIR CONDITIONERS




GE APPLIANCES


How to Choose The Right Portable Air Conditioner For Your Room Size

1 MEASURE YOUR ROOM

Length x Width = Square Footage



2 VERIFY WINDOW



3 CHECK ELECTRICAL



115V

Oversizing or undersizing air conditioners is not recommended.

4 MATCH ROOM SIZE

Find the corresponding AC box that matches your desired cooling area.

	Cooling Area	Room Size	BTU
SMALL ROOM	150 SQ. FT.	10' X 15'	8,000
	UP TO 250 SQ. FT.	12' X 20'	9,000
MEDIUM ROOM	UP TO 350 SQ. FT.	15' X 20'	10,000
	UP TO 450 SQ. FT.	18' X 22'	11,000
	UP TO 550 SQ. FT.	22' X 25'	14,000