

User Manual	Operating Humidity	20% ~ 80%
Battery	Storage Temperature	\
Quick Start Guide	Storage Humidity	\
Battery		
Stand/Screw		