




Please give us a chance to make it right and do better !

Contact our friendly customer service department for help first.
Replacements for missing or damaged parts will be shipped ASAP !

US office: Fontana UK office: Ipswich AU office: Truganina



Contact Us !

Do NOT return this item.

Contact our friendly customer service department for help first.



US: cs.us@costway.com
UK: cs.uk@costway.com
AU: cs.au@costway.com

USER'S MANUAL



Patio Rattan Sectional Sofa Set HW67690-14-24-34-44

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.




Before You Start

- ⚠ Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.
- ⚠ Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
- ⚠ Work in a spacious area, preferably on a carpet close to where the unit will be used.
- ⚠ Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.




A




(1 pc)

B




(1 pc)

C




(1 pc)

D




(2 pcs)

E




(2 pcs)

F




(2 pcs)

G




(2 pcs)

H



(2 pcs)

M




(1 pc)

N




(7 pcs)

X



(2 pcs)

Y




(1 pc)

Z




(1 pc)

1 M6x35 mm




(18 pcs)

2 M6x40 mm




(22 pcs)

3 M6x55 mm



(12 pcs)

4 M6x70 mm




(2 pcs)

5 Ø6x14x1 mm




(46 pcs)

6




(12 pcs)

7




(2 pcs)

8 M6x 45mm




(4 pcs)

9 Allen key 4x98 mm



(3 pcs)



STEP 1




x2





STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7




STEP 8



STEP 9





STEP 10





STEP 11

Option 1





STEP 12

Option 1





STEP 13

Option 1





STEP 14

Option 2




STEP 15

Option 2




STEP 16

Option 2




STEP 17

Option 2




STEP 18

Option 2




STEP 19


Option 2




STEP 20



STEP 21



STEP 22

**FINISH**

Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting.

Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area.

Using solvents of any kind on your furniture may damage the finish.

Never use water to clean your furniture as it may cause damage to the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

Further advice about wood furniture care

Please protect your outdoor furniture with a cover when not in use since Long-term sunlight exposure will result in the damage on the surface.

In addition to sunlight damage, wood and metal frame suffers when exposed to extremes in temperature and humidity.

Proper care and cleaning at home will extend the life of your purchase.

Following these important and helpful tips will enhance your furniture as it ages.