Inspiron 3668 Setup and Specifications

Computer Model: Inspiron 3668 Regulatory Model: D19M Regulatory Type: D19M003



Notes, cautions, and warnings



NOTE: A NOTE indicates important information that helps you make better use of your product.



CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



WARNING: A WARNING indicates a potential for property damage, personal injury, or death.

Copyright © 2017 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

2016 - 12

Rev. A00

Contents

Set up your computer	4
Views	9
Front	
Back	11
Back panel	12
Specifications	14
Dimensions and weight	
System information	14
Memory	
Ports and connectors	
Media-card reader	
Communications	
Audio	16
Storage	16
Power ratings	
Video	17
Computer environment	
Getting help and contacting Dell	19
Self-help resources	19
Contacting Dell	

Set up your computer

1 Connect the keyboard and mouse.

See the documentation that shipped with the keyboard and mouse.



2 Connect the network cable — optional.



Connect the display.



Connect the power cable.

DEL



Press the power button.



6 Finish operating system setup.

For Windows:

a) Connect to a network.

Pick a network and go online t	o finish setting up this d	levice.	
Connections			
P Network Connected			
Wi-Fi			
Ma hashad			
(fr. 1999), 1999, 1999			
· Constraint			
(ii. ***			
Skip this step			
(t+			

b) Sign-in to your Microsoft account or create a new account.

Make it yours	
Your Microsoft account opens a world of benefits. Learn more	e
(4 6 6 6 b) 1	
Email or phone	
Password	
Forgot my password	
No account? Create one!	
Microsoft privacy statement	
	Sign in

For Ubuntu:

Follow the instructions on the screen to finish setup.

7 Locate Dell apps in Windows.

Table 1. Locate Dell apps



Register your computer

Dell Help & Support # total help & support







SupportAssist—Check and update your computer

D¢I

Views

Front



1 Optical drive (optional)

Reads from and writes to CDs and DVDs.

2 Optical-drive eject button

Press to open or close the optical drive tray.

3 Power button

Press to turn on the computer if it is turned off, in sleep state, or in hibernate state.

Press to put the computer in sleep state if it is turned on.



Press and hold for 4 seconds to force shut-down the computer.

NOTE: You can customize the power-button behavior in Power Options. For more information, see *Me and My Dell* at <u>www.dell.com/</u> <u>support/manuals</u>.

4 Hard-drive activity light

Turns on when the computer reads from or writes to the hard drive.

5 Media-card reader

Reads from and writes to media cards.

6 Headset port

Connect a headphone or a headset (headphone and microphone combo).

7 USB 3.0 ports (2)

Connect peripherals such as storage devices and printers. Provides data transfer speeds up to 5 Gbps.

Back



1 Back panel

Connect USB, audio, video, and other devices.

2 Expansion-card slots

Provide access to ports on any installed PCI Express cards.

3 Power port

Connect a power cable to provide power to your computer.

4 Power-supply diagnostic light

Indicates the power-supply state.

5 Padlock rings

Attach a standard padlock to prevent unauthorized access to the interior of your computer.



6 Security-cable slot

Connect a security cable to prevent unauthorized movement of your computer.

7 Service Tag label

The Service Tag is a unique alphanumeric identifier that enables Dell service technicians to identify the hardware components in your computer and access warranty information.

Back panel



1 Line-in port

Connect recording or playback devices such as a microphone or CD player.

2 Line-out port

Connect speakers.

3 Microphone port

Connect an external microphone to provide sound input.

4 VGA port

Connect an external display or a projector.

5 HDMI port

Connect a TV or another HDMI-in enabled device. Provides video and audio output.

6 USB 2.0 ports (4)

Connectperipherals such as storage devices and printers. Provides data transferspeeds up to 480 Mbps.

7 Network port (with lights)

Connect an Ethernet (RJ45) cable from a router or a broadband modem for network or internet access.

The two lights next to the connector indicate the connectivity status and network activity.

Specifications

Dimensions and weight

Table 2. Dimensions and weight

Height

Width

Depth

Weight (approximate)

352.90 mm (13.90 in)

154 mm (6.06 in)

303 mm (11.93 in)

5.90 kg (13.01 lb)



NOTE: The weight of your computer varies depending on the configuration ordered and the manufacturing variability.

System information

Table 3. System information

Computer model

Processor

Inspiron 3668

- Intel Core i3/i5/i7
- Intel Celeron
- Intel Pentium

Intel H110

Chipset

Memory

Table 4. Memory specifications

Slots	Two U-DIMM slots
Туре	DDR4
Speed	• 2133 MHz (Intel Celeron)

 2400 MHz (Intel Pentium and Intel Core i3/i5/i7)

Configurations supported

 $2~\mbox{GB},~4~\mbox{GB},~6\mbox{GB},~8~\mbox{GB},~10~\mbox{GB},~12~\mbox{GB},$ and 16 \mbox{GB}

Ports and connectors

Table 5. Ports and connectors	
External:	
Network USB	One RJ45 port
	 Four USB 2.0 ports Two USB 3.0 ports
Audio/Video	 One headset port One microphone port One line-out port One line-in port One VGA port One HDMI port
Internal:	
M.2 card	One M.2 card slot for Wi-Fi and Bluetooth combo card
PCIe slots	Two PCIe x1 card slotsOne PCIe x16 card slot

Media-card reader

Table 6. Media-card reader specifications

Туре	One 5-in-1 slot
Cards supported	• SD card



- · SD High Capacity (SDHC) card
- SD Extended Capacity (SDXC) card
- MultiMediaCard (MMC)
- MultiMediaCard Plus (MMC Plus)

Communications

Table 7. Supported Communications

Ethernet

Wireless

10/100/1000 Mbps Ethernet controller integrated on system board

- Up to Wi-Fi 802.11ac/n
- · Bluetooth 4.0

Audio

Table 8. Audio specifications

Controller

Туре

Realtek ALC3820

Integrated 5.1 channel Intel High Definition Audio

Storage

Table 9. Storage specifications

Interface

Hard drive

SATA 1.5 Gbps for optical drive

- SATA 6 Gbps for hard drive
- One 2.5-inch hard drive
- One 3.5-inch hard drive

One 2.5-inch solid-state drive

One 9.5-mm DVD+/-RW drive

Solid-state drive Optical drive

Power ratings

Table 10. Power ratings

Input voltage	100 VAC to 240 VAC
Input frequency	50 Hz to 60 Hz
Input current (maximum)	4.0 A

Video

	Integrated	Discrete
Controller	Intel HD Graphics	 NVIDIA GeForce GT710FH
		 NVIDIA GeForce GT730
		 NVIDIA GeForce GTX750Ti
		AMD Radeon R9 360
Memory	Shared system memory	2 GB DDR32 GB GDDR5

Table 11. Video specifications

Computer environment

Airborne contaminant level: G2 or lower as defined by ISA-S71.04-1985

Relative humidity (maximum): 20% to 80% (non-condensing)

Table 12. Computer environment

	Operating	Storage
Temperature range	10°C to 35°C	–40°C to 65°C
	(50°F to 95°F)	(-40°F to 149°F)
Vibration (maximum)*	0.25 GRMS	2.20 GRMS



	Operating	Storage
Shock (maximum)	40 G for 2 ms with a change in velocity of 20 in/s (51 cm/s)†	50 G for 26 ms with a change in velocity of 320 in/s (813 cm/s)‡
Altitude (maximum)	–15.24 m to 3048 m (–50 ft to 10,000 ft)	–15.24 m to 10,668 m (–50 ft to 35,000 ft)

 \ast Measured using a random vibration spectrum that simulates user environment.

† Measured using a 2 ms half-sine pulse when the hard drive is in use.

 \ddagger Measured using a 2 ms half-sine pulse when the hard-drive head is in parked position.

Getting help and contacting Dell

Self-help resources

You can get information and help on Dell products and services using these self-help resources:

www.dell.com

Table 13. Self-help resources

Information about Dell products and services

Dell Help & Support app

Get started app

Accessing help

Online help for operating system

Troubleshooting information, user manuals, setup instructions, product specifications, technical help blogs, drivers, software updates, and so on.

Learn about your operating system, See *Me and My D* setting up and using your computer, data <u>support/manuals</u>. backup, diagnostics, and so on.

In Windows search, type Help and Support, and press Enter.

www.dell.com/support/windows www.dell.com/support/linux

www.dell.com/support

See *Me and My Dell* at <u>www.dell.com/</u> <u>support/manuals</u>.

Contacting Dell

To contact Dell for sales, technical support, or customer service issues, see www.dell.com/contactdell.





NOTE: Availability varies by country and product, and some services may not be available in your country.



NOTE: If you do not have an active internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.