

## QUICK SETUP GUIDE

# 800 Lumen Rechargeable Flashlight

NS-CFL300A


## PACKAGE CONTENTS

- 800 Lumen Rechargeable Flashlight
- USB charging cable
- Carrying case
- Carrying strap
- Quick Setup Guide

Before using your new product, please read these instructions to prevent any damage.

## FEATURES

- 800 lumen output with a maximum beam distance of 623 ft. (190 m) makes your flashlight ideal for general indoor and outdoor use.
- Ultra-high capacity, internal, rechargeable battery is small and light and provides a long runtime.
- Battery indicator lets you know when the battery is low, charging, or fully charged.
- Integrated Micro USB port lets you recharge from any powered device with a standard USB port.
- IPX4 rating provides protection in dusty and damp environments (not waterproof).
- Four brightness levels plus a strobe (flashing) mode provide a wide range of lighting options.
- Carrying case and strap makes it easy to carry and keep track of your flashlight




Battery indicator:

- **RED LED** - Battery low or charging
- **GREEN LED** - Battery fully charged

## CHARGING THE BATTERY

## Notes:


- Your flashlight contains a non-replaceable lithium battery that is sealed inside your flashlight. Trying to replace the battery will damage your flashlight.
  - When the flashlight is charging, the ⏻ (power) button LED lights red. When it is fully charged, the ⏻ (power) button LED lights green.
  - When the battery level is below 3.2V, the ✨ (mode) button LED lights red and you need to charge the battery.
- 1 Plug the small plug on the USB cable into the USB port on your flashlight.
  - 2 Plug the large plug into a powered USB port on a device with a standard USB port.



- 3 When the battery charge indicator turns green, unplug the USB cable.


## USING YOUR FLASHLIGHT

- 1 Press and hold the ⏻ (power) button for 1.5 seconds to turn on.




- 2 Quickly press and release the ✨ (mode) button one or more times to select a brightness level (Eco, high, medium, or low), or press and hold the button for 1.5 seconds to select strobe mode.

**Note:** To exit strobe mode, press and hold the ✨ (mode) button again. Your flashlight returns to the last brightness level you selected.



- 3 To turn off your flashlight, press and hold the ⏻ (power) button.



## TROUBLESHOOTING

### The LED does not light or I cannot select a brightness level.

- Make sure that your flashlight is turned on.
- Make sure that the battery is charged.

### The flashlight body is overheating.

- Make sure that your flashlight is turned off during charging.
- If you set the brightness level to high, the LED generates a moderate amount of heat. This is normal. If your flashlight is too hot to hold, turn it off and wait 10 minutes for it to cool.

### The light level dims on its own.

- The LED and battery are thermally-controlled for protection and long life. If the LED or battery gets too warm, the light level will automatically dim. This is normal operation.

## SPECIFICATIONS

**Dimensions (H x W):** 5.9 x 1.27 in.  
(15 x 3.2 cm)

**Weight:** 5.0 oz.

**Battery:** 2600mAh lithium battery (sealed inside, non-replaceable)

**Battery indicator:** LED located behind the power and mode selection buttons.

**Maximum output:** 800 LM

**Maximum beam distance:** 623 ft. (190 m)

**Maximum run time:** 4 hrs. on high beam selection mode

**Charging time:** 5 hrs.

**USB Cable specification:** 5V 1A, .98ft. (30 cm)

**IP rating:** IPX4 (rain and splash resistant)

**Impact resistance:** 3 ft. (1 m)

Beam selection modes	Output	Max. beam distance	Runtime
Eco	35LM	131 ft. (40 m)	36 hrs.
Low	120LM	262 ft. (80 m)	8 hrs.
Medium	370LM	439 ft. (134 m)	5 hrs.
High	800LM	623 ft. (190 m)	4 hrs.

## SAFETY INFORMATION

### Charging cautions:

- Do not use your flashlight while the battery is charging because it shortens the life of the battery due to excess heat.
- Promptly remove the USB cable when charging is complete.

### Flashlight cautions:

- Do not shine the flashlight into a person's eyes. This might damage the person's eyesight.
- When your flashlight is on, do not touch the flashlight head. The head may be hot enough to burn your skin.
- Keep your flashlight away from children under 18 years of age.

## ONE-YEAR LIMITED WARRANTY

Visit [www.insigniaproducts.com](http://www.insigniaproducts.com) for details.

### CONTACT INSIGNIA:

For customer service, call 1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)

[www.insigniaproducts.com](http://www.insigniaproducts.com)

INSIGNIA is a trademark of Best Buy and its affiliated companies  
Distributed by Best Buy Purchasing, LLC  
7601 Penn Ave South, Richfield, MN 55423 U.S.A.  
©2017 Best Buy. All rights reserved.  
**Made in China**