

Congratulations on your purchase of a high-quality Insignia product. Your NS-NBBAR represents state of the art in sound bar design and works with most laptops and netbooks. It is designed for reliable and trouble-free performance.

Safety

- Avoid high temperatures, fire, moisture, water, and dust.
- Do not expose your sound bar to dripping or splashing.
- Do not place any sources of danger, such as liquid-filled objects or lighted candles, near your sound bar.
- Do not use organic solvents on surface.


Specifications

Maximum output power	0.9 W + 0.9 W
SNR	≥100dB
THD+N	≤1.5%
Crosstalk	≥60dB
Frequency response	100 ~ 20,000Hz
Power supply	DC 5V through USB port
Operating temperature	14° ~ 113°F (-10° ~ 45°C)
Supported operating systems	Windows® ME Windows® 2000 Windows® XP Windows Vista® Mac OS X or higher


Using your sound bar

To use your sound bar:


- 1 Use the clip on the back of the sound bar to hold the sound bar in place, then secure the sound bar to the top of the computer screen as shown below.



- 2 Insert the USB cable from the sound bar into an available USB port on the computer. The computer automatically recognizes your sound bar. When installation is complete, your sound bar is ready to use.



- 3 For best results, make sure that the computer screen is tilted slightly backward (not straight up).



- 4 Adjust the volume of your sound bar just as you would for your built-in speakers: through pre-installed computer software, designated buttons on your keyboard, or through the volume settings of the application you are running for sound.

Troubleshooting

To use your sound bar:

Problem:	Solution:
No power	<ul style="list-style-type: none"> • Make sure that the sound bar is plugged into an active USB port on the computer. • Make sure that the computer is turned on. • Press a keyboard key to make sure that the computer is not in sleep mode.
No sound	<ul style="list-style-type: none"> • Make sure that the computer is playing sound. • Make sure that the volume on the computer is not set too low. • Make sure that the sound on the computer is not muted. • Make sure that the sound bar is connected before opening the program or playing back the audio.

Legal notices

FCC Part 15

This device complies with Part 15 of the FCC Rules. Operation of this product is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canada ICES-003 statement

This Class B digital apparatus complies with Canadian ICES-003.

One-year limited warranty

Visit www.insigniaproducts.com for details.

Contact Insignia:

For customer service please call 1-877-467-4289

www.insigniaproducts.com

Distributed by Best Buy Purchasing, LLC

7601 Penn Avenue South, Richfield, Minnesota, U.S.A. 55423-3645