

INSIGNIA™

QUICK SETUP GUIDE

9" Glass Lid for Pressure Cookers

NS-MCGL6CL9



PACKAGE CONTENTS

- 9" Glass Lid for Pressure Cookers
- *Quick Setup Guide*

FEATURES

- Shatterproof glass lets you see food while it's cooking in non-pressurized cooking modes
- Vented lid allows steam to escape and creates better visibility
- Dishwasher-safe design makes cleanup easy
- Works with Insignia and select other pressure cooker brands

Before using your new product, please read these instructions to prevent any damage.


CLEANING YOUR LID

Wash the lid with hot water and dish soap, or rinse and place in your dishwasher. Dry before storing.



Dishwasher safe

or



Hand washable

SPECIFICATIONS

Dimensions (H × W × D): 3.2×9.1×9.1 in.
(8.0×23.2×23.2 cm)

Weight: 1.1lbs. (0.5 kg)

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

For customer service, call 1-877-467-4289 (U.S. and Canada) or
01-800-926-3000 (Mexico)

www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies

Distributed by Best Buy Purchasing, LLC

7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2018 Best Buy. All rights reserved

Made in China