

Please make sure to read the enclosed Ninja® Owner's Guide prior to using your unit.

Please make sure to read the enclosed Ninja® Owner's Guide prior to using your unit.

CLEANING

Dishwasher: The containers, lids, and blade assembly are all dishwasher safe. The lids and blade assembly are top-rack dishwasher safe. Ensure the blade assembly is removed from the cup before placing in the dishwasher.

Hand-washing: Wash containers, lids, and blade assembly in warm, soapy water. When washing the blade assembly, use a dishwashing utensil with a handle to avoid direct hand contact with blades. Handle blade assembly with care to avoid contact with sharp edges. Rinse and air-dry thoroughly.

**NUTRI
NINJA**
WITH
FRESHVAC™ TECHNOLOGY

**QUICK
START
GUIDE**

⚠ WARNING: Always unplug the base before cleaning.

⚠ WARNING: Handle the blade assembly with care when washing, as the blades are sharp. Contact with the blades' edges can result in laceration.

QUESTIONS? We're here to help. Call **1-877-646-5288** or visit ninjakitchen.com

SINGLE-SERVE FRESHVAC™ CUP


PARTS




INSTALLING THE BATTERIES IN THE FRESHVAC PUMP

- 1 Unscrew the FreshVac Pump's power button cap and remove the spring-loaded battery cover.
- 2 Install 6 AA alkaline batteries (included), ensuring the +/- symbols on the batteries match the markings on the battery cover and battery housing.
- 3 Replace the battery cover, making sure it is fully seated and clicked in place.
- 4 Screw on the pump's power button cap.

ASSEMBLY





BLEND & ENJOY




⚠ WARNING: Handle the Pro Extractor Blades Assembly with care, as the blades are sharp.

QUESTIONS? We're here to help. Call 1-877-646-5288 or visit ninjakitchen.com

VACUUM BLENDING WITH THE SINGLE-SERVE FRESHVAC™ CUP



- 4 Press the power button on top of the pump to begin vacuum sealing. The pump will shut off automatically once vacuum sealing is complete.
- 5 To release the pump from the cup, press the pump release button on the bottom front of the pump and lift. Click the Flip & Seal Lid closed.



⚠ WARNING: Handle the blade assembly with care when washing, as the blades are sharp. Contact with the blades' edges can result in laceration.

QUESTIONS? We're here to help. Call 1-877-646-5288 or visit ninjakitchen.com