

Quick Start Guide

TC HELICON HARMONY SINGER 2

Harmony - Selects the harmonies that will be blended with your voice.

Ground lift - If you experience buzz or hum, try pressing the ground lift button in or out.

Guitar thru

Level - Adjusts the volume of the harmonies.



Reverb - Selects the type and amount of reverb effect.

Guitar input

Tone - Engages 'Adaptive Tone' for EQ, compression, de-essing and gating.

USB - Accepts micro-USB cables for firmware updates.

On/Off



Out - Connect to a mixer or powered speaker.

Mic - Connect your microphone.

Power - Connect a 9V / >300 mA power supply, such as the PowerPlug 9 (not included). The pedal also accepts 4 x AA batteries.

Visit tc-helicon.com to download the full manual

TC HELICON