




AC60L L-DESK



Assembly Instructions - Important:

Carefully unpack and identify each component before attempting to assemble. Refer to parts list. Please take care when assembling the unit and always set the parts on a clean, soft surface. If you require any assistance with assembly, parts or information on other products, please visit our website: www.officestar.net or call or write us.




1. Do not use this product unless all screws and bolts are securely tightened.
2. Check that all screws and bolts are tight every three months or as needed.
3. Dispose of packing material properly. Do not use plastic cover as head covering. It may cause suffocation.
4. Do not use this product as a stepladder.
5. Use this product for its intended purpose only.
6. **FOR INDOOR RESIDENTIAL USE ONLY.**


LIMITED WARRANTY

OSP Home Furnishings® warrants to the original purchaser that this product will be free from defects in material and workmanship as described below. Home Furnishings® will repair or replace, at its option, without charge to the original purchaser only, defective products or parts for one (1) year from the date of purchase. Replacement parts can only be supplied if parts are available. Items out of production may be unavailable. This warranty shall be effective for the applicable time period beginning from the date of purchase as shown on your original sales receipt. This warranty is your sole remedy for product defects and excludes defects due to or arising in connection with product abuse or misuse, use modification of, or attachments to the product, and products or parts not used, maintained, or installed in accordance with the company's installation, maintenance and/or applicable guidelines. There are no other warranties, express or implied, other than those specifically described, including without limitation any implied warranty of merchantability or of fitness for a particular purpose. OSP Home Furnishings® will not be responsible for incidental or consequential damages. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which may vary from state to state. Our quality standards are among the highest in the industry. Sometimes, no matter how hard we try, there are times when parts are damaged or missing. Our Parts Department will do everything possible to promptly remedy the problem. Contact us via e-mail parts.department@officestar.net by Fax 1-909-930-5629, or toll free parts number 1-800-950-7262, Monday through Friday 8:00 a.m. - 3:30 p.m. Pacific Time. To make a warranty claim, contact Parts Department. Provide model number, proof of purchase, description of the problem and obtain return authorization. At its option OSP Home Furnishings® will: (a) Supply compatible components of current manufacture. (b) Repair the customer's component. The customer must prepay freight on any components returned to the factory. Return freight on components still in warranty will be paid by OSP Home Furnishings®.


CAM LOCK INSTALLATION



Screw in Cam Bolt and fully tighten.




Align hole in panel with Cam Bolt and attach.




Screw Cam Lock in. Turn clockwise until you feel Cam Lock securely fasten to Cam Bolt. Fully tighten Cam Lock.


PARTS




(A) Main Desk Add-On Shelf (1 Pc)




(B) Main Desk Top Panel (1 Pc)




(C) Return Desk Top Panel (1 Pc)




(D) Return Desk Bottom Panel (1 Pc)




(E) Back Panel (1 Pc)




(F) Return Desk Side Panel (1 Pc)




(G) Return Desk Middle Panel (1 Pc)



(H) Door (1 Pc)




(I) Left Shelf (1 Pc)




(J) Right Shelf (1 Pc)


PARTS




(K) Front Support (1 Pc)




(L) Back Support (1 Pc)




(M) Main Desk Side Frame (1 Pc)




(N) Main Desk Support Tube (3 Pcs)




(O) Return Desk Support Tube (2 Pcs)




(P) Main Desk Upper Crossbar (2 Pcs)




(Q) Main Desk Lower Crossbar (1 Pc)




(R) Return Desk Side Frame (1 Pc)



(S) Power Outlet (1 Pc)



(T) Plastic Cup Holder (1 Pc)



















(U) Plastic Tray (1 Pc)




(V) Accessory Hook (1 Pc)

HARDWARE


NO	DRAWING	DESCRIPTION	SIZE	QUANTITY
1		Glue	N/A	1 Pc
2		Wood Dowel	8 x 30mm	13 Pcs +1 extra
3		Cam Lock	15 x 11mm	18 Pcs +2 extra
4		Cam Bolt	M6	4 Pcs
5		Cam Bolt	N/A	14 Pcs +1 extra
6		Handle	N/A	1 Pc
7		Phillips Bolt	5/32" x 15 x 8mm	4 Pcs
8		Phillips Screw	4 x 15 x 8mm	22 Pcs +2 extra
9		Allen Bolt	1/4" x 15mm	18 Pcs +1 extra
10		Allen Bolt	1/4" x 32mm	19 Pcs +1 extra
11		Allen Bolt	1/4" x 65mm	1 Pc
12		Allen Key	4mm	1 Pc
13		Sticker	20mm	2 Pcs
14		Phillips Screw	3.5 x 15 x 7mm	2 Pcs
15		Shelf Support	6mm	4 Pcs
16		Adhesive Pad	N/A	4 Pcs

Phillips screwdriver also needed for assembly (not provided)

STEP 1






STEP 2






FULLY TIGHTEN BOLTS (7)


STEP 3

3		x1
4		x4



STEP 4


3		x3
9		x4
12		x1



FULLY TIGHTEN ALL BOLTS


STEP 5

3		x2
---	---	----




STEP 6

3		x8
---	---	----




STEP 7




FULLY TIGHTEN ALL BOLTS

STEP 8




STEP 9




FULLY TIGHTEN ALL BOLTS

STEP 10




1. Check to make sure that the latch slider switch on pre-assembled Latches (ZB) are located in the **DOWN** and **UNLOCKED** position.
2. Place the pre-assembled Rollers (ZA), which are attached to the **BOTTOM** of Door (H) assembly, down in the groove on Bottom Panel (D).
3. Align the Latches (ZB), which are attached to the **TOP** of Door (H) assembly, and then push the latch slider switch up until it reaches the upmost **LOCKED** position.
4. Check the travel of Door (H) assembly, making sure it slides freely.
5. If the Door (H) assembly doesn't slide smoothly, please adjust the height of the Rollers (ZA) by loosening the screw in the center of Rollers (ZA) and turn Rollers (ZA) clockwise slightly and tighten screws again.

STEP 11




FULLY TIGHTEN ALL BOLTS

STEP 12




FULLY TIGHTEN ALL BOLTS

STEP 13




FULLY TIGHTEN ALL BOLTS


STEP 14



FULLY TIGHTEN ALL SCREWS

STEP 15

7		x2
---	---	----



FULLY TIGHTEN ALL BOLTS

FCC INSTRUCTIONS

NOTE: This equipment has been tested and found to comply with the limits for the Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interferences in a residential installation. This equipment generates, uses and can radiate frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- Instructions shall caution users that modifications not approved by part responsible for compliance could void user's authority to operate the equipment.



Office Star Products
Model number: BY213-N011