

**** IMPORTANT ****

**Retain this card, a copy of your receipt
and your 24 digit serial number
for your records**



NEED HELP?


Please visit our “support and contact”
section on www.hover-1.com

**Do not return to store.
We're here to help!**




BEFORE FIRST USE, PLEASE FULLY CHARGE YOUR HOVER-1 BLAST.

- The Blast is fully charged when the light on the charger itself, turns from red to green as shown below.



LOCATING YOUR HOVER-1 BLAST SERIAL NUMBER

- There are two (2) stickers with a corresponding serial number for your Blast affixed on the bottom of the unit as shown below. Carefully remove one (1) serial number sticker and affix it onto the designated place on page 21 in the manual of your Blast.




BOTTOM OF BLAST

CALIBRATING YOUR HOVER-1 BLAST

If your Blast is vibrating, spinning, uneven, leaning or unbalanced, a quick calibration is necessary.

- First, place the Blast on a flat, horizontal surface, such as the floor or a table, making sure it is powered off and not plugged into the charger.



- Press and hold the power button for 5-10 seconds as shown to the right.

- When your Blast starts beeping, you may release the power button.

- To complete calibration, power off your Blast and then back on. The beeping will stop and the board is now calibrated. It's a good idea to recalibrate your Blast after every few rides, to keep it running smoothly.