

Quick Start Guide

TC HELICON VOICETONE H1

Voice Above/Below Selector – Select whether harmonized voices appear above or below the original voice input.

Key Selector – Choose a diatonic key to create harmonies or use a guitar signal to control and generate harmonies.

Mic Input Level Control

Ground Lift – Press the button inward if you experience buzz and hum.

Instrument Thru – Send a copy of the instrument input signal to an amp or PA.

Effect On/Off Footswitch – Turns the effect on and off.

USB – Accepts the included mini-USB cable for firmware update.

Power – Connect the included 12 V / \geq 400 mA power supply.




Input Level LED – Green = signal, red = clip.

Mic Control – Use the optional MP-75 mic (button in = on).

Guitar Input – Use a guitar signal to control and generate voice harmonies.

Dry/Wet Mix Control – Control the amount of effected "wet" signal mixed with the original "dry" signal.

Effect Active LED – Also displays delay time in Tap Tempo mode.



Out – Connect to a mixer or powered speaker.

Mic – Connect your microphone.

Visit tc-helicon.com to download the full manual

TC HELICON