

# Chair Assembly Instructions


Your chair comes packaged in one box.

**DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.**

Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching the finish.

Estimated Assembly Time in Minutes

★ ☆ ☆  
 <15 <45 60+



## Parts List

**A** 1 x Chair Base



\* **C** 2 x Back Legs



\* **B** 2 x Front Legs




\* **D** 4 x Washers




\* Replaceable Parts

## Assembly


Step 1




**A**



Step 2



OPTIONAL



**B** or **C**

Adjust each leg by inserting a washer (D) to make it even and level with the floor.

Your style may differ from images. Care for your furniture by periodically tightening all legs.

**CAUTION:** Tighten all components securely before use. Failure to do so may result in personal injury.

About your furniture piece:

- Softening of foam is natural and will happen over time with use.
- Fabric will fade or discolor in direct sunlight. Minimize exposure to direct sunlight to extend the life of your furniture.
- Wood grain, knots, streaks, and color variation occur naturally in wood and are not considered defects.

Customer Support: 866-238-0531  
 Mon-Fri 8:00am - 4:30pm CST  
[customerservice@furniturequestions.com](mailto:customerservice@furniturequestions.com)