

Curl Secret™

IMPORTANT SAFEGUARD

**PLEASE READ THIS CARD
AND INSTRUCTION BOOKLET
BEFORE USE**

IMPORTANT: To prevent tangling of hair, ensure the opening of the Curl Secret™ curl chamber is always facing toward your head as indicated and pictured below. Failing to use the styler in the correct position greatly increases the risk of tangling.



✓ **Correct curl chamber position**



✗ **Incorrect curl chamber position**

ANTI-TANGLE FEATURE:

Curl Secret is safe and easy to use when used properly. However, should improper use occur, the anti-tangle feature has been designed to immediately stop drawing the hair in and reverse to a neutral position. Simply open the handles and ease hair out of the curl chamber.

MOST IMPORTANT: For more serious tangles, unplug the unit and gently work the hair out of the unit.

GETTING STARTED:

1. Comb through clean, dry hair so it is smooth and free of tangles.
2. Work with 1/2 in.–1 in. sections (longer hair requires smaller sections).
3. Wait for red blinking light to remain solid before starting.
4. **ENSURE THE OPENING OF THE CURL CHAMBER IS ALWAYS FACING TOWARD YOUR HEAD.**

infinitiPRO by CONAIR®


PRODUCTION INKS



Cyan



Magenta



Yellow



Black

All prints CMYK

Other Instructions:

White k/o

Hi res in place

Bleed edges

Document is created to trim size: 4" W x 7.25" H