

INSIGNIA™

QUICK SETUP GUIDE

V31 SERIES Wall Charger

30W

- NS-MW3130C1W24
- NS-MW3130C1W24B
- NS-MW3130C1W24B-C

45W


- NS-MW3145C1B24B
- NS-MW3145C1B24B-C

65W

- NS-MW3165C2A1B24
- NS-MW3165C2A1B24-C


FEATURES

Single USB-C wall charger




Multiple-port USB/USB-C wall charger

Using one port




OR

Using multiple ports



Using multiple ports



Note: The USB-C1 port works best for a laptop when multiple ports are charging simultaneously.

SPECIFICATIONS

MODEL#	NS-MW3130C1W24		NS-MW3130C1W24B / NS-MW3130C1W24B-C		NS-MW3145C1B24B / NS-MW3145C1B24B-C		NS-MW3165C2A1B24 / NS-MW3165C2A1B24-C	
POWER	30W		30W (with USB-C cable)		45W (with USB-C cable)		65W (Multiple ports)	
WORKS BEST WITH	iPhone 15 Pro Max iPhone 15 Pro iPhone 15 Plus iPhone 15 iPhone 14 Series iPhone 13 Series iPhone 12 Series iPhone SE Series Apple Watch	AirPods Pro AirPods iPad Pro iPad Air iPad iPad mini MacBook Air	iPhone 15 Pro Max iPhone 15 Pro iPhone 15 Plus iPhone 15 iPad Pro 12.9-inch (6th generation) iPad Pro 11-inch (4th generation) iPad (10th generation) iPad mini (6th generation)	iPad Air (5th generation) AirPods Pro (2nd generation, USB-C) MacBook Air	Galaxy S24 Ultra Galaxy S24+ Galaxy S23 Ultra Galaxy S23+ Galaxy S22 Ultra Galaxy S22+ Galaxy S20 Ultra Galaxy Note10+ Galaxy Tab S9 Ultra Galaxy Tab S9+	Galaxy Tab S9 Galaxy Tab S8 Ultra Galaxy Tab S8+ Galaxy Tab S8 iPhone 15 Series iPad Series	FOR TWO / THREE DEVICES SIMULTANEOUSLY: iPhone Series iPad Series Galaxy S Series Galaxy Z Fold / Flip Series Galaxy Note Series Galaxy Tab S Series Apple Watch AirPods Pro / AirPods Samsung Galaxy Watch Samsung Galaxy Buds	FOR ONE DEVICE: MacBook Pro MacBook Air Surface Laptop Surface Pro / Go HP Spectre / EliteBook Dell XPS / Inspiron / Latitude Lenovo ThinkPad / YOGA / IdeaPad Chromebook / Pixelbook
COMPATIBILITY DEVICES								
PACKAGE CONTENTS	• Wall Charger • Quick Setup Guide		• Wall Charger • 6 ft. 60W certified USB-C to USB-C cable • Quick Setup Guide		• Wall Charger • 6 ft. 240W certified USB-C to USB-C cable • Quick Setup Guide		• Wall Charger • Quick Setup Guide	

Before using your new product, please read these instructions to prevent any damage.

MODEL#	NS-MW3130C1W24	NS-MW3130C1W24B / NS-MW3130C1W24B-C	NS-MW3145C1B24B / NS-MW3145C1B24B-C	NS-MW3165C2A1B24 / NS-MW3165C2A1B24-C
INPUT	100-240V~ 50/60Hz	100-240V~ 50/60Hz	100-240V~ 50/60Hz	100-240V~ 50/60Hz
OUTPUT	5V===3A, 9V===3A,15V===2A, 20V===1.5A (PPS) 3.3-11V/3A, 3.3-16V/2A, 30W Max	5V===3A, 9V===3A,15V===2A, 20V===1.5A (PPS) 3.3-11V/3A, 3.3-16V/2A, 30W Max	5V===3A, 9V===3A,15V===3A, 20V===2.25A (PPS) 5-11V/5A, 5-16V/3A, 5-21V/2.25A, 45W Max	Use One Port: USB-C1/ C2: 65W 5V===3A, 9V===3A,15V===3A, 20V===3.25A (PPS) 5-11V/5A, 5-16V/4.3A, 5-21V/3.25V, 65W Max USB-A: 5V===2.4A Use Multiple Ports: USB-C1 + USB-C2: 45W + 20W USB-C1 + USB-A: 45W + 5V===2.4A USB-C2 + USB-A: 5V===3A USB-C1 + USB-C2 + USB-A: 45W + (5V===3A) PD 45W: 5V===3A, 9V===3A, 15V===3A, 20V===2.25A (PPS) 5-11V/5A, 5-16V/3A, 5-21V/2.25A, 45W Max PD 20W: 5V===3A, 9V===2.22A (PPS) 5-11V/2.2A, 20W Max
DIMENSION (H × W × D)	1.3 × 1.2 × 1.2 in. (34.5 × 32.5 × 32.5 mm)	1.3 × 1.2 × 1.2 in. (34.5 × 32.5 × 32.5 mm)	1.4 × 1.3 × 1.3 in. (38 × 34.5 × 34.5 mm)	2 × 1.6 × 1.5 in. (52 × 40 × 38.5 mm)
WEIGHT (CHARGER ONLY, Approx.)	1.8 oz. (51 g)	1.8 oz. (51 g)	2 oz. (57 g)	4.6 oz. (130 g)

TROUBLESHOOTING

My device isn’t charging.

- Make sure that the charging cable is connected securely to the wall charger.
- Make sure that your device is securely connected to the charging cable.

My device is charging slowly.

- Make sure that the power requirements of your device match the power delivery of the charger.
- Stop using your device while it is charging.
- Close apps that run in the background on your device.

- Devices may start charging slower as they get older. This is normal.
- Charging will be slower if the user is charging multiple devices at the same time.

SAFETY INFORMATION/CAUTION

READ ALL INSTRUCTIONS BEFORE USING.

- THIS PRODUCT IS NOT A VOLTAGE CONVERTER. Use this adapter only if the power outlet voltage is within the range of your device’s voltage. Using this adapter with an incompatible device and power outlet may result in a risk of fire, electric shock, injury to persons, or damage to the device.
- Always disconnect the adapter and the device from the power outlet when not in use.

- Do not expose the adapter to high temperatures or humid environments.
- Do not place the product into a fire or submerge it in liquid.
- Do not disassemble the product.
- Avoid external shocks.
- The product will heat slightly when charging and discharging. This is normal.
- Do not operate the adapter with wet hands.
- Keep out of reach of children.
- Indoor use only.
- Protection class II appliance.

LEGAL NOTICES

1.FCC Caution:
Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.
FCC Statement: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
2. CAN ICES-003 B/NMB-003 B

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

For customer service, call
1-877-467-4289 (U.S. and Canada)
www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies
Distributed by Best Buy Purchasing, LLC
7601 Penn Ave South, Richfield, MN 55423 U.S.A.
©2024 Best Buy. All rights reserved.