


*Thank you for your purchase!*

## 3-Seat Outdoor Steel Converting Patio Swing



## ASSEMBLY INSTRUCTIONS

### **Before You Begin:**

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

### **Caution:**

Tighten all components securely before use. Failure to do so may result in personal injury.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

### **Warning:**

CHOKING HAZARD - Small Parts. Adult Assembly Required.

Injury may result from tipping furniture. You must install the Tipping Restraint Hardware with the unit to prevent the unit from tipping and causing any accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.




































This tipping restraint is not an earthquake restraint. If you wish to add the extra security of earthquake restraints, they must be purchased and installed separately.

Serious or fatal crushing injuries can occur from furniture tipping over. To prevent furniture from tipping over it must be permanently fixed to the wall. Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home.

Failure to detach this restraint before moving furniture may result in injury or damage.


DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE

# PARTS


 1PC	 1PC	 2PCS	 2PCS	 2PCS	 1PC	 1PC
 1PC	 1PC	 4PCS	 2PCS	 1PC	 1PC	 1PC
 2PCS	 3PCS	 2PCS				
 2PCS	 M8 × 105MM 8PCS	 M6 × 35MM 2PCS	 M6 × 75MM 2PCS	 M6 × 75MM 2PCS	 M6 × 55MM 9PCS	 M6 × 45MM 2PCS
 M6 × 40MM 4PCS	 M6 × 30MM 3PCS	 M6 × 25MM 1PCS	 M6 2PCS	 2PCS	 2PCS	 Ø7X15 2PCS
 Ø48 2PCS	 Ø48 4PCS	 Ø16 8PCS	 1PCS			

# STEP 1


①




②




③




④



⑤




⑥




# STEP 2


7




8




9




10



11



12



13

