


IMPORTANT NOTE:

Some Samsung MHL-enabled devices require the included adapter to be connected to the USB/MHL connector on the Samsung device. The micro USB connector on the MHL cable then connects to the adapter. Devices that require the adapter include the Galaxy S® III, 4, and 5, and Galaxy Note® II, 3, 4, and Edge, and other Samsung products.

Before using your new product, please read these instructions to prevent any damage.



AVIS IMPORTANT :

Certains périphériques compatibles MHL de Samsung requièrent que l'adaptateur inclus soit connecté au port USB/MHL du périphérique Samsung. Le connecteur micro USB du câble MHL doit ensuite être connecté à l'adaptateur. Les périphériques qui requièrent l'adaptateur incluent les Galaxy S^{MD} III, 4, et 5, et Galaxy Note^{MD} II, 3, 4 et Edge, ainsi que d'autres produits Samsung.

Avant l'utilisation de ce produit neuf, lire ces instructions afin d'éviter tout dommage.

