



HGN781

HAGNEY LANE L-DESK WITH POWER AND STORAGE



Assembly Instructions - Important:

Carefully unpack and identify each component before attempting to assemble. Refer to parts list. Please take care when assembling the unit and always set the parts on a clean, soft surface. If you require any assistance with assembly, parts or information on other products, please visit our website: www.officestar.net or call or write us.




1. Do not use this product unless all screws and bolts are securely tightened.
2. Check that all screws and bolts are tight every three months or as needed.
3. Dispose of packing material properly. Do not use plastic cover as head covering. It may cause suffocation.
4. Do not use this product as a stepladder.
5. Use this product for its intended purpose only.
6. **FOR INDOOR RESIDENTIAL USE ONLY.**


LIMITED WARRANTY

OSP Home Furnishings™ warrants to the original purchaser that this product will be free from defects in material and workmanship as described below. OSP Home Furnishings™ will repair or replace, at its option, without charge to the original purchaser only, defective products or parts for one (1) year from the date of purchase. Replacement parts can only be supplied if parts are available. Items out of production may be unavailable. This warranty shall be effective for the applicable time period beginning from the date of purchase as shown on your original sales receipt. This warranty is your sole remedy for product defects and excludes defects due to or arising in connection with product abuse or misuse, use modification of, or attachments to the product, and products or parts not used, maintained, or installed in accordance with the company's installation, maintenance and/or applicable guidelines. There are no other warranties, express or implied, other than those specifically described, including without limitation any implied warranty of merchantability or of fitness for a particular purpose. OSP Home Furnishings™ will not be responsible for incidental or consequential damages. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which may vary from state to state. Our quality standards are among the highest in the industry. Sometimes, no matter how hard we try, there are times when parts are damaged or missing. Our Parts Department will do everything possible to promptly remedy the problem. Contact us via e-mail parts@officestar.net, by Fax 1-909-930-5629, or toll free parts number 1-800-950-7262, Monday through Friday 8:00 a.m. - 5:00 p.m. Pacific Time. To make a warranty claim, contact Parts Department. Provide model number, proof of purchase, description of the problem and obtain return authorization. At its option OSP Home Furnishings™ will: (a) Supply compatible components of current manufacture. (b) Repair the customer's component. The customer must prepay freight on any components returned to the factory. Return freight on components still in warranty will be paid by OSP Home Furnishings™.


PARTS




(A) Left Top Panel (1PC)




(B) Right Top Panel (1PC)




(C) Left Front Frame (1PC)




(D) Left Rear Frame (1PC)




(E) Right Side Panel (1PC)




(F) Right Side Panel (1PC)




(G) Shelf (1PC)




(H) Bottom Panel (1PC)




(I) Cross Rail (1PC)




(J) Left Rear Panel (1PC)




(K) Right Rear panel (1PC)



(L) Right Rear panel (1PC)




(M) Support (1PC)




(N) Support (1PC)


PARTS




(O) Support (1PC)




(P) Support (1PC)




(Q) Right Frame (1 PC)




(R) Right Frame (1 PC)




(S) Drawer Front Panel (1 PC)




(T) Drawer Left Side Panel (1 PC)




(U) Drawer Right Side Panel (1 PC)




(V) Drawer rear panel (1 PC)




(W) Drawer Front Panel (1 PC)




(X) Drawer Left Side Panel (1 PC)



(Y) Drawer Right Side Panel (1 PC)





















(Z) Drawer Rear Panel (1 PC)






(A1) Drawer Bottom Panel (2 PCS)

HARDWARE LIST


NO	DRAWING	DESCRIPTION	SIZE	QUANTITY
1		Bolt	1/4" x 1/2"	21PCS+2EXTRA
2		Bolt	1/4"x1-1/4"	13PCS+1EXTRA
3		Screw	Ø3.5x1/2"	26PCS+2EXTRA
4		Screw	Ø3.5x1-1/4"	12PCS+1EXTRA
5		Nail Screw	N/A	20PCS+2EXTRA
6		Wooden Dowel	Ø8x30mm	20PCS+2EXTRA
7		Wooden Dowel	Ø6x30mm	8PCS+1EXTRA
8		Bolt	M4x22mm	4PCS
9		Cam Screw	M8x20mm	25PCS+2EXTRA
10		Cam Screw	M6x20mm	6PCS+1EXTRA
11		Cam Nut	Ø15x9mm	31PCS+2EXTRA
12		Left Drawer Rail	N/A	1PC
13		Right Drawer Rail	N/A	1PC
14		Left Drawer Slide	N/A	1PC
15		Right Drawer Slide	N/A	1PC
16		Drawer Rail	N/A	2PCS
17		Sticker	N/A	4PCS
18		USB charge station	N/A	1PC

HARDWARE LIST


NO	DRAWING	DESCRIPTION	SIZE	QUANTITY
19		Handle	N/A	2PCS
20		Bar iron	N/A	2PCS
21		Hex key	N/A	1PC

Phillips Screwdriver and hammer also needed for assembly (not provided).


CAM LOCK INSTALLATION



Screw in Cam Screw. Fully Tighten.



Align hole in panel with Cam Screw. Attach.





**Screw Cam Nut in. Turn clock-wise until you feel
Cam Nut securely fasten to Cam Screw.
Fully tighten Cam Nut.**

DRAWER INSTALLATION

If you need to remove the drawer with ball bearing slides from the unit, follow the steps below to prevent any damage to the slides or the drawer.


1. If you need to remove the drawer, please pull the drawer all the way out, then push the plastic release lever of the ball bearing slide up on one side and down on the other side, and then pull the drawer completely out. See detail #A.



Detail #A


2. To place the drawer back, simply push the ball bearing cart all the way to the end of the slide (in both sides), and align the slide runners on the drawer with the slide tracks on the unit and push it carefully inside until it stops. See detail #B.

Note: If they do not align properly, remove and repeat step 2




Detail #B

STEP 1




FULLY TIGHTEN CAM SCREWS (9).

STEP 2




FULLY TIGHTEN CAM SCREWS (10).

STEP 3




FULLY TIGHTEN CAM SCREWS (10).

STEP 4




FULLY TIGHTEN CAM NUTS (11) AND BOLTS (1).

STEP 5




FULLY TIGHTEN CAM NUTS (11) AND BOLTS (2).

STEP 6




FULLY TIGHTEN CAM SCREWS (9).

STEP 7




FULLY TIGHTEN CAM SCREWS (9) AND SCREWS (3).

STEP 8




FULLY TIGHTEN CAM SCREWS (9) AND SCREWS (3).

STEP 9




STEP 10




FULLY TIGHTEN SCREWS (1).

STEP 11




FULLY TIGHTEN CAM NUTS (11).

STEP 12




FULLY TIGHTEN SCREWS (4).

STEP 13




FULLY TIGHTEN SCREWS (1).

STEP 14




FULLY TIGHTEN CAM NUTS (11) AND SCREWS (2).

STEP 15




FULLY TIGHTEN SCREWS (5).

STEP 16




FULLY TIGHTEN SCREWS (1 & 11).

STEP 17




FULLY TIGHTEN SCREWS (2).

STEP 18




FULLY TIGHTEN CAM SCREWS (9).

STEP 19




FULLY TIGHTEN CAM NUTS (11).

STEP 20




STEP 21




FULLY TIGHTEN BOLTS (8).

STEP 22




FULLY TIGHTEN SCREWS (3).

STEP 23




FULLY TIGHTEN CAM SCREWS (9).

STEP 24




FULLY TIGHTEN CAM NUTS (11).

STEP 25




STEP 26




FULLY TIGHTEN BOLTS (8).

STEP 27




FULLY TIGHTEN SCREWS (3).


STEP 28



STEP 29



STEP 30



FCC INSTRUCTIONS

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Instructions shall caution users that modifications not approved by the party responsible for compliance could void user's authority to operate the equipment.



Office Star Products
Model Number: BY213-Q021