

INSIGNIA™

DEVICE CODES CÓDIGOS DE LOS DISPOSITIVOS

Five-device/Eight-device
Universal Remote
Control remoto universal
para cinco/ocho dispositivos

NS-RMT5D21/NS-RMT8D21



Device codes/Códigos de los dispositivos

TV and AUX Device Codes/Códigos de dispositivos de televisión y AUX

Affinity	3717, 3870, 3577, 3716
Aiwa	3332, 1362
Akai	1675, 3332
AOC	3720, 2691, 1365, 2014, 2087
Apex Digital	2397, 4347, 4350
Ario	2397
Asus	3340
Atak	2397
Atvio	3638, 4398, 3636, 3879
Atyme	2746
Audiovox	1564, 1276, 1769, 2121
Auria	4748, 2087, 2014, 2277, 2855
Avera	2397, 2049
Avol	2735, 4367, 3382, 3118, 1709
Axess	3593
Blu:sens	2735
Bolva	2397
Broksonic	1892, 3118
Calypso	4748
Champion	1362
Changhong	4629
Citizen	1892
Coby	3627
Contex	4053, 4280
Craig	3423, 1687
Crosley	3115
Curtis	2855, 3577, 2466, 3895, 2352, 2397, 3939, 4035, 3636, 3382, 3717, 4139
Curtis Mathes	1661
Daewoo	1661, 3115, 3879
Dell	1749
Digitrex	4207
Disney	1892
Durabrand	1595, 3879
Dynex	2049, 1463, 1780, 2184
Electrograph	1755
Electrohome	1670

Electron	2466, 2855
Element	3559, 1687, 4398, 2183, 2964, 5173, 4635, 4910, 1886, 4217, 4740
Element-Roku	4398, 4740
Elite	1457
Emerson	1864, 1963, 1394, 1886, 1595, 3623, 1661, 2183, 3559
Envision	1365, 2087, 2014
EQD Auria	2014, 2087, 2277
ESA	1963, 1595
eTec	2397
Exorvision	3953
Favi	3382
Fisher	1362
Fluid	2964, 3559
Furrion	3332, 4093, 5410
Gateway	1755
GE	1447
GFM	1864, 1886, 1963
GHIA	5144, 5196
GPX	3980, 3977
Haier	2309, 1749, 1748, 3382, 1753, 3429, 2293, 4398, 2214
Haier-Roku	4398
Hannspree	1348, 2786
Harper	3332
Hewlett Packard	1860
Hisense	3519, 4740, 4618, 2183, 5185, 1660, 3382
Hisense-Roku	4740
Hitachi	1643, 4398, 5102, 4455, 2214, 3382, 3332, 0679, 5446
Hitachi-Roku	4398
Hiteker	3118
HKPro	3879, 2434, 5228
HP	1860
iLo	1463, 1394
InFocus-Roku	4398
Insignia	2049, 1780, 4487, 3227, 5213, 1564, 1641, 2184, 1892, 1423, 1660, 1963
Insignia-Roku	4487
iSymphony	3382, 3429, 3118, 3094
JVC	1774, 1601, 3393, 2321, 2271, 4107, 4398, 5182, 4105, 4053, 1670, 4367, 1892, 3879, 4280, 5228
JVC-Roku	4398
KC	4182
KDS	1687

Kenmore	3953
LeEco	4007
Legend	2397, 2352, 1749, 2309
Lexus	3638
LG	1840, 1860, 2731, 1423, 4397, 2358, 1749, 4398, 1753
MAG	1687
Magnavox	3623, 1866, 2372, 1963, 1454, 1365, 1755, 4398, 1867, 4740, 1394
Magnavox-Roku	4398, 4740
Marantz	1454
Maxent	1755
Memorex	4686, 1892, 1670, 1687, 2049
Mitsubishi	1250, 1797
Mitsui	1123, 3638, 3673
Naxa	4093, 2104, 2735, 3382, 3423
NEC	3257, 1797, 3000, 2293
NetTV	1755
Nexus	1564, 3519, 2183
Norcent	1365, 2087
NuVision	1657, 4347
oCOSMO	3899, 4139
Olevia	1610
Onn	4398, 5348, 1709, 3024, 3078, 5118
Onn-Roku	4398
Optimus	0679
Orion	1463, 1670, 3540, 1892
Panasonic	1480, 1291
Philco	1963, 1394, 5377
Philips	2800, 1867, 2372, 3069, 1454, 3623, 3396, 1866, 1744, 4398, 1963, 1755, 1365, 1394
Philips Magnavox	3396, 1866, 3623
Philips-Roku	4398
Pioneer	0679, 1260, 1457, 2434
Planar	0679
Polaroid	1523, 4035, 1769, 1276, 1687, 1767, 3942, 2121, 3382, 2434, 3118
Portland	1661
Prima	1753, 2049, 1749
Proscan	1447, 3577, 3382, 2183, 3717, 3332, 4494, 3636, 3895, 3953, 4495, 4035, 4053, 4491, 3939, 4483, 4375, 4500, 2746, 3429, 3559, 4093
Proview	1687
Pyle	2196

QFX	3593
QuantumFX	3593
Quasar	1291, 4207, 3899, 4367, 3382, 5221
RCA	2746, 2434, 2247, 4214, 3577, 1781, 4398, 3382, 4740, 3332, 3717, 2932, 3895, 2187, 4629, 4488, 4494, 3953, 2183, 4623, 3636, 3939, 2855, 4053, 3519, 4491, 4495, 4627, 0679, 4035, 4483, 4625, 5223, 1661, 5377, 3938, 4093, 1670, 5173, 1447
RCA-Roku	4398, 4740
Roku	4398, 4740
Sampo	1755
Samsung	2051, 1632, 5386, 5371
Sansui	1892, 3540, 1670, 1463, 4053, 3564, 4280, 3559
Sanyo	1142, 1362, 4168, 4740, 2049, 4667, 3488, 1480, 1564
Sanyo-Roku	4740
Sceptre	3899, 4139, 2528, 5393
Seiki	3953, 4635, 2964, 3560, 3559, 4217, 3382, 4794
Seura	4751
Sharp	2360, 1659, 3519, 3394, 4740, 4618, 3720, 4507, 2214, 4398
Sharp-Roku	4740, 4398
Sigmac	3477, 3423
Silo Digital	3899, 4494, 3477, 4182
SkyVue	4135, 2360
Skyworth	5340, 4542
Sony	0810, 4448, 4189
Spectroniq	1687
Speler	4105, 4041, 2434
SunBriteTV	2528, 4139, 1610
Superscan	1963
Supersonic	3593, 2104, 1753
SVA	1963
Sylvania	1963, 1864, 1886, 1394, 1595, 3332, 3577, 4053
Symphonic	1963, 1595, 1394
TCL	4398, 2434, 3183, 5446, 3879
TCL-Roku	4398
Technicolor	3577
Toshiba	2724, 3945, 5213, 4885, 5394
Upstar	4182, 4405, 3899
V7 Videoseven	2087
Vidao	2397
Videoseven	2087
Viewsonic	2014, 2277, 2087, 3706, 1755, 2049, 1860, 1564, 1365
Viore	3382, 2352, 3118, 2104, 3429, 3094

VisionQuest	1687
VIZIO	1758, 3758, 4905, 5454, 4723, 2707, 2757, 3415, 2512
W Box Technologies	4686
Westinghouse	1712, 4797, 3559, 3382, 4398, 5173, 4910, 2293, 3094, 4139, 3560, 4635, 2397, 3908
Westinghouse-Roku	4398
White Westinghouse	1661
Wyse	1365
Xococo	1753, 2049, 1749
Zenith	1423, 2731, 1661, 1365, 2358, 1463

STB Device Codes/Códigos de dispositivos STB

Access Communications	1376, 2187, 4537
ADB	2586, 1481, 1998, 2254, 3028
Altice USA	3885, 1376, 6351, 1877, 3560, 1982
Amino	1615, 1481, 1898, 3605, 2482, 4437, 1998, 3028, 3426
Armstrong	1376, 3560
Arris	1376, 2378, 1982, 1998, 2187, 0869, 5912, 1877, 5889, 5097, 6400, 0858, 5537, 5942
AT&T	1377, 6268, 0858
AT&T U-verse	0858
Atlantic Broadband	1376, 1877, 1982, 3560, 4079
Axtel	4458
Bell	0775, 1998, 5537, 1877, 5097
Bell Aliant	1998
Bell Fibe TV	1998, 5097, 5537
Bell MTS	1998, 5097, 5537
Bell Satellite TV	0775
Blue Ridge Communications	1877, 3560
Buckeye Broadband	1376, 1877, 2187, 4079
Cable Axion	1376
Cable One	1376, 3560, 1877
Cablecom Mexico	1376
Cablemás	1376, 1877
Cablevisión Mexico	1376, 4375, 4537
CenturyLink	1998, 0858

Channel Master	3118
Cincinnati Bell	1877, 1376
Cisco	1877, 1982, 2947, 0858, 3028, 2345, 2378, 5912, 1998, 4315, 3294, 4374, 5484, 2826, 4450, 4514, 5942
Cogeco	1376, 1982, 3560, 4537
Comcast	1982, 1376, 1877, 3560, 2187, 4079, 4443, 4537
Cox Communications	1877, 1376, 1982, 4315, 3774, 3560, 6400
DIRECTV	1377, 6268, 3724
DISH	0775
Dish Mexico	0775, 6068
DISH Network	0775
EastLink	1376, 2187
Echostar	0775
Entone	3426, 1615, 1898, 4437
Evolution Digital	2479, 4079, 2746, 4315, 3560
Frontier Communications	2378, 1998, 3560, 0775
Google Fiber	3666
Ignite TV	1982
Izzi Telecom	1376, 6195, 4375, 4537
Kaon Media	4458, 2746
Liberty Cablevision	1376
Maxcom	1998
Mediacom	1376, 3560, 1982, 1877
Megacable	1376, 6286, 4374, 4450, 4514, 4375, 4537, 4883
Midco	1376, 1982, 3560, 2826, 4079
Motorola	1376, 0869, 2378, 1998, 0858, 1982, 4375, 5097, 3469
Moxi	2187
Optimum	3885, 1376, 6351
Pace	1982, 1376, 1377, 1877, 3469, 3560, 1998, 0858, 6195, 4537, 5370
Philips	1377, 2378, 3560, 2619, 3469
Pioneer	1877
RCN	1376, 3560, 1877
Rogers	1877, 1376, 5484, 1982, 2826, 3294, 4537
Sagemcom	3885, 5842
Samsung	1377, 1877, 1982, 2947, 3928, 6268
SaskTel	1998
Scientific Atlanta	1877, 0858, 1982, 2345, 3028, 2378, 2826
Service Electric	1376, 1982, 1877, 2187
Shaw	1376, 1877, 1982, 2187, 4537

Shaw Direct	0869, 0775
Sky Mexico	3469, 2619, 1377
Sparklight	1376, 3560, 1877
Spectrum	1877, 1376, 2187, 3560, 3294, 4537
Suddenlink	1877, 1376, 3560, 6351, 3885, 1982
Tbaytel	1998
TDS Telecom	0775, 1376, 3028, 1877, 1982
Technicolor	1377, 1877, 1982, 5484, 5912, 2947, 6286, 6068, 6195, 3469
TeleCable	1376
TELUS	5912, 3028, 0775, 5942
Time Warner Cable	1877, 1376, 3294, 2187, 3560, 4537
TiVo	3560, 3724, 1377
Totalplay	4589
TVision Home	5370, 1998
U-verse	0858
Verizon	2378, 5889, 6326
Vidéotron	1877, 2947, 1376, 1982
Vmedia	4596
Wave Broadband	1376, 1877, 4079, 2479, 3560, 2187
WOW!	1877, 1376, 2187, 2479, 3560, 2826, 3294
Xfinity	1982, 1376, 1877, 3560, 2187, 4079, 4443, 4537
Xtream	1376, 3560, 1982, 1877
ZTE	6286

Streaming Device Codes/Códigos de dispositivos de streaming

AirTV	5295
Amlogic	4899
Apple	2615
Armada	4899
Beelink	5123
Boxee	3693
Ceton	1272
Cloud Media	2260
Delta Electronics	4339
DishTV	5295
D-Link	3671, 3693
Dynalink	6413
Echostar	5295

Funai	3339
G-Box Midnight	4440
Geniatech	4339
Iomega	2558
Kollins	4339
LG	3373
Linksys	1272
Logitech	3272
Magnavox	3339
Matricom	4440, 4899
Media Center PC	1272
Mi	3982
Micca	3850
Microsoft	4000, 1272, 2049
Millet	3982
Mind	1272
Minix	4413, 3884
MyGica	4339
Netgear	3324, 2036, 4401, 3292
NVIDIA	4918
Onn	6490
Ortek	3122
Panasonic	3760
PDP	5724
Pivos	4339
Popcorn Hour	2260
Qumi	4339
RCA	3335
Roku	3061
Seagate	2698
Sling Media	5295, 3778
Sony	2713, 5724, 1272
Technicolor	5295
Tibo	4339
Vensmile	4899
Vivitek	4339
VIZIO	3670
Western Digital	2558
Xbox	4000, 2049
Xiaomi	3982

BLURAY and DVD Device Codes/Códigos de dispositivos BLU-RAY y DVD

Accurian	0675
Bel Canto Design	1571
Blackweb	4372
California Audio Labs	0490
Citizen	2213
Coby	2494
Curtis	3052
Curtis Mathes	2331
Denon	2258, 1634, 0490, 2748, 3851
Digix	3850
Disney	0675
Durabrand	0675, 3464
Dynex	2596
Emerson	0675, 2213
Funai	0675
GE	0522
GFM	0675
Go Video	1075, 0741
Harman/Kardon	3228, 2927
Hitachi	0573, 0675
Insignia	2095, 2596, 2428, 0675, 0741
Integra	2147, 0627, 1769, 1634, 3787
JVC	1602, 2365, 2855
Kenwood	0534, 0490
LG	0741, 1602, 4091
Magnavox	0675, 3488, 0503, 0539
Marantz	2481, 0539, 2414, 3444
Memorex	2213, 3031, 2331
Microsoft	0522
NAD	0741
New Acoustic Dimension	0741
Olevia	2331
Onkyo	0627, 2147, 0503, 1769, 2562, 3787
Onn	4371, 4016, 4372, 4377
Oppo	2545
Panasonic	0490, 3641, 1641, 1579, 0503
Philco	0675

Philips	2056, 2789, 2434, 0675, 0539, 3488, 0503, 3274, 2084
Philips Magnavox	0503, 0675
Pioneer	1571, 2854, 2442, 0142, 2847
Polk Audio	0539
Presidian	0675
Proscan	0522
Pye	0675
RCA	0522, 2213, 2532, 3464, 1769
Samsung	0199, 0573, 2069, 1075, 1573, 2113, 2843, 2269, 2329, 4108, 2556, 0490
Sanyo	0675
Seiki	2912
Sharp	2250, 0675, 2652
Sherwood	3052, 3837
Sony	1633, 1516, 1033, 0864, 1070, 4009, 0675
SV2000	0675
Sylvania	0675, 4016
Symphonic	0675
Technics	0490
Toshiba	0503, 2277, 3957, 2006, 3857, 1769, 3157
TruTech	0675
VIZIO	2563
Yamaha	0539, 3320, 2298, 0490, 3995, 3837
Zenith	0741, 0503

AUDIO Device Codes/Códigos de dispositivos de AUDIO

Acoustic Audio	4683
Aiwa	0158, 1243
Altec Lansing	4609
AMC	1077
Anker	5578
Apex Digital	4334
Arcam	2241
Arvani	4293
AudioSource	3721
Aura	4293
Axess	4095
Axiim	4951
Bestisan	5271
BOHM	4280

Bose	1933, 1629, 3959, 4307, 3708, 4024, 3706, 3832, 5163
Boston Acoustics	3698
BYL	5271
Canston	5138
Coby	3654
Craig	4466
Current Audio	5190, 5191
Curtis	3942
Definitive Technology	4415, 4984, 3645
Denon	3347, 2857, 2516, 3380, 4025, 2502
Dynavox	3231
Dynex	2971, 3951
Emotiva	3763
Enclave Audio	4800
Energy	4941
Episode	5107
Epworth	0158, 1243
GE	3297
GPX	5103
Haier	3516
Harman/ Kardon	2241, 0110, 2443, 1304, 3320, 4186, 3418, 3756, 3391, 3517
iLive	3175
Inkel	3770, 4090, 3793
Insignia	3951, 2169, 2472, 2966, 3770, 4424, 1077
Integra	1805, 3860, 2730, 4023, 4014, 2503, 3992
Jamo	4941
JBL	3756, 2241, 3391, 3535, 5132, 0110
JVC	1676, 2040, 3049, 2331
Kenwood	1570, 1293
Klipsch	4941, 4198, 4200, 5152
LG	3217, 2676, 3509, 2197, 4043, 3996, 1293
Magnavox	1831, 1269, 3282
Majority	5506
Marantz	1289, 2114, 3772, 1269, 3347
McIntosh	1289
Megacra	5271
Monoprice	4505
Monster Cable	4987
Onkyo	1805, 2730, 3860, 4023, 2503, 4041, 4014, 3992, 3984, 5094
Onn	5041, 5412, 5042, 5414, 5415, 5043

Optimus	1023
Panasonic	3323, 2967, 3309, 3055, 2452, 3767, 1676
Paradigm	4536, 4846
Peerless-AV	5153
Philco	1831
Philips	1831, 1269, 4105, 2459, 3776, 3379, 3282, 3801, 2311, 3652, 2675, 4012
Pinnacle Speakers	3774, 3728
Pioneer	1935, 3057, 2432, 1023, 3956
Polk Audio	4431, 1289
Proficient	3661
Pyle	4333
RCA	2041, 2611, 3297, 2719, 2655, 3969, 1023, 2544, 5490
RichSound Research	5138
Roku	5495
RSR	5138
Samsung	2660, 1868, 2809, 3320, 3382, 3154, 2137, 1304
Samsung Harman/Kardon	3320
Sanyo	4176, 3282
Sceptre	5351
Sennheiser	5330
Sharp	3097, 3736, 3929
Sherbourn	3763
Sherwood	1077, 1567, 3120, 3136, 2169, 3793, 4090, 3770
Sherwood Newcastle	1567, 2169
SnapAV	5107
Sonos	3919
Sony	1622, 3700, 2172, 4315, 1759, 1822, 2522, 2475, 1758, 3257, 2582, 3487, 4457, 0158, 4285, 4366, 2610
Soundcore	5578
Speaker Craft	3661
Stereophonics	1023
TaoTronics	4672
TCL	4672, 5385
Toshiba	3627
VIZIO	3935, 2454, 5095, 4911
Yamaha	2467, 2116, 3580, 3030, 2458, 3325, 3917, 4269, 2021, 0176
Zenith	1293, 2197
ZVOX	2332, 3913, 2334

INSIGNIA™

www.insigniaproducts.com

1-877-467-4289 (U.S. and Canada/EE.UU. y Canadá)

INSIGNIA is a trademark of Best Buy and its affiliated companies.

Distributed by Best Buy Purchasing, LLC

7601 Penn Ave South, Richfield, MN 55423 U.S.A

©2022 Best Buy. All rights reserved.

INSIGNIA es una marca comercial de Best Buy y sus compañías asociadas.

Distribuida por Best Buy Purchasing, LLC

7601 Penn Avenue South, Richfield, MN 55423 E.U.A.

© 2022 Best Buy. Todos los derechos reservados.

V2 ENGLISH/
ESPAÑOL
22-0137