

NC3说明书

尺寸: 70*82mm



Scan the QR code to get the manual in other languages.

Thank you for purchasing the TOZO authentic product. For more latest products, parts and accessories, please visit: www.tozostore.com

For any assistance please contact Email: info@tozostore.com

8.0 TOZO APP

Download the TOZO App for UI customization, EQ settings, and more.

- UI customization: Most of the controls can be customized in the App.

- EQ settings: There are lots of EQ settings you can choose in the App to optimize your experience while enjoying different music genres.


- Earbuds firmware update: The earbuds firmware can be updated in the App.

Once you connect the earbuds to the App, you will be informed if a new version of firmware is detected.

9.0 TOZO APP pairing

Step 1: Download the TOZO App on your phone.

Step 2: Bluetooth pairing with your earbuds.



Step 3: TOZO App pairing with your earbuds.



10.0 EU Battery Regulation

This symbol on the battery(ies) or on the packaging indicates that the battery(ies) provided with this product shall not be treated as household waste. Instead, please separate battery(ies) from other types of waste and recycle it (them) through your local recycling system to protect environment and health. (When Cd is more than 20ppm or Pb is more than 40ppm, the chemical symbol of the excess substance shall be marked under the separate collection symbol) For more detailed information about recycling of this battery(ies), please contact your local authority or the shop where you purchased the product or battery(ies).

11.0 FCC Compliance Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


12.0 ISED Compliance Statements

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:



The power delivered by the charger must be between min 2.5 Watts required by the radio equipment, and max 5.0 Watts in order to achieve the maximum charging speed.


TOZO®
www.tozostore.com



NC3 ACTIVE NOISE CANCELLATION


1.0 Product Overview and Features

The packaging contains TOZO NC3 earbuds preinstalled with M size earbud tips, a charging case, a USB-C cable, extra ear tips, and instructions.




2.0 Wearing Guide

For a better fit, adjust the wearing angle slightly after putting on the earbuds to push them gently into the ear canal.



3.0 Pairing and Connectivity

Remove the earbuds from the case. They'll reconnect to the last paired device if paired before. If not paired or pairing canceled, the earbuds enter pairing mode with a slow white light blink. Search [TOZO NC3] on your phone and connect.



4.0 Power on/off

4.1 Earbuds auto power on

Open the cover and take out the earbuds, and the earbuds will automatically turn on.

4.2 Earbuds auto power off

Placing the earbuds back in the charging case and closing the cover will automatically turn them off.


4.3 Another method of earbuds power on/off

Hold L or R for 3 seconds will turn on when earbuds power off. Hold L or R for 5 seconds will turn off when not playing media. The earbuds will automatically turn off if they remain disconnected for more than 5 minutes.




5.0 Operation and Controls


5.1 Wearing both earbuds




5.2 Wearing one earbud




5.3 Calling Control




5.4 Active Noise Cancellation Control



5.5 Voice Assistant




5.6 Low-latency Mode



6.0 Active Noise Cancellation Mode and Transparency Mode


6.1 Active Noise Cancellation Mode

With Active Noise Cancellation, TOZO NC3 earbuds detect external sounds through an outward-facing microphone and counter them with anti-noise, cancelling them before they reach your ears. Additionally, an inward-facing microphone listens for unwanted internal sounds, which are also negated by the anti-noise feature.



6.2 Transparency Mode


Transparency Mode enhances the voice frequency band, improving awareness of your surroundings, so you can hear what's around you without removing your earbuds. Both Active Noise Cancellation and Transparency Mode work best when your TOZO NC3 fits and is worn properly.



7.0 Charging and Battery

7.1 Charging Case Display On/Off

By default, the display is off. It will activate for 5s and then automatically shut off after opening the case to remove the earbuds, placing the earbuds back in the case, and pressing the reset button once. During charging, the display stays on continuously.



7.2 Charging Case Indicators

When both earbuds are placed in the case, the charging lights on both sides and the case battery light flash for 5s to show charging and battery status. With one earbud, it displays its charging status and case battery level.



7.3 Charging

The charging case won't charge earbuds when below 5%, but it can still power them off. Charge before 5% to avoid interruption. Both earbuds and case need 2 hours to charge fully.



TOZO®
www.tozostore.com



NC3 ACTIVE NOISE CANCELLATION