Marshall

MONITOR II A.N.C.

USER MANUAL

LEGAL AND TRADEMARK NOTICE

- MARSHALL, Marshall Amps, their respective logos, "Marshall" and "Marshall" trade dress are trademarks and intellectual property of Marshall Amplification PIc and may not be used without permission. Permission granted to Zound Industries.
- The Bluetooth[®] wordmark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Zound Industries is under license.
- Google Play and the Google Play logo are trademarks of Google LLC.
- Apple and the Apple logo are trademarks of Apple Inc. registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries.
- All other trademarks are the property of their respective owners and may not be used without permission.

For more legal information related to this product and to its use in your specific region, and for more detailed information about Zound Industries and partner & license information, please visit the website: www.marshallheadphones.com. The user is recommended to visit the website regularly for up-to-date information.

Zound Industries International AB, Centralplan 15, 111 20 Stockholm, Sweden

DISCLAIMER

Use of the Made for Apple badge means that an accessory has been designed to connect specifically to the Apple product(s) identified in the badge and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

The availability of third party services may need separate agreements between you and any third party and Zound Industries International AB do not take responsibility for the availability of such services.

Stated play time is calculated using a random selection of music, played at medium volume.

The information contained herein is correct at the time of publication, with reservation for editorial errors. This product is software dependent and its functions and compatibility can change when updating the software.

Designed in Stockholm • Produced in China

INDEX

002. LEGAL AND TRADEMARK NOTICE

006. GETTING STARTED

006. DEVICE LAYOUT

007. THE CONTROL KNOB

008. THE LED INDICATOR

008. CHARGING YOUR HEADPHONES

009. THE ANC MODE BUTTON

010. THE M-BUTTON

010. THE 3.5 MM INPUT

011. TROUBLESHOOTING



GETTING STARTED

- 001. Push and hold the control knob until the LED indicator blinks blue.
- 002. Select MONITOR II from your audio device's Bluetooth® list.
- 003. Download the Marshall Bluetooth app and follow the in-app instructions to setup the M-button, adjust ANC, customise the EQ settings and more.

Get the Marshall Bluetooth app on Google Play or the App Store.

It is recommended to charge the battery before using your headphones for the first time.

DEVICE LAYOUT

- 001. Customisable M-button
- 002. ANC mode button
- 003. LED indicator
- 004. 3.5 mm input
- 005. USB-C port for charging
- 006. Multi-directional control knob

THE CONTROL KNOB

Use the control knob on the right ear cap to control audio, start Bluetooth^ ${\circledast}$ pairing mode and turn the headphones on or off.

FUNCTION	ACTION
POWER ON/OFF	Push and hold for 2 seconds
PLAY/PAUSE	Single-click
SKIP FORWARD	Push to the right
SKIP BACK	Push to the left
FAST FORWARD	Push to the right and hold
REWIND	Push to the left and hold
TURN UP THE VOLUME	Push upwards
TURN DOWN THE VOLUME	Push downwards
HANDLE CALLS	Single-click to answer or end call
	Double-click to reject an incoming call

THE LED INDICATOR

The LED indicator is located on the left ear cap and shows the headphones status:

LED STATUS	HEADPHONES STATUS
RED-ORANGE-YELLOW-GREEN	Charging (0-100% battery level)
WHITE LIGHT BLINKING EVERY 5TH SECOND	Powered on, connected to a Bluetooth [®] device with audio paused
WHITE BLINKING	Searching for previously paired devices
BLUE BLINKING	Bluetooth pairing mode
OFF	Power off or playing via Bluetooth

CHARGING YOUR HEADPHONES

When the battery charge is low, an alert will sound.

Plug your headphones into a USB power source via the USB-C cable to charge the battery. A full battery recharge takes approximately 2 hours, and 15 minutes of charging can get you up to 5 hours of wireless playtime.

THE ANC MODE BUTTON

Monitor II A.N.C. utilise Active Noise Cancelling (ANC) technology that continuously pinpoints and measures ambient noise to control how much of the outside world you hear.

There are two ANC modes.

- Active noise cancelling Block out the noise and focus on what is playing.
- Monitoring mode Let the outside world in to engage in a conversation or listen to an announcement.

Use the ANC button to quickly change between modes.

001. Short press toggles **Active noise cancelling** and **Monitoring mode** 002. Push and hold for 2 seconds to turn ANC off or on

The level of noise cancelling and monitoring can be adjusted in the Marshall Bluetooth app.

THE M-BUTTON

The M-button can be set to switch between three different equaliser presets or alternatively, your phones voice assistant or the Google Assistant.

Go to the Marshall Bluetooth app and configure the M-button from the M-Button settings menu

Note: Voice assistant may not be available in your country and requires a separate account/agreement between you and the third party service.

THE 3.5 MM INPUT

To use the Monitor II A.N.C. with a wired device, simply use the 3.5 mm cable included. Once connected, Bluetooth will disconnect for audio streaming. You can still use ANC, as long as your headphones are turned on.

When the 3.5 mm cable is disconnected, the headphones will try to reconnect with the last connected Bluetooth device.

TROUBLESHOOTING

PROBLEM	CAUSE	ACTION	PROBLEM	CAUSE	ACTION
CANNOT PAIR WITH A BLUETOOTH DEVICE	The headphones are not in pairing mode.	Make sure the headphones are turned off. Push the control knob for 4 seconds, until the LED indicator blinks blue. Select MONITOR II from your Bluetooth device list.	THERE ARE TWO INSTANCES O MONITOR II IN THE BLUETOOTH DEVICE LIST		This is normal behaviour a action is needed.
			THE HEADPHONES ARE NOT	A software error has occurred.	Perform a hardware reset
	Your headphones are connected to the 3.5 mm lead.	Disconnect the 3.5 mm cable from your headphones before Bluetooth pairing	RESPONDING		Push and hold the M-butto while pushing the control downwards.
ANC IS NOT WORKING	Your headphones are not turned on.	Push the control knob for 2 seconds to turn on your headphones.			If the problem persists, pe factory reset.
	ANC is not on.	Push the ANC button for 2 seconds to turn ANC on.			Note: This will delete all us settings and after the factor reset, the headphones nee
		Short-press the ANC button to toggle the ANC modes.			set up again. Push and hold both the M-
	ANC level is turned down in the Marshall Bluetooth app.	Go to the Marshall Bluetooth app and set the level of the ANC in the ANC settings menu.			and the control knob for 7 seconds until the LED indic turns purple.

MARSHALLHEADPHONES.COM