

## Wii Rechargeable Induction Battery



### Package contents


- Rechargeable induction battery (1)
- *Quick Setup Guide*




**WARNING:** The RF-GWII053 rechargeable induction battery is designed only for use with the RF-GWII052 Induction Charge Kit (sold separately).

### Installing the battery


- 1 Remove the Wii remote jacket (if necessary), then remove the battery compartment cover.



- 2 Install the battery pack into the remote.




- 3 Put the Wii remote jacket back on the remote.



### Using the charger

- 1 Insert the plug into the **DC IN** connector on the remote induction charger (sold separately), then plug the AC adapter into a power outlet.



- 2 Turn on the charger, then place the remote with the battery pack installed on the charger. The charger will work with or without the jacket on the Wii remote.



**Note:** You should place the remote parallel with the center bar and the remote should be straight and centered on the charger.



Charging starts if the charger detects the battery pack and the glow bar lights red. There may be a brief delay before you see the light. When the battery pack is fully charged, the glow bar changes to green.

**Notes:**

- The rechargeable battery pack must be fully charged before being used for the first time. Approximate full charge time is 4 hours. A light will indicate when the battery is fully charged.
- Rechargeable battery packs only attain maximum charging capacity after they have been charged and discharged several times.
- The battery pack has a limited service life, and playing time is reduced after many charging cycles.

**Battery warnings:**

- Do not handle a damaged or leaking battery pack. Contact with the material can result in injury or burns to the eyes or skin. Even if foreign substances are not immediately visible, chemical changes in the material can result in injuries occurring at a later time. If you come into contact with material from a leaking battery pack, take the following actions:
  - If the material gets into the eyes, do not rub. Immediately flush the eyes with clean water and seek medical attention.
  - If the material comes into contact with the skin or clothes, immediately rinse the affected area with clean water. Consult your physician if inflammation or soreness develops.
- Do not allow the battery pack to come into contact with fire or subject it to extreme temperatures such as in direct sunlight, in a vehicle exposed to the sun, or near a heat source.
- Do not cause the battery pack to short-circuit.
- Do not disassemble or tamper with the battery pack.
- Prevent damage to the battery pack. Do not carry or store the battery pack with metal items such as coins or keys. If damaged, discontinue use.
- Do not throw or drop the battery pack or subject it to strong physical shock.



- Do not put heavy objects on or apply pressure to the battery pack.
- Do not allow the battery pack to come into contact with liquids. If it becomes wet, discontinue use until it is completely dry.
- Keep the battery pack out of reach of small children.
- Dispose of batteries in accordance with local and national disposal regulations (if any).
- If the Wii remote will not be used for an extended period of time, remove the battery pack and store it in a cool, dry place.

**90-day limited warranty**

Visit [www.rocketfishproducts.com](http://www.rocketfishproducts.com) for details



Wii is a trademark of Nintendo of America, Inc. ROCKETFISH is a trademark of Best Buy Enterprise Services, Inc. © 2009 Best Buy Enterprise Services, Inc. All rights reserved.

ENGLISH 09-0480

