


2.1" Circular USB-C Display Solution

2.1" Napster View 3D Display

Installation, safety and user manual



Version 1.0

CONTENT

1. FOREWORD.....	4
1.1 Notes on documentation.....	4
2. SAFETY, OPERATION & MAINTENANCE	5
2.1 Explanation of the safety symbols	5
2.2 Basic security measures.....	6
2.3 Duty of care for the operator.....	7
2.4 Requirements for the operating personnel	7
2.5 General Warning	7
3. WARRANTY.....	8
3.1 Warranty claims & repair	8
3.2 Life support policy warning	9
3.3 In case of defect	9
4. Product Description.....	10
4.1 Appropriate use.....	10
4.2 Interfaces	11
4.3 Scope of delivery	12
5. Installation Instructions	13
5.1 Transportation	13
5.2 Unpacking.....	13
5.3 Mounting options.....	14
5.4 Connecting the device	14
6. Operating Instructions.....	15
6.1 Initial power-up and driver installation.....	15
6.2 Troubleshooting.....	15

7. Service and Support.....	16
7.1 Service.....	16
7.2 Contact	16
8. Appendix	17
8.1 CE and UKCA - Declaration of Conformity	17

1. FOREWORD

Please read this manual carefully prior to use of the product, and keep it properly.

1.1 Notes on documentation

This description is intended exclusively for trained specialists in controlling and automation technology who are familiar with the applicable national standards. For installation and commissioning of the components it is absolutely necessary to observe the following notes and explanations. The qualified personnel must ensure that the application or use of the described products meets all safety requirements, including all applicable laws, regulations, provisions and standards.

Disclaimer

This documentation has been carefully prepared. However, the products described are subject to continuous further development. Therefore, the documentation is not always completely checked for compliance with the described performance data, standards or other features. If it contains technical or editorial errors, we reserve the right to make changes at any time and without notice. The information, illustrations and descriptions in this documentation do not constitute grounds for claims for changes to products already supplied.

Copyright

© Napster

Passing on and reproduction of this document, use and communication of its contents are prohibited unless expressly permitted. All rights reserved in case of patent, utility model or design patent registration.

State of delivery

All components are delivered in specific hardware and software configurations depending on the application requirements. Changes to the hardware or software configuration, which go beyond the documented possibilities are not permitted and result in the exclusion of liability of Napster.

Notice on waste recycling

If this Product is no longer needed or reaches its service life, it shall be submitted to the qualified recycling plants recognized by state in accordance with the relevant laws and regulations for recycling of waste electric products in order to care and protect our earth.

2. SAFETY, OPERATION & MAINTENANCE

2.1 Explanation of the safety symbols

The following safety symbols are used in these operating instructions. These symbols are primarily intended to draw the reader's attention to the text of the adjacent safety instructions.

 DANGER	Acute danger of injury! If the safety instruction next to this symbol is not observed, there is an immediate danger to life and health of persons.
 WARNING	Caution Risk of injury! If the safety instruction next to this symbol is not observed, there is a danger to life and health of persons.
 CAUTION	Injury to persons! If the safety instruction next to this symbol is not observed, persons may be injured.
 Attention	damage to the environment or equipment If the note next to this symbol is not observed, the environment or equipment may be damaged.
 Note	Tip or pointer This symbol indicates information that contributes to better understanding.

2.2 Basic security measures

Below are some basic security measures to ensure proper operation of the display.

 Attention	<p>Switch off all system components, then disconnect the fieldbus</p> <p>Before opening the display housing and whenever the display is not used for control purposes, for example during the functional test after a repair, all system parts must first be switched off and then the display must be disconnected from the system.</p> <p>Switched off system parts must be secured against being switched on again.</p>
---	---

 Attention	<p>Do not replace any parts when under voltage</p> <p>When installing and removing components, the supply voltage must be switched off.</p> <p>Damage can occur during installation in the display:</p> <ul style="list-style-type: none"> • If metal objects such as screws or tools are placed in the circuit boards. • If display internal connection cables are pulled off or plugged in during operation.
--	---

2.3 Duty of care for the operator

The operator must ensure that:

- The display is only used for its intended purpose (see chapter Product Description).
- The display is only operated in a faultless, fully functional condition.
- The operating manual is always available in a legible condition and complete at the place of use of the display.
- Only sufficiently qualified and authorized personnel operate, maintain and repair the Touch PC.
- This personnel is regularly instructed in all applicable questions of occupational safety and environmental protection, and the operating manual and in particular the information contained therein contained in the safety instructions.
- All safety and warning notices attached to the display are not removed and stay legible.

Depending on the type of machine and system in which the display is used, there are national regulations for the control of such machines and systems which the operator must comply with. These regulations regulate, among other things, the intervals at which the controller must be checked.

The operator must arrange for this inspection within a certain period of time.

 Attention	<p>Only qualified personnel may open the housing of the Touch Monitor</p> <p>The operator must ensure that only trained electrical specialists open the housing of the Monitor. In this case the warranty will become invalid.</p>
---	---

In the event of faults on the display, the list in the Troubleshooting section can be used to determine which measures should be taken.

2.4 Requirements for the operating personnel

Every user of the display must have read this operating manual.

2.5 General Warning

If you notice a burning smell or the device is making noise, disconnect it from the power supply immediately.

 Note	<p>Cleaning</p> <p>To clean the device, switch it off and use a dry, soft cloth with light pressure.</p>
--	---

3. WARRANTY

3.1 Warranty claims & repair

Napster devices are produced following the most modern production and test processes. Carefully selected components and accurate production ensure reliable operation and long life. Napster warrants to the original purchaser that each Napster display delivered shall be free from defects in material or workmanship at time of shipment, and that each such module delivered will meet the published specifications for a period of 24 months as measured from the date of original shipment. Napster's obligation under the Warranty contained herein is limited to the repair or replacement of any Napster touch monitor that does not meet the specifications, provided that said product is returned to Napster, transportation charges pre-paid, and provided that upon Napster's examination, the product, when tested within the specified ratings and in accordance with good engineering practice, does not meet the specifications as defined. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WITHOUT LIMITATION THE WARRANTY OF MERCHANTABILITY AND THE WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

All claims under warranty must be made promptly after occurrence of circumstances giving rise thereto and must be received within the applicable warranty period by Napster or its authorized representative. Such claims should include the Product type and serial numbers and a full description of the circumstances giving rise to the claim. Before any Products are returned for repair and/or adjustment, written authorization from Napster or its authorized representative for the return and instructions

as to how and where these Products should be shipped must be obtained. Any product returned to Napster for examination shall be sent prepaid via the means of transportation indicated as acceptable by Napster. Napster reserves the right to reject any warranty claim not promptly reported and any warranty claim on any item that has been altered or has been shipped by non-acceptable means of transportation. When any Product is returned for examination and inspection, or for any other reason, Customer will be responsible for all damage resulting from improper packing or handling and for loss in transit, notwithstanding any defect or nonconformity in the Product. In all cases Napster has sole responsibility for determining the cause and nature of failure, and Napster's determination with regard thereto shall be final. If it is found that Napster's Product has been returned without cause and is still

serviceable, customer will be notified and the Product returned at Customer's expense. In addition, a charge for testing and examination may, in Napster's sole discretion, be made on Products so returned. SELLER'S LIABILITY FOR DAMAGES SHALL NOT EXCEED THE PAYMENT, IF ANY, RECEIVED BY SELLER FOR THE UNIT OF PRODUCT OR SERVICE FURNISHED OR TO BE FURNISHED AS THE CASE MAY BE WHICH IS THE SUBJECT OF CLAIM OR DISPUTE. IN NO EVENT SHALL SELLER BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES. LIABILITY TO THIRD PARTIES, FOR BODILY INJURY INCLUDING DEATH, RESULTING FROM SELLER'S PERFORMANCE SHALL BE DETERMINED IN ACCORDANCE WITH APPLICABLE LAW AND THE TOTAL LIABILITY LIMITATION STATED ABOVE SHALL NOT BE CONSTRUED AS A LIMITATION ON SELLER FOR DAMAGES FOR ANY SUCH BODILY INJURY, INCLUDING DEATH.

WARRANTY FOR ITEMS REPLACED UNDER WARRANTY Whenever a failed module is replaced under Warranty, the greater of the balance of the original Warranty Period or 90 days will constitute the remaining warranty period. The replaced unit does not carry a new Warranty.

3.2 Life support policy warning

LIFE SUPPORT POLICY "WARNING: DO NOT USE IN LIFE SUPPORT" SELLER'S PRODUCTS ARE NOT AUTHORIZED FOR USE AS CRITICAL COMPONENTS IN LIFE SUPPORT DEVICES OR SYSTEMS WITHOUT THE EXPRESS PRIOR WRITTEN APPROVAL OF THE CEO OF Napster. As used herein, "Life Support Devices or Systems" are devices which support or sustain life and whose failure to perform when properly used in accordance with instructions for use provided in the labeling can be reasonably expected to result in a significant injury to the user. A "Critical Component" is any component in a life support device or system whose failure to perform can be reasonably expected to cause the failure of the life support device or system or to affect its safety or effectiveness.

3.3 In case of defect

If your device does have a defect within the warranty period, please contact Napster directly. The warranty period is 24 months from the date of purchase under the following conditions:

- All warranties are void if the unit has been opened or disassembled without Napster's prior approval.
- Damage caused by improper handling or operation, by incorrect installation or storage, through improper connections, as well as due to force majeure or other external influences are not covered by the warranty.
- For warranty claim, we reserve the right to replace the defective components or to exchange the device.
- Exchanged components or devices become the property of Napster.
- Claims for damages are excluded in so far as they are not based on intent or gross negligence of the manufacturer.
- After expiration of the warranty period, warranty claims can no longer be pursued.
- Any warranty claim must be accompanied by proof of purchase (receipt or invoice).

4. PRODUCT DESCRIPTION

4.1 Appropriate use


This display is meant to be used as an AI avatar display mounted on top of your monitor or laptop screen to provide an LCD display capable to be powered on and linked through a single Type-C USB cable



Front of 2.1" Napster View Circular Display




Back side of 2.1" Napster View Circular Display



Front & integration example of the 2.1" Napster View Circular Display

4.2 Interfaces

Interfaces of the display



Drawing of the 2.1" Napster View Circular Display

Single Type-C USB

The signal and power are both transmitted through this single type-C USB (1). The input is 5V, with 1.5A (max).


Front Clip

the front clip (2) is used to stabilize the round display over a monitor or laptop screen from the front.

Back Clip

Flippable back clip (3) which allows for stabilizing the mounting on a monitor or laptop screen from the back, it also can be flipped to allow for a free-standing solution.

4.3 Scope of delivery



Type-C USB Cable

A Type-C USB cable is included in the delivery (1). various lengths are available.

Brief instructions

This quick guide (2) contains the most important information about the display.
Unplugging Instructions

<p>Attention</p>	<p>Cleaning the device</p> <p>Make sure that you only clean when the device is off.</p>
-------------------------	--

5. INSTALLATION INSTRUCTIONS

5.1 Transportation

Despite the robust design, the built-in components are sensitive to strong vibrations and shocks. Therefore, protect your display from high mechanical stress during transport. Use the original packaging for shipping.

<p>Attention</p>	<p>Risk of damage to the device</p> <p>When transporting the device in cold weather or if the device is exposed to extreme temperature fluctuations, make sure that no moisture (condensation) condenses on or in the device.</p> <p>Allow the device to slowly adjust to room temperature before putting it into operation. If there is condensation, the unit may only be switched on after a waiting period of about 12 hours.</p>
-------------------------	--

5.2 Unpacking

Proceed as follows when unpacking the device:

1. Remove the packaging.
2. Do not throw away the original packaging. Keep it for re-transport.
3. Check the delivery for completeness based on your order.
4. Please keep the documents supplied with the device; they contain important information about the device and on how to use it.
5. Check the package contents for visible transport damage.
6. If you notice transport damage or discrepancies between the contents of the package and your order, please inform the Napster service team.

5.3 Mounting options

There are several ways to mount the device:

1. Clip it directly on the back of a monitor or laptop using the front and back clips.
2. Use the clips as freestanding by flipping them backwards.

 Note	<p>Own mounting solution</p> <p>Of course it is also possible to use your own mounting solutions. Napster is not responsible for the proper use of the mountings.</p>
--	--

5.4 Connecting the device

The connectors is located at the rear of the product and are documented in the chapter Product Description. To start the device, connect it to a power source with the supplied type-c USB cable or any other of your own cables. Make sure it provides at least 5V and maximum 1.5W.

 Attention	<p>Own power supply</p> <p>Only use your own power supply unit if you are aware of the use of the power supply unit. If the wrong voltage is used, it may destroy the unit.</p>
---	--

 CAUTION	<p>Fire or smoke</p> <p>If the appliance catches fire or starts smoking, immediately unplug the appliance and then extinguish with powder or nitrogen.</p>
---	---

6. OPERATING INSTRUCTIONS

6.1 Initial power-up and driver installation

To turn the unit on, simply connect it to another appliance such as a Macbook, Ipad or Iphone.

6.2 Troubleshooting

No image

1. First check whether the power cable is correctly connected and working.
2. Make sure that the source of the power is on and working properly.
3. If none of the above points leads to success, please contact our direct Manufacturer service, under the contact details given on the Service and Support page.

7. SERVICE AND SUPPORT

7.1 Service

If you think your Napster product has a defect please always contact us directly. Our trained after sales service specialists can help you to resolve your problems regarding the device. Please check the manual and our frequently asked questions before contacting us – you will usually find an answer to your question.

Please attach your invoice and a detailed description of the issues you are facing with your device to your contact E-mail/fax. In reply, you will receive an e-mail/fax with your RMA number and additional information. For defective accessories that were content of the original delivery, we usually send you a replacement before receiving the damaged goods. In case of a defective product, we try to check and solve the problem within 3 working days after receipt. Make sure that shipping has been paid before sending the goods back to us. We do not accept postage due packages at our service centers. Anything shipped with postage due will be rejected. Within the first 30 days after the purchase of a new Napster product, we will refund the shipping costs for returned defective products. For the rest of the warranty period, we will only cover shipping costs for repaired or replaced items that we ship back to you (one way).

For support outside of China, we work with local representatives / local service partners together who may work on our behalf in our name. For more information, feel free to contact us under the following contact details.

7.2 Contact

Napster Corporation
1489 W Palmetto Park Drive, Suite 320
Boca Raton, FL 33486

Need full installation, warranty, or safety details?
napster.ai/view/manual

8. APPENDIX

8.1 CE and UKCA - Declaration of Conformity

Hereby Napster declares that the equipment is in compliance with the essential requirements and other relevant regulations of the directives 2014/30/EU, 2014/35/EU, 2011/65/EU, 2015/863 RoHS, UK SI 2016/1091 and UK SI 2016/1101.

The long version of the CE Declaration of Conformity can be found in English at: www.napster.ai

Version 1.0

2.1" Round Napster View circular display

Product Series