

© Arlo Technologies, Inc. Arlo, Arlo logo, and Every Angle Covered are trademarks of Arlo Technologies, Inc. Any other trademarks are for reference purposes.


Si ce produit est vendu au Canada, vous pouvez accéder à ce document en français canadien à [arlo.com/docs](https://www.arlo.com/docs).

(If this product is sold in Canada, you can access this document in Canadian French at [arlo.com/docs](https://www.arlo.com/docs).)

For regulatory compliance information including the EU Declaration of Conformity, visit www.arlo.com/about/regulatory/.

CE Arlo Technologies Intl. Ltd
Ground Floor, Building 3
University Technology Centre
Curraheen Road, Cork T12 EF21
Ireland

December 2019



201-50267-01

Arlo Technologies, Inc.
2200 Faraday Avenue, Suite 150
Carlsbad, CA 92008 USA



Ceiling adapter

What's in the box




Ceiling adapter




Screw Kit

Set up the ceiling adapter

1. Mount the adapter to the ceiling using the provided screws.



2. Align the base of the Arlo Floodlight Camera swivel mount to the bottom right dot and then rotate the device clockwise to lock in place.



3. Tighten the locking screw.

Need help?

We are here for you.

Visit www.arlo.com/support for quick answers and resources:

- How-to videos
- Troubleshooting tips
- The Arlo Support phone number for your location