

# How to make moves with your C-start smart switch:

①

Schedule your motion sensor to sleep when you sleep.

Go to **C by GE app** and set the response schedule under **room motion sensor**.

②

Automate your lights by enabling ambient light and motion detection.

Go to **C by GE app** and enable the ambient light sensor under **room motion sensor**.

③

Preset brightness levels.

Dim switch to desired level, then turn off. Use **Dim** button instead of center on/off button to turn on lights at the preset level.

④

Control other **C by GE bulbs** in the room with your switch.

Go to **C by GE app**. Add bulbs and switches to a room under **create a room**.  
(sold separately)

# Touch Controls & Sensors

Connect to your Alexa or Google Assistant device to control your lights with your voice.

**Try these voice commands:**

## Amazon Alexa

Alexa, turn off the living room.

Alexa, good morning.


Alexa, set kitchen to 50%.

## Google Assistant

Hey Google, turn on the lights.

Hey Google, set bedroom to 20%.

Hey Google, I'm leaving.



**Air Gap**

(When changing light bulbs, pull out to turn off power to the sockets)