

37-Key Electronic Piano Toy

TY578001

USA office: Fontana

GBR office: Ipswich

AUS office: Truganina

If you're having difficulty, our friendly
customer team is always here to help.



USA:cs.us@costway.com
AUS:cs.au@costway.com
GBR:cs.uk@costway.com

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

KEYS AND OPERATION

8 Kinds of Musical Instruments:

Music box, piano, guitar, Clarinet, violin, trumpet, mandolin, flute.

Let the kid to identify different instrument timbre.

Demo Mode:

22 demonstrative songs constant playing. Press the button, it will change to another song.

3 Kinds of Teaching Mode:

Teaching 1: Teach one note at a time

Teaching 2: Teach a few notes at a time

Teaching 3: In the "Demo Mode", press "Teaching 3" to practice the whole piece

Random Play Function:

Just play it randomly and you'll get the wonderful right note.

4 Kinds of Drum Sounds:
Drum1, Drum2, Drum3, Drum4

Power on/off

Recording Button:

Press the record button to start recording, you can record songs when playing the piano, and then enjoy it again.

Stop Button:

You can pause all sounds.

Replay Button:

To play the music that has been recorded.

Volume +/-:

The volume can be adjusted.

Tempo +/-:



The tempo can be adjusted.

8 Kinds of Rhythms:

Rock, slow rock, twist, disco, march, waltz, samba, blues.
In order to make kids have a better sense of rhythm when they are in their childhood.



Lighting cue function:

The light will cue when kids are playing music, to guide kids to play.



BATTERIES

Please take out the batteries when not in use for a long term. Requires 4 X 1.5V "AA" batteries.



WARNING:

This product should be assembled by adults, please don't discard the dismantled packing box. Small parts are not for children under 3 years to avoid choking hazard.

37-Key black and white keyboard, Lets play music together!