

+ Nila Bottle (Tritan Plastic)

INSTRUCTIONS FOR USE:

- ALL PARTS ARE TOP-RACK DISHWASHER SAFE.
- DO NOT MICROWAVE, FREEZE, OR BOIL.
- NOT FOR USE WITH HOT, CARBONATED, OR PERISHABLE LIQUIDS.
- AVOID ACCIDENTAL OPENING OF THE BOTTLE BY KEEPING THE BUTTON FREE AND CLEAR OF OTHER OBJECTS.
- COVER THE BUTTON WITH THE LOOP TO HELP AVOID ACCIDENTAL PUSHING OF THE BUTTON.
- WHEN OPENING THE BOTTLE, KEEP FINGERS AWAY FROM THE RECESS BEHIND THE SPOUT COVER.

WARNINGS:

- DRINKING HOT LIQUIDS PRESENTS A RISK OF INJURY.
- THE STRAW ALLOWS GENEROUS AMOUNTS OF LIQUID TO BE DRAWN SUDDENLY INTO THE MOUTH FROM THE BOTTOM OF THE BOTTLE WHERE THE TEMPERATURE OF HOT LIQUIDS IS USUALLY HIGHER THAN IT IS AT THE LIQUID'S SURFACE.
- HOT, CARBONATED, AND PERISHABLE LIQUIDS AND OTHER CONTENTS MAY BUILD UP PRESSURE WITHIN THE BOTTLE AND UNEXPECTEDLY LEAK OR SPRAY OUT.
- PRESSURIZED CONTENTS ALSO MAY CAUSE THE SPOUT COVER TO OPEN RAPIDLY ENOUGH TO INJURE FINGERS POSITIONED IN OR NEAR THE RECESS BEHIND THE SPOUT COVER.
- ALWAYS OPEN WITH CAUTION.