



LASK Installation Instructions

Lynx Accessory Switch Kit



Introduction:

These instructions detail the electrical connections for Lynx Accessories to an independent power source for the following products:

LSB1	Single Side Burner	LPB	Power Burner	LSBGE	Grill Extender
LSB2	Double Side Burner	LSB2PC	Prep Center		

Lynx Accessory Switch Kit: Model LASK

The Lynx Accessory Switch Kit is designed to power a Lynx Accessory burner directly without a connection to the grill. The kit contains a transformer as well as a switch assembly with a mounting plate. The kit also contains a wire harness to adapt a 2009 series accessory to the switch and transformer.




Precautions while working on electrical connections:


Read and understand the instruction manuals provided with both the grill and accessory being installed. Review these instructions in their entirety before beginning.

TURN OFF ALL GAS AT IT'S SOURCE to the appliances **BEFORE** beginning any electrical work. When working on an island installation, open any doors or drawers and allow the space to ventilate before beginning any work. Unplug the transformer from it's receptacle under the island.


Connector identification:




4 pin PLUG



4 pin RECEPTACLE



2 pin PLUG



2 pin RECEPTACLE