



30" SLIDE IN GAS CONVECTION RANGE


MODELS:

KSGG700EBL0 (Black)

KSGG700EWH0 (White)

KSGG700ESS0 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7		Knob	20		Console, Lower Panel
	W10665256	Instructions, Installation		W10786065	Stainless (All except Left Front)		W10555932	Black
	W10722060	Guide, Use & Care		W10786064	Stainless (Left Front)		W10555933	White
	W10665227	Sheet, Tech			Kit, Grate		W10555934	Stainless
	W10703182	Wire Diagram	8			21	W10606241	Bracket, Anti-Tip
	W10400066	Guide, Quick Start (English)		W10432520	Black	22	W10162253	Brace, Corner (Left)
	W10400067	Guide, Quick Start (French)	9	W10673618	Screw		W10162252	Brace, Corner (Right)
			10	W10289170	Support, Cooktop (Left)	23	W10555923	Bracket, User Interface
2		Kit, Burner Cap		W10289169	Support, Cooktop (Right)	24	W10598048	Bracket, Console (Center)
	W10479989	Black				25	W10757531	Keypad, Shield
3		Console	11	8016P022-60	Glide, Main Top	26	3196169	Screw
	W10547095	Black	12		Endcap	27	W10612719	Gasket, Console/ Cooktop
	W10547094	White		W10555936	Black (Left)			
	W10547096	Stainless		W10555939	Black (Right)	28	W10465081	Grate, Bumper
4	W10495853	Spreader, Flame (Left Front)		W10555935	White (Left)			FOLLOWING PARTS NOT ILLUSTRATED
	W10464795	Spreader, Flame (Left Rear)		W10555938	White (Right)		W10580231	Harness, Main
	W10256028	Spreader, Flame (Right Front)		W10555937	Stainless (Left)		W10754419	Harness, Bake/Broil
	W10256025	Spreader, Flame (Right Rear & Center)		W10555940	Stainless (Right)		W10598169	Harness, Display
			13		Trim, Vent		W10575120	Harness, Keypad
				W10577781	Black		313438	Clip, Harness
				W10577780	White		3196520	Clip, Wire
5		Cooktop	14	W10453983	Control, MRC2		W10580229	Wire, Ground
	W10536181	Black	15	W10603096	Assembly, Display		W10681410	Kit, LP Conversion
	W10536182	White	16	W10558372	Bracket, Control		W10566535	Kit, LP Conversion (Bake/Broil)
6	7101P485-60	Screw, Anti-Tip Kit	17		Bezel		7111P017-60	Clamp, Wire
				W10785119	Stainless (Kit of 5)		W10182767	Tie, Manifold Wire
			18	W10645947	Grommet			
			19	W10664705	Bumper			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10614920	Assembly, Flue	18	W10323077	Diffuser, Flame	36	W10554007	Rack, Steam
2	9758701	Spacer, Door	19	3196178	Screw	37	W10137382	Clip, Panel
3	W10273002	Bracket, Oven Support	20	W10289166	Back, Main	38	W10457998	Module, Spark (0+2)
4		Panel, Side	21	W10162385	Gasket, Door	39	W10475149	Module, Spark (5+0)
	W10162245	Black	22	W10031780	Screw	40	W10655451	Guard, Splash
	W10575396	White	23	W10686408	Kit, Reservoir (Steam Rack)	41	W10162254	Duct, Cooling
5	W10877642	Assembly, Cooling Fan	24	W10273192	Rod, Door Switch	42	W10162255	Duct, Cover
6	W10627802	Switch, Door	25	W10889764	Cord, Power	43	W10273204	Pan, Bake
7	W10554006	Rack, Maximum Capacity	26	W10035900	Support, Oven Bottom	44	W11117035	Shield, Wire
8	W10554005	Rack, Heavy Duty	27	W10541959	Shield, Bake	45	W10162257	Duct, Cooktop
9	W10289077	Receiver, Hinge	28	W10454648	Assembly, Light	46	W10289172	Cover, Back
10	W10058460	Foot, Leveling	29	7407P103-60	Bulb, Light	47	W10162249	Cover, Wire
11	W10211368	Bottom, Oven	30	W10341186	Assembly, Front Foot	48	W10162241	Channel, Rear
12	W10586204	Sensor	31	W10390008	Assembly, Base Rail (Left)	49	W10289168	Box, Burner SI
13	3601P356-45	Baffle, Bake Burner		W10390007	Assembly, Base Rail (Right)	50	3196560	Screw
14	3196178	Screw				51	W10067840	Screw
15	W10552502	Element, Broil Assist	32	W10558276	Box, Burner Gas			INSULATION
16	W11040249	Assembly, Flue (Upper)	33	W10874477	Assembly, Convection	4820F015-59		Insulation, Strap
17	W10362924	Screw	34	W10346153	Baffle, Full Convection	W10289173		Insulation, Wrap
			35	W10362924	Screw	W10162240		Insulation, Back


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	7	W10826727	Assembly, Manifold	17	W10506739	Orifice (17K)
2	W10552123	Orifice, Assembly (Left Front)	8	W10432224	Valve, Gas Duel (Left Front)		W10256132	Orifice (1.2K) (Left Front)
	W10552121	Assembly, Orifice (Left Rear)		W10831591	Valve, Gas (Left Rear)		W10515054	Orifice (5K) (Left Rear)
	W10552120	Assembly, Orifice (Right Front)		W10566062	Valve, Gas (Right Front)		W10434277	Orifice (1.8MM) (Right Front)
	W10552119	Assembly, Orifice (Right Rear)		W10566057	Valve, Gas (Right Rear & Center)		W10657949	Orifice (9.2K) (Right Rear)
	W10552124	Assembly, Orifice (Center)	9	W10224921	Bracket, Aegis		W10657947	Orifice (8K) (Center)
3	W10295996	Bracket, Saddle Valve	10	W10439242	Burner, Broiler	18	3196178	Screw
4	W10432252	Tube, Gas Supply	11	W10680035	Burner, Bake	19	3196385	Screw
5	W10432517	Harness, Switch Spark	12	W10554066	Valve, Regulator	20	3400016	Screw
6	W10496874	Electrode (Left Front)	13	W10324262	Igniter, Bake	21	3601P336-45	Baffle, Broil Burner
	W10464799	Electrode (Left Rear)	14	W10306050	Tube, Broil Supply (Broiler Fitting To Valve)	22	W10575401	Clip, Spring (Electrode)
	W10496870	Electrode (Right Front & Center)	15	W10583216	Fitting, Broil Burner		W10256046	Clip, Spring (Electrode) (Left Front Only)
	W10496872	Electrode (Right Rear)	16	W10333842	Electrode, Broil	23	W10140571	Seal, Switch Shaft


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10541911	Bracket, Glass Upper Handle	6		Assembly, Door Handle	11	W10319024	Washer, Door
2	8533988	Screw		W10551000	Stainless	12	W10541883	Hinge, Support Rail
3		Assembly, Outer Door	7	W10031780	Screw	13	W10031790	Screw
	W10634272	Black	8	9780274	Screw	14	W10518672	Badge
	W10634273	White	9		Scoop, Door	15	W10327235	Screw
	W10634271	Stainless		W10613791	Black	16	W10541885	Support, Glass
4	W10541882	Liner, Door		W10613790	White			
5	W10541888	Glass, Inner		W10551024	Stainless			
			10	W10388635	Hinge, Door (Active)			

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle, Drawer
	W10551000	Stainless
2	W10688022	Drawer, Storage
3	W10318026	Bracket, Mounting

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4		Panel, Drawer Front
	W10541953	Black
	W10541952	White
	W10541954	Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10441804	Slide, Drawer (Left)
	W10441805	Slide, Drawer (Right)
6	8533988	Screw
7	3823F017-45	Spacer, Handle

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	31463A	Protectant, Cooktop
	31605	Kit, Cooktop Care
	W10355016	Cleaner, Stainless Steel
	W10355051	Cleaner, Cooktop
	W10391473	Pad, Cooktop Cleaning
	W10355049	Wipes, Stainless Steel Cleaning
	W10275756	Cleaner, Granite
	31617A	Cleaner, Grate & Drip Pan
	WA906B	Scraper, Cooktop
	242905	Kit, Canning Unit
	4396923	Grid, Broiler Pan and
	W10123240	Rack, Broiler Pan & Roasting
	W10432545	Kit, Grill
	W10432019	Alt Cleaning Kit Assembly, Trim (5/8")
	W10675026	Black
	W10675027	White
	W10675028	Stainless (1 1/8")
	W10731886	Black
	W10731885	White
	W10731887	Stainless Assembly, Backsplash
	W10655449	Black
	W10655448	White
	W10655450	Stainless