








Dell 24 Adjustable Stand Monitor




SE2426HS




Quick Start Guide









HDMI HDMI





















1







2




3







Dell Display and Peripheral Manager
Dell.com/support/ddpm



Dell.com/support/SE2426HS