



Lenovo

IdeaPad L340 Series


SETUP GUIDE

Lenovo

Initial Setup



Overview



- | | |
|------------------------------------|---------------------------------------|
| 1. Camera | 11. Speakers |
| 2. Shutter | 12. Power LED |
| 3. Camera indicator | 13. Novo button |
| 4. Wireless LAN/Bluetooth antennas | 14. USB-C™ connector |
| 5. Microphones | 15. Audio connector |
| 6. Mini security-lock slot | 16. USB 3.0 connector |
| 7. CD/DVD drive | 17. HDMI™ connector |
| 8. Screen | 18. Ethernet connector |
| 9. Ventilation slots | 19. Battery/Charging status indicator |
| 10. Touchpad | 20. ac power connector |

Note:

Read the statement on USB transfer rate in the *User Guide*. Refer to the *Safety and Warranty Guide* for accessing the *User Guide*.

Additional information

European Union – compliance with the Radio Equipment Directive

Hereby, Lenovo (Singapore) Pte. Ltd., declares that the radio equipment type(s) IdeaPad L340-15API, IdeaPad L340-15APITouch, and IdeaPad L340-17API are in compliance with Directive 2014/53/EU.

The full text of the system EU declaration of conformity and the EU wireless module declarations are available at the following Internet addresses:

- For notebook computers:
<https://www.lenovo.com/eu-doc-notebooks>
- For tablets:
<https://www.lenovo.com/eu-doc-tablets>

This radio equipment operates with the following frequency bands and maximum radio-frequency power:

Technology	Frequency band [MHz]	Maximum transmit power
WLAN 802.11b/g/n	2400 - 2483.5	< 20 dBm
WLAN 802.11a/n/ac	5150 - 5725	< 23 dBm
WLAN 802.11a/n/ac	5725 - 5875	< 13.98 dBm
Bluetooth BR/EDR/LE	2400 - 2483.5	< 20 dBm

First Edition (February 2019)

© Copyright Lenovo 2019.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration "GSA" contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Reduce | Reuse | Recycle

